

Linux driver for Brocade FC/FCOE adapters

Supported Hardware

bfa 3.0.2.2 driver supports all Brocade FC/FCOE adapters. Below is a list of adapter models with corresponding PCIIDs.

PCIID	Model
1657:0013:1657:0014	425 4Gbps dual port FC HBA
1657:0013:1657:0014	825 8Gbps PCIe dual port FC HBA
1657:0013:103c:1742	HP 82B 8Gbps PCIe dual port FC HBA
1657:0013:103c:1744	HP 42B 4Gbps dual port FC HBA
1657:0017:1657:0014	415 4Gbps single port FC HBA
1657:0017:1657:0014	815 8Gbps single port FC HBA
1657:0017:103c:1741	HP 41B 4Gbps single port FC HBA
1657:0017:103c:1743	HP 81B 8Gbps single port FC HBA
1657:0021:103c:1779	804 8Gbps FC HBA for HP Bladesystem c-class
1657:0014:1657:0014	1010 10Gbps single port CNA - FCOE
1657:0014:1657:0014	1020 10Gbps dual port CNA - FCOE
1657:0014:1657:0014	1007 10Gbps dual port CNA - FCOE
1657:0014:1657:0014	1741 10Gbps dual port CNA - FCOE
1657:0022:1657:0024	1860 16Gbps FC HBA
1657:0022:1657:0022	1860 10Gbps CNA - FCOE

Firmware download

The latest Firmware package for 3.0.2.2 bfa driver can be found at:

<http://www.brocade.com/services-support/drivers-downloads/adapters/Linux.page>

and then click following respective util package link:

Version	Link
v3.0.0.0	Linux Adapter Firmware package for RHEL 6.2, SLES 11SP2

Configuration & Management utility download

The latest driver configuration & management utility for 3.0.2.2 bfa driver can be found at:

<http://www.brocade.com/services-support/drivers-downloads/adapters/Linux.page>

and then click following respective util package link

Version	Link
v3.0.2.0	Linux Adapter Firmware package for RHEL 6.2, SLES 11SP2

Documentation

The latest Administration's Guide, Installation and Reference Manual, Troubleshooting Guide, and Release Notes for the corresponding out-of-box driver can be found at:

<http://www.brocade.com/services-support/drivers-downloads/adapters/Linux.page>

and use the following inbox and out-of-box driver version mapping to find the corresponding documentation:

Inbox Version	Out-of-box Version
v3.0.2.2	v3.0.0.0

Support

For general product and support info, go to the Brocade website at:

<http://www.brocade.com/services-support/index.page>