

ioctl VIDIOC_S_HW_FREQ_SEEK

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v4l\linux-master) (Documentation) (userspace-api) (media) (v4l)vidioc-s-hw-freq-seek.rst, line 2)

Unknown directive type "c:namespace".

```
.. c:namespace:: V4L
```

Name

VIDIOC_S_HW_FREQ_SEEK - Perform a hardware frequency seek

Synopsis

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v4l\linux-master) (Documentation) (userspace-api) (media) (v4l)vidioc-s-hw-freq-seek.rst, line 18)

Unknown directive type "c:macro".

```
.. c:macro:: VIDIOC_S_HW_FREQ_SEEK
```

```
int ioctl(int fd, VIDIOC_S_HW_FREQ_SEEK, struct v4l2_hw_freq_seek *argp)
```

Arguments

fd

File descriptor returned by `c:func:open()`.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v4l\linux-master) (Documentation) (userspace-api) (media) (v4l)vidioc-s-hw-freq-seek.rst, line 26);
[backlink](#)

Unknown interpreted text role "c:func".

argp

Pointer to struct `c:type:v4l2_hw_freq_seek`.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v4l\linux-master) (Documentation) (userspace-api) (media) (v4l)vidioc-s-hw-freq-seek.rst, line 29);
[backlink](#)

Unknown interpreted text role "c:type".

Description

Start a hardware frequency seek from the current frequency. To do this applications initialize the `tuner`, `type`, `seek_upward`, `wrap_around`, `spacing`, `rangelow` and `rangehigh` fields, and zero out the `reserved` array of a struct `c:type:v4l2_hw_freq_seek` and call the `VIDIOC_S_HW_FREQ_SEEK` `ioctl` with a pointer to this structure.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v4l\linux-master) (Documentation) (userspace-api) (media) (v4l)vidioc-s-hw-freq-seek.rst, line 34); [backlink](#)

Unknown interpreted text role "c:type".

The `rangelow` and `rangehigh` fields can be set to a non-zero value to tell the driver to search a specific band. If the struct

`c:type:'v4l2_tuner'` capability field has the `V4L2_TUNER_CAP_HWSEEK_PROG_LIM` flag set, these values must fall within one of the bands returned by [ref: VIDIOC_ENUM_FREQ_BANDS](#). If the `V4L2_TUNER_CAP_HWSEEK_PROG_LIM` flag is not set, then these values must exactly match those of one of the bands returned by [ref: VIDIOC_ENUM_FREQ_BANDS](#). If the current frequency of the tuner does not fall within the selected band it will be clamped to fit in the band before the seek is started.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v4l\linux-master) (Documentation) (userspace-api) (media) (v4l) vidioc-s-hw-freq-seek.rst, line 41); [backlink](#)

Unknown interpreted text role "c:type".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v4l\linux-master) (Documentation) (userspace-api) (media) (v4l) vidioc-s-hw-freq-seek.rst, line 41); [backlink](#)

Unknown interpreted text role "ref".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v4l\linux-master) (Documentation) (userspace-api) (media) (v4l) vidioc-s-hw-freq-seek.rst, line 41); [backlink](#)

Unknown interpreted text role "ref".

If an error is returned, then the original frequency will be restored.

This ioctl is supported if the `V4L2_CAP_HW_FREQ_SEEK` capability is set.

If this ioctl is called from a non-blocking filehandle, then `EAGAIN` error code is returned and no seek takes place.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v4l\linux-master) (Documentation) (userspace-api) (media) (v4l) vidioc-s-hw-freq-seek.rst, line 61)

Unknown directive type "tabularcolumns".

```
.. tabularcolumns:: |p{4.4cm}|p{4.4cm}|p{8.5cm}|
```

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v4l\linux-master) (Documentation) (userspace-api) (media) (v4l) vidioc-s-hw-freq-seek.rst, line 63)

Unknown directive type "c:type".

```
.. c:type:: v4l2_hw_freq_seek
```

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v4l\linux-master) (Documentation) (userspace-api) (media) (v4l) vidioc-s-hw-freq-seek.rst, line 65)

Unknown directive type "flat-table".

```
.. flat-table:: struct v4l2_hw_freq_seek
   :header-rows: 0
   :stub-columns: 0
   :widths:      1 1 2

   * - __u32
     - __tuner
     - The tuner index number. This is the same value as in the struct
       c:type:'v4l2_input' __tuner field and the struct
       c:type:'v4l2_tuner' __index field.
   * - __u32
     - __type
     - The tuner type. This is the same value as in the struct
       c:type:'v4l2_tuner' __type field. See
       c:type:'v4l2_tuner_type'
   * - __u32
     - __seek_upward
     - If non-zero, seek upward from the current frequency, else seek
       downward.
```

- * - `__u32`
 - `wrap_around`
 - If non-zero, wrap around when at the end of the frequency range, else stop seeking. The struct `:c:type:'v4l2_tuner'` `capability` field will tell you what the hardware supports.
- * - `__u32`
 - `spacing`
 - If non-zero, defines the hardware seek resolution in Hz. The driver selects the nearest value that is supported by the device. If spacing is zero a reasonable default value is used.
- * - `__u32`
 - `rangelow`
 - If non-zero, the lowest tunable frequency of the band to search in units of 62.5 kHz, or if the struct `:c:type:'v4l2_tuner'` `capability` field has the `V4L2_TUNER_CAP_LOW` flag set, in units of 62.5 Hz or if the struct `:c:type:'v4l2_tuner'` `capability` field has the `V4L2_TUNER_CAP_1HZ` flag set, in units of 1 Hz. If `rangelow` is zero a reasonable default value is used.
- * - `__u32`
 - `rangehigh`
 - If non-zero, the highest tunable frequency of the band to search in units of 62.5 kHz, or if the struct `:c:type:'v4l2_tuner'` `capability` field has the `V4L2_TUNER_CAP_LOW` flag set, in units of 62.5 Hz or if the struct `:c:type:'v4l2_tuner'` `capability` field has the `V4L2_TUNER_CAP_1HZ` flag set, in units of 1 Hz. If `rangehigh` is zero a reasonable default value is used.
- * - `__u32`
 - `reserved` [5]
 - Reserved for future extensions. Applications must set the array to zero.

Return Value

On success 0 is returned, on error -1 and the `errno` variable is set appropriately. The generic error codes are described at the [ref:Generic Error Codes <gen-errors>](#) chapter.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v4l\linux-master) (Documentation) (userspace-api) (media) (v4l)vidioc-s-hw-freq-seek.rst, line 120); [backlink](#)

Unknown interpreted text role "ref".

EINVAL

The tuner index is out of bounds, the `wrap_around` value is not supported or one of the values in the `type`, `rangelow` or `rangehigh` fields is wrong.

EAGAIN

Attempted to call `VIDIOC_S_HW_FREQ_SEEK` with the filehandle in non-blocking mode.

ENODATA

The hardware seek found no channels.

EBUSY

Another hardware seek is already in progress.