

# AUDIO\_PLAY

**System Message: ERROR/3** (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\linux-master\drivers\staging\media\av7110\audio-play.rst, line 2)

Unknown directive type "c:namespace".

```
.. c:namespace:: DTV.audio
```

## Name

AUDIO\_PLAY

**Attention!**

This ioctl is deprecated

## Synopsis

**System Message: ERROR/3** (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\linux-master\drivers\staging\media\av7110\audio-play.rst, line 20)

Unknown directive type "c:macro".

```
.. c:macro:: AUDIO_PLAY
```

```
int ioctl(int fd, AUDIO_PLAY)
```

## Arguments

**System Message: ERROR/3** (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\linux-master\drivers\staging\media\av7110\audio-play.rst, line 27)

Unknown directive type "flat-table".

```
.. flat-table::
   :header-rows: 0
   :stub-columns: 0

   - .. row 1
     - int fd
     - File descriptor returned by a previous call to open().
```

## Description

This ioctl call asks the Audio Device to start playing an audio stream from the selected source.

## Return Value

On success 0 is returned, on error -1 and the `errno` variable is set appropriately. The generic error codes are described at the [ref`Generic Error Codes <gen-errors>`](#) chapter.

**System Message: ERROR/3** (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\linux-master\drivers\staging\media\av7110\audio-play.rst, line 46); [backlink](#)

Unknown interpreted text role "ref".