

USB Error codes

Revised: 2004-Oct-21

This is the documentation of (hopefully) all possible error codes (and their interpretation) that can be returned from usbcore.

Some of them are returned by the Host Controller Drivers (HCDs), which device drivers only see through usbcore. As a rule, all the HCDs should behave the same except for transfer speed dependent behaviors and the way certain faults are reported.

Error codes returned by `:c:func:`usb_submit_urb``

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\driver-api\usb\ (linux-master) (Documentation) (driver-api) (usb) error-codes.rst, line 17); [backlink](#)

Unknown interpreted text role "c:func".

Non-USB-specific:

0	URB submission went fine
-ENOMEM	no memory for allocation of internal structures

USB-specific:

-EBUSY	The URB is already active.
-ENODEV	specified USB-device or bus doesn't exist
-ENOENT	specified interface or endpoint does not exist or is not enabled
-ENXIO	host controller driver does not support queuing of this type of urb. (treat as a host controller bug.)
-EINVAL	<ul style="list-style-type: none">a. Invalid transfer type specified (or not supported)b. Invalid or unsupported periodic transfer intervalc. ISO: attempted to change transfer intervald. ISO: <code>number_of_packets</code> is < 0e. various other cases
-EXDEV	ISO: <code>URB_ISO_ASAP</code> wasn't specified and all the frames the URB would be scheduled in have already expired.
-EFBIG	Host controller driver can't schedule that many ISO frames.
-EPIPE	The pipe type specified in the URB doesn't match the endpoint's actual type.
-EMSGSIZE	<ul style="list-style-type: none">a. endpoint maxpacket size is zero; it is not usable in the current interface altsetting.b. ISO packet is larger than the endpoint maxpacket.c. requested data transfer length is invalid: negative or too large for the host controller.
-EBADR	The <code>wLength</code> value in a control URB's setup packet does not match the URB's <code>transfer_buffer_length</code> .
-ENOSPC	This request would overcommit the usb bandwidth reserved for periodic transfers (interrupt, isochronous).
-ESHUTDOWN	The device or host controller has been disabled due to some problem that could not be worked around.
-EPERM	Submission failed because <code>urb->reject</code> was set.
-EHOSTUNREACH	URB was rejected because the device is suspended.
-ENOEXEC	A control URB doesn't contain a Setup packet.

Error codes returned by `in urb->status` or `in iso_frame_desc[n].status` (for ISO)

USB device drivers may only test urb status values in completion handlers. This is because otherwise there would be a race between HCDs updating these values on one CPU, and device drivers testing them on another CPU.

A transfer's actual `_length` may be positive even when an error has been reported. That's because transfers often involve several packets, so that one or more packets could finish before an error stops further endpoint I/O.

For isochronous URBs, the urb status value is non-zero only if the URB is unlinked, the device is removed, the host controller is disabled, or the total transferred length is less than the requested length and the `URB_SHORT_NOT_OK` flag is set. Completion handlers for isochronous URBs should only see `urb->status` set to zero, `-ENOENT`, `-ECONNRESET`, `-ESHUTDOWN`, or `-EREMOTEIO`.

Individual frame descriptor status fields may report more status codes.

0	Transfer completed successfully
-ENOENT	<p>URB was synchronously unlinked by <code>:c:func:'usb_unlink_urb'</code></p> <div><p>System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\driver-api\usb\ (linux-master) (Documentation) (driver-api) (usb)error-codes.rst, line 104); backlink</p><p>Unknown interpreted text role "c:func".</p></div>
-EINPROGRESS	URB still pending, no results yet (That is, if drivers see this it's a bug.)
-EPROTO [1] , [2]	<ul style="list-style-type: none">a. bitstuff errorb. no response packet received within the prescribed bus turn-around timec. unknown USB error
-EILSEQ [1] , [2]	<ul style="list-style-type: none">a. CRC mismatchb. no response packet received within the prescribed bus turn-around timec. unknown USB error <p>Note that often the controller hardware does not distinguish among cases a), b), and c), so a driver cannot tell whether there was a protocol error, a failure to respond (often caused by device disconnect), or some other fault.</p>
-ETIME [2]	No response packet received within the prescribed bus turn-around time. This error may instead be reported as -EPROTO or -EILSEQ.
-ETIMEDOUT	Synchronous USB message functions use this code to indicate timeout expired before the transfer completed, and no other error was reported by HC.
-EPIPE [2]	<p>Endpoint stalled. For non-control endpoints, reset this status with <code>:c:func:'usb_clear_halt'</code>.</p> <div><p>System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\driver-api\usb\ (linux-master) (Documentation) (driver-api) (usb)error-codes.rst, line 137); backlink</p><p>Unknown interpreted text role "c:func".</p></div>
-ECOMM	During an IN transfer, the host controller received data from an endpoint faster than it could be written to system memory
-ENOSR	During an OUT transfer, the host controller could not retrieve data from system memory fast enough to keep up with the USB data rate
-EOVERFLOW [1]	The amount of data returned by the endpoint was greater than either the max packet size of the endpoint or the remaining buffer size. "Babble".
-EREMOTEIO	The data read from the endpoint did not fill the specified buffer, and URB_SHORT_NOT_OK was set in <code>urb->transfer_flags</code> .
-ENODEV	Device was removed. Often preceded by a burst of other errors, since the hub driver doesn't detect device removal events immediately.
-EXDEV	ISO transfer only partially completed (only set in <code>iso_frame_desc[n].status</code> , not <code>urb->status</code>)
-EINVAL	ISO madness, if this happens: Log off and go home
-ECONNRESET	<p>URB was asynchronously unlinked by <code>:c:func:'usb_unlink_urb'</code></p> <div><p>System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\driver-api\usb\ (linux-master) (Documentation) (driver-api) (usb)error-codes.rst, line 169); backlink</p><p>Unknown interpreted text role "c:func".</p></div>

-ESHUTDOWN	The device or host controller has been disabled due to some problem that could not be worked around, such as a physical disconnect.
------------	---

- [1] ([1,2,3](#)) Error codes like `-EPROTO`, `-EILSEQ` and `-EOVERFLOW` normally indicate hardware problems such as bad devices (including firmware) or cables.
- [2] ([1,2,3,4](#)) This is also one of several codes that different kinds of host controller use to indicate a transfer has failed because of device disconnect. In the interval before the hub driver starts disconnect processing, devices may receive such fault reports for every request.

Error codes returned by usbcore-functions

Note

expect also other submit and transfer status codes

`:c:func:'usb_register':`

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\driver-api\usb\ (linux-master) (Documentation) (driver-api) (usb) `error-codes.rst`, line 198); [backlink](#)

Unknown interpreted text role "c:func".

-EINVAL	error during registering new driver
---------	-------------------------------------

`usb_get_*/usb_set_*()`, `:c:func:'usb_control_msg'`, `:c:func:'usb_bulk_msg()'`:

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\driver-api\usb\ (linux-master) (Documentation) (driver-api) (usb) `error-codes.rst`, line 204); [backlink](#)

Unknown interpreted text role "c:func".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\driver-api\usb\ (linux-master) (Documentation) (driver-api) (usb) `error-codes.rst`, line 204); [backlink](#)

Unknown interpreted text role "c:func".

-ETIMEDOUT	Timeout expired before the transfer completed.
------------	--