

ioctl FE_SET_PROPERTY, FE_GET_PROPERTY

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\[linux-master] [Documentation] [userspace-api] [media] [dvb] fe-get-property.rst, line 2)

Unknown directive type "c:namespace".

```
.. c:namespace:: DTV.fe
```

Name

FE_SET_PROPERTY - FE_GET_PROPERTY - FE_SET_PROPERTY sets one or more frontend properties. -
FE_GET_PROPERTY returns one or more frontend properties.

Synopsis

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\[linux-master] [Documentation] [userspace-api] [media] [dvb] fe-get-property.rst, line 18)

Unknown directive type "c:macro".

```
.. c:macro:: FE_GET_PROPERTY
```

```
int ioctl(int fd, FE_GET_PROPERTY, struct dtv_properties *argp)
```

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\[linux-master] [Documentation] [userspace-api] [media] [dvb] fe-get-property.rst, line 22)

Unknown directive type "c:macro".

```
.. c:macro:: FE_SET_PROPERTY
```

```
int ioctl(int fd, FE_SET_PROPERTY, struct dtv_properties *argp)
```

Arguments

fd

File descriptor returned by `c:func:open()`.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\[linux-master] [Documentation] [userspace-api] [media] [dvb] fe-get-property.rst, line 30); [backlink](#)

Unknown interpreted text role "c:func".

argp

Pointer to struct `c:type:dtv_properties`.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\[linux-master] [Documentation] [userspace-api] [media] [dvb] fe-get-property.rst, line 33); [backlink](#)

Unknown interpreted text role "c:type".

Description

All Digital TV frontend devices support the FE_SET_PROPERTY and FE_GET_PROPERTY ioctls. The supported properties and statistics depends on the delivery system and on the device:

- `FE_SET_PROPERTY`:
 - This `ioctl` is used to set one or more frontend properties.
 - This is the basic command to request the frontend to tune into some frequency and to start decoding the digital TV signal.
 - This call requires read/write access to the device.

Note

At return, the values aren't updated to reflect the actual parameters used. If the actual parameters are needed, an explicit call to `FE_GET_PROPERTY` is needed.

- `FE_GET_PROPERTY`:
 - This `ioctl` is used to get properties and statistics from the frontend.
 - No properties are changed, and statistics aren't reset.
 - This call only requires read-only access to the device.

Return Value

On success 0 is returned.

On error -1 is returned, and the `errno` variable is set appropriately.

Generic error codes are described at the [ref`Generic Error Codes <gen-errors>`](#) chapter.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\dvb\[linux-master] [Documentation] [userspace-api] [media] [dvb] fe-get-property.rst, line 74); [backlink](#)

Unknown interpreted text role "ref".