

ioctl LIRC_SET_SEND_DUTY_CYCLE

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\rc\[linux-master] [Documentation] [userspace-api] [media] [rc]lirc-set-send-duty-cycle.rst, line 2)

Unknown directive type "c.namespace".

```
.. c:namespace:: RC
```

Name

LIRC_SET_SEND_DUTY_CYCLE - Set the duty cycle of the carrier signal for IR transmit.

Synopsis

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\rc\[linux-master] [Documentation] [userspace-api] [media] [rc]lirc-set-send-duty-cycle.rst, line 19)

Unknown directive type "c.macro".

```
.. c:macro:: LIRC_SET_SEND_DUTY_CYCLE
```

```
int ioctl(int fd, LIRC_SET_SEND_DUTY_CYCLE, __u32 *duty_cycle)
```

Arguments

fd

File descriptor returned by open().

duty_cycle

Duty cycle, describing the pulse width in percent (from 1 to 99) of the total cycle. Values 0 and 100 are reserved.

Description

Get/set the duty cycle of the carrier signal for IR transmit.

Currently, no special meaning is defined for 0 or 100, but this could be used to switch off carrier generation in the future, so these values should be reserved.

Return Value

On success 0 is returned, on error -1 and the `errno` variable is set appropriately. The generic error codes are described at the [ref: Generic Error Codes <gen-errors>](#) chapter.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\rc\[linux-master] [Documentation] [userspace-api] [media] [rc]lirc-set-send-duty-cycle.rst, line 45); [backlink](#)

Unknown interpreted text role "ref".