

# AUDIO\_CONTINUE

**System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\linux-master\drivers\staging\media\av7110)audio-continue.rst, line 2)**

Unknown directive type "c.namespace".

```
.. c:namespace:: DTV.audio
```

## Name

AUDIO\_CONTINUE

**Attention!**

This ioctl is deprecated

## Synopsis

**System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\linux-master\drivers\staging\media\av7110)audio-continue.rst, line 20)**

Unknown directive type "c.macro".

```
.. c:macro:: AUDIO_CONTINUE
```

```
int ioctl(int fd, AUDIO_CONTINUE)
```

## Arguments

**System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\linux-master\drivers\staging\media\av7110)audio-continue.rst, line 27)**

Unknown directive type "flat-table".

```
.. flat-table::
   :header-rows: 0
   :stub-columns: 0

   - .. row 1
     - int fd
     - File descriptor returned by a previous call to open().
```

## Description

This ioctl restarts the decoding and playing process previously paused with AUDIO\_PAUSE command.

## Return Value

On success 0 is returned, on error -1 and the `errno` variable is set appropriately. The generic error codes are described at the [ref`Generic Error Codes <gen-errors>` chapter](#).

**System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\linux-master\drivers\staging\media\av7110)audio-continue.rst, line 46); [backlink](#)**

Unknown interpreted text role "ref".