

# V4L2\_SDR\_FMT\_RU12LE ('RU12')

Real unsigned 12-bit little endian sample

## Description

This format contains sequence of real number samples. Each sample is represented as a 12 bit unsigned little endian number. Sample is stored in 16 bit space with unused high bits padded with 0.

**Byte Order.** Each cell is one byte.

**System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v4l\linux-master) (Documentation) (userspace-api) (media) (v4l)pixfmt-sdr-ru12le.rst, line 26)**

Unknown directive type "flat-table".

```
.. flat-table::
   :header-rows: 0
   :stub-columns: 0

   * - start + 0:
     - I'\ :sub:`0[7:0]`
     - I'\ :sub:`0[11:8]`
```