

UUT Report

Station ID:

Serial Number:

Date:

Time:

Operator:

Execution Time:

Number of Results:

UUT Result:

Product:

Product type:

Comm type:

Product FW Version:

Comm FW Version:

IT-W-7303101

NONE

lunedì 6 novembre 2023

14:26:18

administrator

553.996849 seconds

331

Passed

ARI LV

NO COMM

NO COMM

NO COMM

NO COMM

Begin Sequence: MainSequence
(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD_Shared\TestStand\Sequences\MOD\General_test.seq)

Simultaneous trip_open	
Status:	Skipped
General and Architecture and LED	
Status:	Passed
Module Time:	540.034869

Begin Sequence: General and Architecture and LED
(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD_Shared\TestStand\Sequences\MOD\General_test.seq)

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power off and the LED is OFF.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT-Active state.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT-Active state.
Status:	Passed
Additional Results	

Status:	Done
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that when the ARI is power ON an auto-reclosing command is executed.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" after autoreclose.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED was "Blinking Red" during the stand-by state and now is "Fix Red" in Lock State.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Locked state.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Red".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Locked state.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that ARI reach Lock state after 3 trip due to the NO-reset of reclosing attempts during the power fail before the autoreclosing.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that ARI reach Lock state after 4 trip due to the reset of reclosing attempts during the power fail.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that ARI reach Lock state after 3 trip.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that ARI reach Lock state after 3 trip.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that ARI reach Lock state after the default number of reclosing attempts.
Status:	Passed

End Sequence: General and Architecture and LED

Input-Output	
Status:	Skipped
Power Outage	

Status:	Skipped
Motor Driver	
Status:	Skipped

End Sequence: MainSequence

End UUT Report

