

UUT Report

Station ID:

Serial Number:

Date:

Time:

Operator:

Execution Time:

Number of Results:

UUT Result:

Product:

Product type:

Comm type:

Product FW Version:

Comm FW Version:

IT-W-7303101

NONE

lunedì 23 ottobre 2023

10:25:37

administrator

985.3013783 seconds

411

Terminated

MOD HV

MOD HV

COMM1\_RS485

56010804

56010000

Begin Sequence: MainSequence  
(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD\_Shared\TestStand\Sequences\MOD\General\_test.seq)

Simultaneous trip_open	
Status:	Skipped
General and Architecture and LED	
Status:	Skipped
Input-Output	
Status:	Skipped
Power Outage	
Status:	Skipped
Motor Driver	
Status:	Skipped

Modbus Register check	
Status:	Terminated
Module Time:	967.7561772

Begin Sequence: Modbus Register check  
(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD\_Shared\TestStand\Sequences\MOD\General\_test.seq)

Internal communication failure	
Status:	Done
Register Value:	OK
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via modbus worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus worked.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus has not worked during dead time.

Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus worked.
Status:	Passed
input	
Status:	Done
Register Value:	Disable
Pass/Fail Test	
Status:	Passed
Communication	
Status:	Done
Register Value:	Disable
Pass/Fail Test	
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via input has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via input has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus has not worked.
Status:	Passed
input	
Status:	Done
Register Value:	Disable
Pass/Fail Test	
Status:	Passed
Communication	
Status:	Done
Register Value:	Disable
Pass/Fail Test	
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via input has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via modbus has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via input has not worked.

Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via modbus has not worked.
Status:	Passed
input	
Status:	Done
Register Value:	Enable
Pass/Fail Test	
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via input worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via modbus has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via input worked.
Status:	Passed
Communication	
Status:	Done
Register Value:	Enable
Pass/Fail Test	
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing and opening via input worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing and opening via modbus worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via input has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via input has not worked.
Status:	Passed
Additional Results	
Status:	Done

PopupString:	Check that the remote opening via modbus worked.
Status:	Passed
Status Breaker	
Status:	Done
Register Value:	Open
Test Status Breaker	
Status:	Passed
Status Breaker	
Status:	Done
Register Value:	Open
Test Status Breaker	
Status:	Passed
Status Breaker	
Status:	Done
Register Value:	Close
Test Status Breaker	
Status:	Passed
Status Breaker	
Status:	Done
Register Value:	Close
Test Status Breaker	
Status:	Passed

Status Breaker	
Status:	Done
Register Value:	Open
Test Status Breaker	
Status:	Passed
Status Breaker	
Status:	Done
Register Value:	Open
Test Status Breaker	
Status:	Passed


Tripped	
Status:	Done
Register Value:	No Trip
Test Tripped	
Status:	Passed


Tripped	
Status:	Done
Register Value:	Trip
Test Tripped	
Status:	Passed
Tripped	
Status:	Done
Register Value:	Trip
Test Tripped	
Status:	Passed

Tripped	
---------	--


Status:	Done
Register Value:	No Trip
Test Tripped	
Status:	Passed

TIME Tripped	
Status:	Done
Time Tripped before:	000101000000
TIME Tripped	
Status:	Done
Time Tripped after:	000101000009
Time tripped check	
Status:	Passed







Peak torque  
toggle angle  
in  
degree[0..9]:



Closing time  
in ms[0..9]:



Opening time  
in ms[0..9]:



End Sequence: Modbus Register check

End Sequence: MainSequence

End UUT Report

