

UUT Report

Station ID:

Serial Number:

Date:

Time:

Operator:

Execution Time:

Number of Results:

UUT Result:

IT-W-7303101

NONE

venerdì 14 aprile 2023

11:15:08

ITLAVIT1

00:08:06.000

188

Terminated

Begin Sequence: MainSequence  
(C:\Users\itlavit1\OneDrive - ABB\LabRnD\_Shared\TestStand\Sequences\MOD\Complete\_test.seq)

|                                  |             |
|----------------------------------|-------------|
| UUT Parameters                   |             |
| Status:                          | Done        |
| TestResults/Data:                |             |
| Product Name:                    | ARI LV      |
| Communication Module:            | RS485       |
| UUT_info_comm                    |             |
| Status:                          | Done        |
| TestResults/Data:                |             |
| Product type:                    | ARI HV      |
| COMM type:                       | COMM1_RS485 |
| Product Firmware version:        | "           |
| COMM Firmware version:           | "           |
| General and Architecture and LED |             |
| Status:                          | Terminated  |
| Module Time:                     | 483.6       |

Begin Sequence: General and Architecture and LED  
(C:\Users\itlavit1\OneDrive - ABB\LabRnD\_Shared\TestStand\Sequences\MOD\Complete\_test.seq)

|                    |  |
|--------------------|--|
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that manual opening and closing of the device shall be possible when the device is power off and the LED is OFF.     |
| Status:            | Passed   |
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT-Active state. |
| Status:            | Passed   |
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that the LED is "Blinking Green" in both active and close configurations.  |
| Status:            | Passed   |
| Additional Results |  |
|                    |  |

|                    |  |
|--------------------|--|
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that the LED is "Blinking Green".  |
| Status:            | Passed   |
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT-Active state. |
| Status:            | Passed   |
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that the LED is "Blinking Green" in both active and close configurations.  |
| Status:            | Passed   |
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that the LED is "Blinking Green".  |
| Status:            | Passed   |
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that the LED is "Blinking Green" in both active and close configurations.  |
| Status:            | Passed   |
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.     |
| Status:            | Passed   |

|                    |  |
|--------------------|--|
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration. |
| Status:            | Passed   |
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that the LED is "Blinking Green".  |
| Status:            | Passed   |

|                    |  |
|--------------------|--|
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state. |
| Status:            | Passed   |

|                    |  |
|--------------------|--|
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration. |

|         |        |
|---------|--------|
| Status: | Passed |
|---------|--------|

|                    |  |
|--------------------|--|
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that the LED is "Fix Green".   |
| Status:            | Passed   |
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state. |
| Status:            | Passed   |

|                    |  |
|--------------------|--|
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.     |
| Status:            | Passed   |
| Check Close        |  |
| Status:            | Failed   |
| Check Close        |  |
| Status:            | Failed   |
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that when the ARI is power ON an auto-reclosing command is executed.   |
| Status:            | Failed   |
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that the LED is "Fix Green" after autoreclose.   |
| Status:            | Passed   |
| Check LED Status   |  |
| Status:            | Failed   |
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that the LED was "Blinking Red" during the stand-by state and now is "Fix Red" in Lock State.                    |
| Status:            | Passed   |
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that manual opening and closing of the device shall be possible when the device is power ON and in Locked state. |
| Status:            | Passed   |
| Additional Results |  |
| Status:            | Done   |
| TestResults/Data:  |  |
| PopupString:       | Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.     |
| Status:            | Passed   |
| Check LED Status   |  |
| Status:            | Failed   |

End Sequence: General and Architecture and LED

End Sequence: MainSequence

End UUT Report

