

UUT Report

Station ID:

Serial Number:

Date:

Time:

Operator:

Execution Time:

Number of Results:

UUT Result:

Product:

Product type:

Comm type:

Product FW Version:

Comm FW Version:

IT-W-7303101

NONE

martedì 24 ottobre 2023

10:46:07

administrator

265.3374229 seconds

91

Terminated

ARI LV

ARI HV

COMM1_RS485

56010804

56010000

Begin Sequence: MainSequence
(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD_Shared\TestStand\Sequences\MOD\General_test.seq)

Simultaneous trip_open	
Status:	Skipped
General and Architecture and LED	
Status:	Terminated
Module Time:	261.1423146

Begin Sequence: General and Architecture and LED
(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD_Shared\TestStand\Sequences\MOD\General_test.seq)

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power off and the LED is OFF.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT-Active state.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT-Active state.
Status:	Passed
Additional Results	
Status:	Done

PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.
Status:	Passed
Check Close	
Status:	Failed
Additional Results	
Status:	Done
PopupString:	Check that when the ARI is power ON an auto-reclosing command is executed.
Status:	Failed

Check LED Status	
Status:	Failed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" after autoreclose.
Status:	Failed

End Sequence: General and Architecture and LED

End Sequence: MainSequence

End UUT Report

