

UUT Report

Station ID:

Serial Number:

Date:

Time:

Operator:

Execution Time:

Number of Results:

UUT Result:

Product:

Product type:

Comm type:

Product FW Version:

Comm FW Version:

IT-W-7303101

NONE

martedì 10 ottobre 2023

16:02:01

administrator

510.9368899 seconds

323

Passed

ARI LV

ARI LV

COMM1\_RS485

56010804

56010000

Begin Sequence: MainSequence  
(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD\_Shared\TestStand\Sequences\MOD\General\_test.seq)

General and Architecture and LED	
Status:	Passed
Module Time:	463.9869634

Begin Sequence: General and Architecture and LED  
(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD\_Shared\TestStand\Sequences\MOD\General\_test.seq)

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power off and the LED is OFF.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT-Active state.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT-Active state.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that when the ARI is power ON an auto-reclosing command is executed.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" after autoreclose.

Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED was "Blinking Red" during the stand-by state and now is "Fix Red" in Lock State.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Locked state.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Red".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Locked state.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that ARI reach Lock state after 3 trip due to the NO-reset of reclosing attempts during the power fail before the autoreclosing.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that ARI reach Lock state after 4 trip due to the reset of reclosing attempts during the power fail.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that ARI reach Lock state after 3 trip.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that ARI reach Lock state after 3 trip.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that ARI reach Lock state after the default number of reclosing attempts.
Status:	Passed

End Sequence: General and Architecture and LED

Input-Output	
Status:	Skipped
Power Outage	
Status:	Skipped
Motor Driver	
Status:	Skipped

Modbus Register check	
Status:	Skipped
Modbus settings check	
Status:	Skipped
COMM LED & Button	
Status:	Skipped
Firmware Upgrade	
Status:	Skipped

End Sequence: MainSequence

End UUT Report

