

UUT Report

Station ID:

Serial Number:

Date:

Time:

Operator:

Execution Time:

Number of Results:

UUT Result:

Product:

Product type:

Comm type:

Product FW Version:

Comm FW Version:

IT-W-7303101

NONE

mercoledì 21 giugno 2023

09:55:57

administrator

524.0763609 seconds

279

Terminated

ARI LV

ARI LV

COMM1\_RS485

56010707

42030100

Begin Sequence: MainSequence  
(C:\Users\itlavit1\OneDrive - ABB\LabRnD\_Shared\TestStand\Sequences\MOD\General\_test.seq)

General and Architecture and LED	
Status:	Passed
Module Time:	437.6919411

Begin Sequence: General and Architecture and LED  
(C:\Users\itlavit1\OneDrive - ABB\LabRnD\_Shared\TestStand\Sequences\MOD\General\_test.seq)

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power off and the LED is OFF.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT-Active state.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT-Active state.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that when the ARI is power ON an auto-reclosing command is executed.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" after autoreclose.

Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED was "Blinking Red" during the stand-by state and now is "Fix Red" in Lock State.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Locked state.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Green" in close active configuration and "Blinking green" in open active configuration.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the LED is "Fix Red".
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Locked state.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that ARI reach Lock state after 3 trip due to the NO-reset of reclosing attempts during the power fail before the autoreclosing.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that ARI reach Lock state after 4 trip due to the reset of reclosing attempts during the power fail.
Status:	Passed

End Sequence: General and Architecture and LED

Input-Output	
Status:	Terminated
Module Time:	81.520446

Begin Sequence: I/O  
(C:\Users\itlavit1\OneDrive - ABB\LabRnD\_Shared\TestStand\Sequences\MOD\General\_test.seq)

Additional Results	
Status:	Done
PopupString:	Check that remote closing hasn't appened.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that remote closing hasn't appened.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that remote opening hasn't appened.

Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that remote opening hasn't appened.
Status:	Passed
Check Outputs	
Status:	Failed
Configuration:	MOD in Active State and MPD OPEN
Output 1:	True
Output 2:	False
Additional Results	
Status:	Done
PopupString:	Check that remote opening worked.
Status:	Passed
Check Outputs	
Status:	Failed
Configuration:	MOD in Active State and MPD OPEN
Output 1:	False
Output 2:	False
Check Outputs	
Status:	Failed
Configuration:	MOD in Active State and MPD OPEN
Output 1:	False
Output 2:	False
Check Outputs	
Status:	Failed
Configuration:	MOD in Active State and MPD HALF OPEN
Output 1:	True
Output 2:	False

End Sequence: I/O

End Sequence: MainSequence

End UUT Report

