

Operating instructions Automatic Delivery BA700

Model 102-13 / -13A / -13B / -14

as of September 2004



palamides GmbH
Benzstraße 14 – 71272 Renningen
Tel: +49 (0) 7159 / 92570-0 – Fax +49 (0) 7159 / 92570-99
www.palamides.de

englisch

Contents

| | | |
|----|--|----|
| 1 | Description of the machine parts and groups..... | 7 |
| 2 | Fundamental Safety Advice | 10 |
| 3 | How to run the machine | 12 |
| 4 | Sensor Technology | 25 |
| 5 | Pneumatics..... | 38 |
| 6 | Electrical control panel BA700 | 44 |
| 7 | Setting the exits manually | 45 |
| 8 | Programming of frequency converter | 46 |
| 9 | Programming of frequency converter 1 | 47 |
| 10 | Belts | 48 |
| 11 | Inputs..... | 49 |
| 12 | Outputs..... | 50 |
| 13 | Code list TC166..... | 51 |
| 14 | Code list TC161..... | 54 |
| 15 | Error list TC166 | 58 |
| 16 | Error list TC161 | 63 |

Declaration of Conformity

Manufacturer Declaration
according to EC-Machinery Directive 98/37/EG, Annex II A

We

palamides GmbH
Benzstr. 14
D-71272 Renningen/Germany

hereby declare that because of their design and construction, the machinery/devices detailed below comply with the Health and Safety legislation of the EC-Machinery Directive. This Declaration becomes invalid if an alteration is made which has not been agreed with ourselves.

Product: Automatic Delivery BA700

Model: 102-13, 102-13A, 102-13B, 102-14

Serial number: _____

Appropriate EC-Directives:

EC-Machinery Directive (98/37/EG)

To comply the basic requirements we consulted the following appropriate standards:

EN 292-1; EN 292-2; EN 294
pr EN 1010 EN 60204-1

Date: 04.01.2004

Signature: (S. Palamides)

Identification
Of the Signatory: Managing Director

Preface



You have acquired a technically superior industrial product in the BA700 Delivery and, by paying careful attention to the Operating Instructions, you will achieve the highest levels of reliability and performance.

These Operating Instructions should guide you in operating the automatic delivery correctly, in complying with the safety regulations and in servicing the machine properly

PLEASE NOTE:

We strongly urge using “Certified palamides” Banding Materials. Use of this material will ensure reliability and consistency in production with your palamides Automatic Delivery. If any adjustments are made to this equipment to accommodate material other than the recommended palamides Banding Material, it may result in voiding the warranty.

1 Description of the machine parts and groups






Elevation
table

Batch level compensator

Jogging plates




Adjusting frame



Tensioning shaft

Tape turn element



Stopper

Support finger

Pressure axle

2 Fundamental Safety Advice

2.1 Warning advice and symbols

Throughout the operating instructions, the following designations, or rather signs are used for especially important statements:

>TIP<

Special statements with regard to the economic application of the machine

>ATTENTION!<



Special statements, or rather commands and prohibitions, to prevent damage.

>Danger<



Statements, or rather commands and prohibitions, to prevent injury to persons or extensive damage to property

2.2 Safety at work Agreed application of the Automatic Delivery

1. At the time of supply, palamides Automatic Deliveries meet all safety-related regulations. For this purpose, moving and rotating parts are covered with safety hoods, which are mechanically, or rather, electrically locked in such a way that no unreasonable interference with the operation exists.
2. It is extremely important with all safety related measures that the operating personnel practice high safety levels and have remaining sources of danger pointed out to them and/or impairment of the machine and other material assets cannot be excluded.
3. The machine may be operated only when in perfect technical condition. Faults which may impair safety are to be removed immediately by trained personnel or personnel from the manufacturer and/or supplier.
4. The machine is only intended for banding folded paper. Banding of other materials goes against agreement. The manufacturer and/or supplier is not responsible for any damage resulting from this.
5. Before you operate the machine, read carefully through all the operating instructions, including the safety and service conditions.
6. The operating instructions must always be handy near the machine.
7. If necessary, supplement the operating instructions with internal safety regulations, as well as with legal accident prevention regulations.
8. If machine personnel changes frequently, make sure that all machine operators are informed, or rather, trained in the previously mentioned points.
9. Never remove the protective, or rather safety devices on the machine and never alter the machine so that safety can no longer be guaranteed.



10. Only use tools which are in perfect condition and take care that no tools are left lying on the machine after adjustment or maintenance work. Tools which may fall into the machine can lead to serious consequences for both man and machine.

11. Pay attention to all safety and danger tips on the machine and keep these tips in a legible / visible condition.

12. Report all audible / visible safety-related machine changes to the appropriate authority in your works.

13. Operating personnel must have long hair tied back and may not wear loose clothing or jewellery, including rings. There is a danger of injury should they get caught up or drawn in.

14. When the machine is running, never try to clean it (rollers, belts), or to rectify faults or set it up.



15. Make sure that no other person switches the machine on while you are busy on it - e.g. whilst setting up or during other work! **>Danger<** Therefore, always press the **EMERGENCY-OFF Button**

16. Do not immediately switch the machine back on if it stops for some unknown reason. Make sure first that the machine is in perfect condition and that no other person is busy on the machine.

17. If you have to carry out extensive mechanical / electrical maintenance or repair work to the machine, turn off the main switch and, if necessary, secure it with a padlock.



18. Never open the main control cabinet or lower service cabinet! Electric, or rather, electronic work may only be carried out by relevant authorised personnel or by the manufacturer's or supplier's personnel. **>MORTAL DANGER<** with the control cabinet OPEN! With the control cabinet opened, even with the main switch **turned off**, there is still electrical current on the main terminal clamps!!!

19. Report any exposed cables or electrical connections to the appropriate authority in your works.



20. According to the latest safety regulations, the machine must stop if one of the safety hoods is opened. The hoods, which serve both as safety and noise dampening hoods, contain electrical switches. These switches may never be dismantled or bridged, as this would mean **>DANGER<** to the life and limb of the operator.




21. **>DANGER<** In order to stop the hoods from closing themselves, it is necessary to ensure that the hoods are completely opened as far as they will go.

3 How to run the machine


3.1 Main control panel

The main control panel is divided into four groups. These four groups can be seen on the picture opposite.




- | | |
|-----------|--|
| Group I | Electrical buttons to switch on and operate the machine. |
| Group II | Electronic keys to set up the machine |
| Group III | Electronic keys to operate the machine manually. |
| Group IV | Display and indicator elements to display messages. |

Group I




- | | |
|--------------------------|--|
| (1) Main switch | <p>This switches the power supply to the BA700 on and off. N.B. Certain areas in the control panel remain under current even when the main switch is switched off. N.B. Unplug the power supply plug only when the main switch is switched off. There is a danger to electronic component parts.</p> |
| (2) Emergency-Off-Button | <p>This is used during dangerous situations for switching the equipment off quickly. When it is pressed, the switch is locked and the machine can only be started again after the switch is pulled out (by turning it clockwise). Note: None of the data is erased when the Emergency-Off button is pressed. This means that, after a new start, work continues from the same position where it stopped before the Emergency-Off button was activated.</p> |

- | | | |
|-----|---------------------|--|
| (3) | Stop button | <p>Switches off the machine</p> <p>Erases errors. When a fault has been removed mechanically, the error message will still be shown on the display. After the Stop button has been pressed, this message will be erased.</p> <p>Note: None of the data is erased when the Stop button is pressed. This means that, after a new start, work continues from the same position where it stopped before the Stop button was activated.</p> |
| (4) | Start button | <p>Starts the machine</p> <p>Note: After pressing the start button, the equipment still needs a few seconds before it is operational. During this time, any products coming along will be ejected via the waste sheet deflector.</p> |
| (5) | Sheet input button | <p>This button only has a function if the BA700 has been connected either to an MBO folding machine using a standard (24-pole) plug, or to a Stahl folding machine using a Stahl interface.</p> <p>Connection with MBO: By pressing the sheet-input button once, the sheet supply on the folding machine's feeder is switched on. By pressing the sheet-input button again the sheet supply is switched off.</p> <p>Connection with Stahl: By pressing the sheet-input button, the sheet supply on the folding machine's feeder is switched on. Pressing the sheet input button again has no effect.</p> |
| (6) | Single sheet button | <p>This button only has a function if the BA700 has been connected either to an MBO folding machine using a standard (24 pole) plug, or to a Stahl folding machine using a Stahl interface.</p> <p>Connection with MBO: By pressing the single sheet button, one single sheet will be delivered by the folding machine's feeder.</p> <p>Connection with Stahl: By pressing the single sheet button, the sheet supply from the folding machine's feeder is switched off. Pressing the sheet input button again has no effect.</p> |
| (7) | Potentiometer 1 | <p>The speed of the transport belts, which lead from the press station to the shaft, can be altered by using the potentiometer's regulator.</p> |
| (8) | Potentiometer 2 | <p>The speed of the round belts, which lead to the press station, can be altered by using the potentiometer's regulator. The speed is shown in metres per minute on the upper right-hand side of the display.</p> |

Group II

- | | |
|----------------------|---|
| (1) Batch counter | When this key is pressed, the display shows the standard reading. The top row shows the results per hour and the speed of the press drive. The lower row shows the actual amount of products located in the shaft. By pressing again, the lower row shows the pre-set batch count. The pre-set batch count can also be altered in this mode. Note: products considered to be waste, which were ejected via the deflector, are not included. |
| (2) Total counter | When this key is pressed, the lower row of the display shows the amount of products which have been moved into the shaft. The total count can be deleted in this mode. Note: products considered to be waste, which were ejected via the deflector, are not included. |
| (3) Code | When this key is pressed and the relevant code entered, the machine parameters can be accessed. |
| (4) Setting Sheet | By pressing this key, the next sheet which comes along will be studied by the photocell near the round belts. All sheets coming along after this one will be compared to it and, if necessary, rejected. |
| (5) Stream delivery: | By pressing this key, the machine is put into "stream delivery" operating mode. Note: This can be seen at the wide transport belts, which only run when sheets are delivered to them. |
| (6) Single sheet | By pressing this key, the machine is put into "single sheet" operating mode. Note: This can be seen at the wide transport belts, which run permanently. |
| (7) Arrow upwards: | Important machine parameters may be accessed directly using this key. |
| (8) Arrow downwards: | Important machine parameters may be accessed directly using this key. |
| (9) Enter Key | Pressing this key will store newly entered values. |
| (10) Delete Key | Pressing this key will delete values called up. |

Group III

- | | |
|-------------------------------|---|
| (1) Starting position | <p>By pressing the starting position key, all movements since last pressing the start button will return to their original positions. Note: The “actual amount” on the batch counter will also be reset at Zero. Please ensure that the shafts are free. The pre-set batch amount stays the same. Note: This key only reacts if the unit is at a standstill.</p> |
| (2) Running out | <p>By pressing the pack remainder key, a packing cycle will start and the unit will be emptied. Note: This key only reacts if the unit is at a standstill.</p> |
| (3) Manual welding | <p>The manual welding key is used to connect the two loose ends of the band after the band has been exchanged or after a malfunction. Pressing the manual-welding key starts the following processes.</p> <ol style="list-style-type: none"> 1. The elevation table moves to its lowest position. 2. The pressing rails and the welding die move into the shaft. 3. The welding process starts up. 4. The pressing rails and the welding die move again to their starting positions. <p>Note: Ensure that there is sufficient band between the welding dies before manual welding. Note: This key only reacts if the unit is at a standstill</p> |
| (4) Elevation table downwards | <p>The elevation table downwards key is used to bring the elevation table down to its lowest position so that jammed product causing an error can be released. Note: Ensure that the area under the elevation table is clear. Note: This key only reacts if the unit is at a standstill.</p> |
| (5) Inspection | <p>When the inspection key is pressed, the next oncoming sheet will be ejected.</p> |
| (6) F1 | <p>Free</p> |
| (7) F2 | <p>When the F2 key is pressed, the actual test reading for monitoring of the format is shown on the display.</p> |
| (8) Side loader | <p>When the side loader key is pressed, the unit is filled with compressed air. When the side loader key is pressed again, the loader moves to the opposite position. When the side loader key is pressed yet again, the side loader moves back to</p> |

its starting position.

Note: This key only reacts if the unit is at a standstill

(9) Package lift table

When the package lift table key is pressed, the unit is filled with compressed air. When the package lift table key is pressed again, the loader moves to the opposite position. When the package lift table key is pressed yet again, the package lift table moves back to its starting position.

Note: This key only reacts if the unit is at a standstill.

(10) Ejector

When the ejector key is pressed, the unit is filled with compressed air. When the ejector key is pressed again, the ejector moves to the opposite position. When the ejector key is pressed yet again, the ejector moves back to its starting position.


Note: This key only reacts if the unit is at a standstill.

Group IV

Depending on its status, the display shows various types of information.

In normal operating mode the following is shown:


- | | | |
|-----|---------|---|
| (1) | Display | Gross performance in sheets per hour. |
| (2) | Display | Batch counter |
| (3) | Display | Speed of the round belts in metres per minute |



An error is shown:


(1) Display

Error No.




3.2 Infeed and press

The BA700 has to be aligned with the folding machine so that the streams of leaflets are accepted evenly in the relevant shafts (see 2.1). The height of the banding machine's delivery unit is to be adjusted to the exact height of the folding machine. Compare with 2.2 - 2.4.



- 2.1 General view.
- 2.2 **Wrong**, delivery too high.
- 2.3 **Wrong**, delivery too low.
- 2.4 **Correct**, leaflet hits the round belt opening exactly.




Now adjust the machine using pressing screw. The round belts are now set up so that the leaflets are guided at a slant to the required shaft. This is a rough pre-adjustment. By pressing key "Setting Sheet" and feeding in a sheet, the leaflet, which is to be processed, is checked. This is necessary so that the register sheet is not ejected. The pressing station is now adjusted to the product thickness with the help of setting screws. The infeed is now set up, using round belts, so that the leaflets are fed into the middle of the shafts. With some formats, it can happen, that the sheets are fed in off centre. This does not lead to a restriction in the ability of the machine to function. Using potentiometer the infeed speed is now adjusted so that the distance between each leaflet is not less than 150 mm. Ideally, the speed is $\pm 10\%$ of the pre-folding unit.


3.3 Layering and shaft infeed

The slope and length of the layering device can be adjusted to the product which is to be processed. It is set up to the product size by adjusting shaft 3.1.1 on handwheel 3.1.2. It is loosened or fixed using knurled screw 3.1.3. The slope is adjusted using the switching handle 3.1.3.

The guide rails 3.2.1 have a very important function. They ensure stabilisation in the direction of feed by bending the sheets; this is significant when stacking up. They are loosened by knurled screws 3.2.2 and adjusted to the relevant format (see 3.2a). The speed is now set up using potentiometer so that the leaflets form a clean unbroken layered stream. Take care here that the infeed runs continuously.

For single sheet infeed, the distance between the leaflets must be at least 100 mm.





3.4 Shaft

Upon loosening clamping lever 4.1, the shaft's width is adjusted with handwheel 4.2. Upon loosening clamping lever 4.3, the shaft walls 4.4 are now adjusted to the format. Ensure that this is carried out at the narrowest position. For this, turn the vibration plate gear with a No. 6 socket head cap screw key (see 4.5).


4.1

4.3

4.4




4.2




3.5 Quick Check

10 Questions which should be posed after adjustment has been carried out.


3.5.1 Does the height of the delivery go together with the folding machine?




3.5.2 Will the leaflets be transported in an evenly diagonal manner?




- 3.5.3 Do the round belts run parallel to each other and are they aligned correctly to the leaflet?




- 3.5.4 Is the difference in speed between the folding machine and the banding machine more than 10%?
- 3.5.5 Are the photocells in the counter free?
- 3.5.6 Is the pressing station adjusted to the product thickness?



- 3.5.7 Do the flat belts transport the stream continuously, without rafting?
- 3.5.8 Is the stream fed in at the mid position?



3.5.9 Were the guide rails in front of the shaft adjusted?




3.5.10 Do the leaflets have some play in the shafts?

4 Sensor Technology

4.1 Sensors used and their functions


| Article-No. | Name | Description | Picture |
|-------------|--|---|---|
| 61.00002 | Reflex photocell MLV40 B8, B9, B11, B12, B18, B19 | Reflex photocell with a sensing range from 10-40mm |  |
| 61.00001 | Proximity switch GT3.51 B4, B7 | Inductive switch for slot discs |  |
| 63.00117 | Inductive switch Omron 4mm B14, B15, B20, B21, B5 | Inductive switch Reacts to the approach of metal Switching distance 0,1 – 1,0mm |  |
| 61.00010 | Proximity switch SME-1-S-LED-24B B1, B2 | Cylinder switch for FESTO round cylinder 32dia |  |
| 61.00011 | Proximity switch SMEO-4U-S-LED-24 B B3, B16, B17 | Cylinder switch for FESTO round cylinder 25dia |  |
| 61.00004 | Proximity switch 25/32D.RS B35, B36, B37, B38, B39, B40 | Cylinder switch for ORIGA linear drive |  |
| 61.00014 | Reflex photocell MLV40 B18, B19 at small size | Reflex photocell with a sensing range from 25-90mm. |  |

4.2 Sensor B 1, B 2 and B3



| Sensor | Position/Name | Adjustment |
|--------|---------------------------------|--|
| B1 | Heat-sealers starting position | <p>Separate welding head manually (either by hand or by code 204). Loosen Sensor B1 and move to the left until the yellow LED goes out. Then move the sensor slowly to the right until the yellow LED lights up again. Now place the sensor a further 2mm to the right and fix it.</p> <p>N.B. This setting has to been made under pressure.</p> |
| B2 | Heat-sealers operating position | <p>Move welding head together manually (either by hand or by code 204). Loosen sensor B2 and move to the right until the yellow LED goes out. Then move the Sensor slowly to the left until the yellow LED lights up again. Now place the sensor a further 2mm to the left and fix it</p> <p>N.B. This setting has to been made under pressure.</p> |
| B3 | Pressing bars working position | <p>Move pressing bars in manually (either by hand or by code 204). Loosen sensor B3 and move to the right until the yellow LED goes out. Then move the Sensor slowly to the left until the yellow LED lights up again. Now place the sensor a further 2mm to the left and fix it</p> |



4.3 Sensor B 4



B4


| Sensor | Position/Name | Adjustment |
|--------|--------------------------|---|
| B4 | Speed counter flat belts | The slot disc must rotate centrally in the sensor's slot. N.B. Bearing damage to the slot disc shaft will result in destruction of the sensor. |

4.4 Sensor B 5




| Sensor | Position/Name | Adjustment |
|--------|----------------|--|
| B5 | Batch pressure | <p>The plunger must be adjusted using the grub screw so that the distance A between the plunger and the pressing bar is 1-2mm. N.B. Set the adjusting frame to its largest format and check if measurement A is correct with pressing bar both retracted and extended.</p> <p>Start the packaging process with one bundle in the middle shaft and stop it using the stop button as the bundle is being pressed.</p> <p>Call up sensor B5 via code 203. Keep turning adjusting screw (cylinder head cap screw) clockwise until the display shows 0.</p> <p>Unscrew the cylinder head cap screw anti-clockwise until 1 appears on the display. Now unscrew the cylinder head cap screw a further full turn anti-clockwise.</p> |

4.5 Sensor B 7



| Sensor | Position/Name | Adjustment |
|--------|----------------------------|--|
| B7 | Speed counter infeed belts | The slot disc must rotate centrally in the sensor's slot. N.B. Bearing damage to the slot disc shaft will result in destruction of the sensor |

4.6 Sensor B 8 B 9 and B 11




| Sensor | Position/Name | Adjustment |
|-----------------|--|---|
| B8 B9 B11 | Counter lane 1 Counter lane 3 Counter lane 2 | The distance to the paper must be approx. 20-30mm |


4.7 Sensor B 12



| Sensor | Position/Name | Adjustment |
|--------|---|---|
| B12 | Single sheet counter Release, stream counter | The distance to the paper must be approx. 20-30mm |


4.8 Sensor B 14, B 15, B 20 and B 21





Distance A

Distance C




Distance B

Base plate


| Sensor | Position/Name | Adjustment |
|--------|---|---|
| B14 | Elevation table upper final position | As it moves upwards, the elevation table must stop in good time so that distance A is a minimum of 2 mm and a maximum of 4mm. Distance C between sensor B14 and the elevation table should be 0,5mm. |
| B20 | Change-over to slow speed when travelling to the upper final position | The height of sensor B20 is adjusted together with sensor B14. Distance C between Sensor B20 and the elevation table should be 0,5mm. |
| B15 | Elevation table lower final position | As it moves downwards, the elevation table must stop in good time so that distance B (upper edge of elevation table to upper edge of base plate) is +/- 1mm |
| B21 | Change-over to slow speed when travelling to the lower final position | The height of sensor B21 is adjusted together with sensor B15. Distance C between sensor B21 and elevation table should be 0,5mm. |

4.9 Sensor B 16 and B 17



| Sensor | Position/Name | Adjustment |
|--------|-------------------------------|--|
| B16 | Pusher Ground position | When the pusher is moved manually, the pusher must still have 2mm of movement left after the yellow LED on Sensor B16 has lit up |
| B17 | Pusher final working position | When the pusher is moved manually, the pusher must still have 2mm of movement left after the yellow LED on Sensor B17 has lit up |


4.10 Sensor B 19




| Sensor | Position/Name | Adjustment |
|--------|------------------|--|
| B19 | Destacking level | Depends on the product. Height adjustable through long wholes. |

How it works: When collecting products in the pile container the pile height grows. As soon as the Sensor B19 is covered longer than the value of Code 115 by the upper edge of the pile, the table lift will destack slowly until Sensor B19 is free.


Attention: When the pile is very high the batch level compensator can cause problems. It is possible, that the side of the product which is at the entrance of the pile container will be lifted by the batch level compensator so high, that the following products bang into the pile. This happens mainly in single stream mode.



Note: Since August 1999, sensor B19 has been delivered with a different angled piece. The advantage of this is that the de-stacking steps are much more accurate and the stack level is easier to adjust.



4.11 Sensor B 18




| Sensor | Position/Name | Adjustment |
|--------|-----------------------|--|
| B18 | Intermediate position | This depends on the product – the height can be adjusted via the slots |


How it works: After reaching the pre-set number of pieces in the batch, the elevation table moves downwards with the stack on top of it until sensor B18 is free again. It then stops and moves upwards to press the stack. Sensor B18 must be positioned so that it recognises the rear side of the stack. The elevation table may be switched off not only by using the possibility for adjustment provided by the slots but also by using code 122.

N.B.: The rear wall of the shaft or the pressing bars should not cover sensor B18 when the elevation table is in the lower final position.

Note: Since August 1999, sensor B18 has been delivered with a different angled piece. Up until that time it is possible that, with smaller formats together with an activated batch level compensator, sensor B18 has sensed into the hollow space under the batch, which was created by the batch level compensator and, therefore, the elevation table has switched off far too early.




4.12 Sensor B 35 and B 36




| Sensor | Position/Name | Adjustment |
|--------|--|--|
| B35 | Side loader, left, final position (control panel side) | When the side loader is moved manually, the side loader must still have 2mm of movement left after the yellow LED on Sensor B35 has lit up |
| B36 | Side loader, right, final position (operators side) | When the side loader is moved manually, the side loader must still have 2mm of movement left after the yellow LED on Sensor B36 has lit up |

4.13 Sensor B 37 and B 38



| Sensor | Position/Name | Adjustment |
|--------|--|--|
| B37 | Package lift table, lower final position | When package lift table is moved manually, the package lift table must still have 2 mm of movement left after the yellow LED on Sensor B37 has lit up. |
| B38 | Package lift table, upper final position | When package lift table is moved manually, the package lift table must still have 2 mm of movement left after the yellow LED on Sensor B37 has lit up. |

4.14 Sensor B 39 and B 40




B39

B40

| Sensor | Position/Name | Adjustment |
|--------|-------------------------|--|
| B39 | Pusher ground position | When the package lift ejector is moved manually, at least 75% of Sensor B39 must be covered by the actuator. The distance between sensor and actuator 0,5 – 1 mm |
| B40 | Pusher working position | When the package lift ejector is moved manually, at least 75% of Sensor B40 must be covered by the actuator. The distance between sensor and actuator 0,5 – 1 mm |

5 Pneumatics


5.1 Throttle rail BA



Because of the arrangement of the throttles, the operating speed of each pneumatic valve can be adjusted centrally.


| Throttle description | Valve descr. | Function | Time | Output |
|----------------------|--------------|---|----------------|---------------------|
| D 1 | V 5 | Ejector moves to working position | 800 msec | Y 4 |
| D 2 | V 5 | Ejector moves to starting position | 400-600 msec | Y 4 |
| D 3 | V 3 | Lower band tensioned | | Y 5 |
| D 4 | V 3 | Upper band tensioned | | Y 5 |
| D 5 | V 1 | Pressing bar moves to working position | 400 – 450 msec | Y 7 |
| D 6 | V 1 | Pressing bar moves to starting position | (800 msec) | Y 13 not to measure |
| D 8 | V 2 | Welding head moves to working position | 1200 msec | Y 6 |
| D 7 | V 2 | Welding head moves to starting position | 1200 msec | Y 6 |
| D 13 | V 13 | Side loader moves to the left side | 2,5 - 3 sec | Y 25 |
| D 14 | V 13 | Side loader moves to the right side | 2,5 – 3 sec | Y 25 |
| D 15 | V 14 | Package lift moves to working position | 3,0 sec | Y 28 |
| D 16 | V 14 | Package lift moves to starting position | 2,0 sec | Y 28 |

5.2 Ventilschrank BA



| Throttle description | Valve descr. | Function |
|----------------------|--------------|---|
| | V1 | Pressing bars |
| | V2 | Welding heads |
| | V3 | Band tension |
| | V4 | Stopper device for stream feed |
| | V6 | Knife |
| | V7 | Cooling |
| | V8 | Deflector |
| | V9 | Main valve Rise-delay time after starting machine approx. 1 second |
| D10 | V10 | Batch level compensator (optional) |
| D9 | | Tape tensioner movement into starting position |
| D11 | V11 | Air blow |

5.3 Valve manifold




Manual operation:

The valves in the valve manifold (V 1 – V 7) can be switched over to manual operation with a snap-in switch, which means that every cylinder can be operated manually.


NB: When starting the machine all switches must be **engaged** in automatic mode. The main valve (V 9) can be operated by a black button situated on the top.

5.4 Deflector




| Throttle description | Valve descr. | Function |
|----------------------|--------------|-----------|
| | V 8 | Deflector |

5.5 summary side loader




| Throttle description | Valve descr. | Function |
|----------------------|--------------|--------------------------------|
| D13 | V13 | Side loader moves to the left |
| D14 | V13 | Side loader moves to the right |

5.6 summary package lift



| Throttle description | Valve descr. | Function |
|----------------------|--------------|---|
| D15 | V14 | Lifting table moves to working position |
| D16 | V14 | Lifting table moves to starting position |
| D17 | V15 | Ejector package lift moves to starting position |
| D18 | V15 | Ejector package lift moves to working position |


5.7 Service unit




1. Compressed air supply.
2. Control knob for adjusting the working pressure. For trouble-free operation of the BA the standard value must be set at 6 bar.
3. Pressure gauge, shows the set working pressure.
4. Oil nebulizer.
5. Opening for refilling pneumatic oil.
NB: To be filled only in an unpressurized condition. This means that there may be no pressure at compressed air supply 1. The pneumatic oil can be filled up after removing the screw.
 Only use oil according to ISO 3448 with viscosity class VG32.
 for example: BP Energol HLP 32
 BP Visco 2000(SAE 15W-SC)
 Castrol Hyspin AWS22
 ESSO Arox EP46
 Mobil Rarus 427
 Shell Tellus Oil S32
6. Condensate outlet

Serviceintervalle:


- | | |
|---------|--|
| daily: | Drain condensate out of the water separator. |
| weekly: | Check level of oil nebulizer. |



6 Electrical control panel BA700



2933



2934

7 Setting the exits manually

Setting the exits manually enables testing and adjusting of the BA700's components.

The exits can be called up in normal operation using code 204. However, if the password has already been entered, the exits can be set or deleted manually using the "E" or "C" buttons..

Instruction:

Enter password in code 100 and confirm with "E".

Go to the exit level with code 204 and using the arrow up/down button, press until the required exit appears (see exit list).

Now the exit can be switched on or off by pressing the "E" or "C" buttons.

For moving the elevation table manually

ATTENTION!

| |
|--|
| Moving the elevation table up manually is intended for faults under the table. Ensure that nothing is lying on the table when it is moved upwards manually.. |
|--|

Instruction:


Enter password in code 100 and confirm with "E".

Go to the exit level with code 204 and using the arrow up/down button, press until Y18 appears.

Now the table can be moved up or down by pressing the "E" or "C" buttons.

8 Programming of frequency converter

From the fabrication ordernumber 102-8 onwards are the frequency converters password protected.



Keyboard M (Menu)

Downwards move in menu, from STATUS-LEVEL to P-LEVEL to VALUE-LEVEL. Drive stops in operating mode LOCAL.

Keyboard E (Enter)

Upwards move in menu from VALUE-LEVEL to P-LEVEL to STATUS-LEVEL. Please note that the parameter values will be stored during this process. Drive starts in operating mode LOCAL.

Keyboard UP

Scroll through P-LEVEL, increase parameter values.
Increases set value in operating mode LOCAL.

Keyboard DOWN

Scroll through P-LEVEL, decreases parameter values.
Decreases set value in operating mode LOCAL.

Following parameter values must be entered:

BA700 102-13 - 102-14

| Parameter | Frequency converter A13 Press drive | Frequency converter A14 Belt drive | Frequency converter A15 Lifting table drive |
|-----------|---|--|---|
| | | 1,5KW | |
| P1 | 5,2 | 3,6 | 35 |
| P2 | 54,4 | 88 | 65 |
| P3 | 0,3 | 0,3 | 0,3 |
| P4 | 1 | 0,3 | 0,1 |
| P5 | 150 | 75 | 125 |
| P6 | 10 | 10 | 13 |
| P7 | 50 | 50 | 40 |
| P8 | 2,5 | 2,5 | 9 |
| P9 | 25 | 25 | 25 |
| P10 | 102 | 102 | 102 |
| P11 | | 0 | 0 |
| P12 | | 0 | 0 |
| P13 | | 0 | 0 |
| P14 | | 0 | 0 |
| P15 | | 0 | 0 |

9 Programming of frequency converter 1

BA700 102-13B – BA700RS-02B

From the BA700 102-13B and BA700RS-02B model ranges onwards, the frequency converters are equipped with a control element (2). Details of loading and reading the data using the operating panel are shown below. Only for the 0.75 KW frequency converter.

Frequency converter / control element



1. Pull control plug (1).
2. Load data

| Basic state | Button |
|-------------|---------------------------------------|
| | <p>➔ Choose parameter “code” menu</p> |
| | <p>▲ Set parameter to 0002</p> |
| | <p>➔ Confirm skips “para”</p> |
| | <p>▲ Set to 10</p> |
| | <p>enter Load data “load”</p> |

3. To readout data, proceed as described in steps 1-4.:
Now enter the value 20 and confirm. The display shows save instead of load.

10 Belts

10.1 BA700

BA700 102-07 – 102-14

| Belt | Size | Tension | Length | Article-number |
|------|------|---------|--------|----------------|
|------|------|---------|--------|----------------|

| | | | | |
|----------------------------|--|--|---------------|------------------------|
| Lower roundbelts | | | 1.580 x 4 mm | 22.00017 |
| Upper roundbelts | | | 1.610 x 4 mm | 22.00052 |
| drivebelt press Unit | | | 1.073 x 27 mm | 22.00021 |
| drivebelt stream infeed | | | 1.625 x 27 mm | 22.00019 |
| Lower belt stream infeed | | | 1.650 x 30 mm | 22.00038 meter ware |
| Upper belt stream infeed | | | 1.200 x 30 mm | 22.00037 |
| joggingbelt | | | 700 x 15 mm | 22.00008 |
| joggingbelt small sheet | | | 280 x 15 mm | 22.00049 |
| lower belt Small sheet | | | 1.260 x 30 mm | 22.00010 meter ware |

11 Inputs

BA700 102-12 – 102-14

| Nr. | description | | |
|---------|--|---------------------|--------------|
| IN01.1 | Counter Lane 1 | B8 | white-red |
| IN01.2 | Counter Lane 2 | B11 | brown-red |
| IN01.3 | Counter Lane 3 | B9 | white-black |
| IN01.4 | Table lower position, pre switch off | B21 | yellow pink |
| IN01.6 | Table upper final position | B14 | brown-black |
| IN01.7 | Table lower final position | B15 | grey-green |
| IN01.8 | Speed counter infeed belts | B7 | white-pink |
| IN01.9 | Speed counter flat belts | B4 | yellow-brown |
| IN01.10 | Pressing bars working position | B3 | white-yellow |
| IN01.11 | Batch pressure | B5 | white-grey |
| IN01.12 | Table middle position | B18 | white-blue |
| IN01.13 | Pusher working position | B17 | pink-green |
| IN01.14 | Table upper position, pre switch off | B20 | grey-brown |
| IN01.15 | Counters free | B12 | pink-brown |
| IN02.1 | Emergency Stop S1 | B26 | |
| IN02.2 | Emergency Stop Q1 | | |
| IN02.3 | Emergency Stop K6 Error | | |
| IN02.4 | Emergency Stop external (MBO) | B28 | |
| IN02.5 | Hood | B30 | |
| IN02.6 | Hood external (MBO) | | |
| IN02.7 | Head-Save | B25 | |
| IN02.8 | Emergency Stop driver press | | |
| IN02.9 | Emergency Stop driver band | | |
| IN02.10 | Emergency Stop driver table | | |
| IN02.11 | temperature | | |
| IN02.12 | K33 function | | |
| IN02.13 | Error message external (MBO) | | |
| IN02.14 | START signal | B27 | |
| IN02.15 | STOP - signal | B29 | |
| IN02.16 | Pusher ground position | B16 | yellow-grey |
| IN03.1 | Heat-sealers ground position | B1 | white-green |
| IN03.2 | Heat-sealers working position | B2 | brown-green |
| IN03.4 | Tape END | B13 | green-blue |
| IN03.5 | Table level while sheet feeding | B19 | brown-blue |
| IN03.6 | shaft save | | yellow-blue |
| IN03.8 | S-Pusher position end right | B36 | |
| IN03.9 | Batch table upper position | B38 | |
| IN03.10 | Batch table lower position | B37 | |
| IN03.11 | Pusher ground position | B39 | |
| IN03.12 | Pusher working position | B40 | |
| IN03.13 | S-Pusher position end left | B35 | |

12 Outputs

BA700 102-12 – 102-14

| Nr. | description | | |
|----------|--|-----|-----------|
| OUT01.1 | Main valve | Y2 | white |
| OUT01.2 | Knife | Y3 | grey-pink |
| OUT01.3 | Pusher | Y4 | violet |
| OUT01.4 | Tape tension | Y5 | red |
| OUT01.5 | Heat Sealers | Y6 | blue |
| OUT01.6 | Pressing bars working position | Y7 | grey |
| OUT01.7 | Stopper | Y8 | black |
| OUT01.8 | Deflector reject | Y9 | brown |
| OUT01.9 | Deflector pass through | Y10 | green |
| OUT01.10 | Batch Clap | Y11 | yellow |
| OUT01.11 | Cooler | Y12 | red-blue |
| OUT01.12 | Pressing bars ground position | Y14 | pink |
| OUT01.13 | S-Pusher left | Y25 | |
| OUT01.14 | Batch table up | Y28 | |
| OUT01.15 | Pusher out | Y29 | |
| OUT01.16 | | | |
| OUT02.1 | Heat-sealing | Y17 | |
| OUT02.2 | Table Start | Y23 | |
| OUT02.3 | Table down | Y18 | |
| OUT02.4 | Table slow speed | Y20 | |
| OUT02.5 | Table high speed | Y21 | |
| OUT02.6 | Error-message | Y22 | |
| OUT02.7 | Flat - belt Start | Y24 | |
| OUT02.8 | Signal Lamp | Y34 | |
| OUT02.9 | Brake K34 | Y33 | |
| OUT02.10 | contactor K8 | Y35 | |
| OUT02.11 | clearing K36 | Y36 | |
| OUT02.12 | stop MBO while installing | Y37 | |
| OUT02.13 | Tape Drive Start | Y38 | |
| OUT02.14 | Tape Drive rewards | Y39 | |
| OUT02.15 | | | |
| OUT02.16 | | | |

13 Code list TC166

BA700
BA900

| Code nr. | Password protected | Set value | Unit | Title | Description |
|----------|--------------------|-----------|--------------------------|---------------------|--|
| 100 | no | | | Password | 1021 |
| 102 | | | | Program version | |
| 103 | no | 45 | 1/100 sec | Heating time paper | Heating time for paper banding |
| 104 | no | 150 | 1/100 sec | Cooling time paper | Cooling time for paper banding |
| 105 | | | | Cycle counter | |
| 106 | yes | 40 | 1/100 sec | Heating delay | Delay in heating (Y17) depends on B2 |
| 108 | yes | 0 | 1/100 sec | Delay 1 | Delay in moving elevation table up (Y18) after reaching intermediate position (B18) |
| 109 | yes | 0 | 1/100 sec | Delay 2 | Delay in moving elevation table up (Y18) after ejecting the banded parcels depends on B16 |
| 110 | yes | 100 | 1/100 sec | Delay 3 | After completing a package cycle, the machine only goes to destacking mode after this length of time |
| 111 | no | 4 | 2,35mm | Tolerance | Tolerance depends on calibrated value |
| 112 | no | 250 | 1,00mm | Direction counter 1 | In stream feeding mode, the stream is gathered together for this length after reaching the pre-selected batch piece value |
| 113 | no | 130 | 1,00mm | Direction counter 2 | After reaching the pre-selected batch piece value the elevation table, in stream delivery mode, only moves to the intermediate position after this value has elapsed |
| 114 | no | 80 | 1,00mm | Direction counter 3 | After reaching the pre-selected batch piece value the elevation table, in single sheet mode, only moves to the intermediate position after this value has elapsed |
| 115 | yes | 100 | 1/100 sec | Delay 4 | Photocell B19 must be continuously covered for this length of time so that the elevation table is destacking. |
| 116 | yes | 50 | in % of the sheet length | Direction counter 5 | In stream delivery mode, this is the maximum the belts move the sheet forward as it arrives. The distance is calculated from the calibrated value. Standard value is 50% of the calibrated sheet length. |
| 117 | yes | 100 | 1/100 sec | Delay5 | Compensation for the reaction of the deflector |
| 118 | yes | 115 | 1,00mm | Direction counter 6 | In stream delivery mode, the start is triggered by photocells B8/B9/B11. The transport belts start after this value has elapsed |

| Code nr. | Password protected | Set value | Unit | Title | Description |
|----------|--------------------|-------------------|----------------------|--|--|
| 119 | no | 0 1 2 3 | | Language 1 Language 2 Language 3 Language 4 | German German English Dutch |
| 120 | no | 0 | | | Photocell counter lane (B8, B9, B11), 0 = all, 1, 2 or 3 |
| 121 | yes | 2000 | 1/1000 sec | Delay 16 | Welding protection |
| 122 | no | 2 | 1/100 sec | Delay 6 | After reaching the pre-selected batch piece value, the elevation table moves into the intermediate position and stops after photocell B18 is released. Photocell B18 must remain free for at least this period of time before the elevation table stops. |
| 123 | no | 50 | 1/100 sec | Delay 7 | After reaching the intermediate position, the elevation table moves upwards until press sensor B5 responds. This is the maximum value during which it moves up. After this value, the elevation table is stopped and the welding process is triggered independently from B5. |
| 124 | no | 0 | 1/100 sec | Delay 8 | Only in connection with the option "Batch level compensator". Usually, the batch level gates are set so that they retract when they reach the intermediate position. This retraction can be delayed by increasing this value. |
| 125 | yes | 100 | 1/100 sec | Delay 9 | After activation, the pressing guides must be extended at the latest after this length of time (B3). If not, the machine will stop with Error 16. |
| 126 | no | 1 | | | Running out of banding, the machine stops with Error 42 (see also code 127). |
| 127 | no | 200 | cycles | | Cycle selection after display of end of banding until machine stops with Error 42 |
| 128 | no | 0 | each | Counter | Only in connection with the option "Batch level compensator". After reaching this value, the batch level gates are set by the batch counter. |
| 129 | no | min 1 | | | Flashing rate of signal indicator |
| 130 | no | 0 1 | not active active | | Operation of the banding delivery without package lift Operation of the banding delivery with package lift. |
| 131 | no | 1 0 | left right | | Operation of the package lift on the operator side Operation of the package lift on the control box side |
| 132 | no | 1,2,3,4,5 o. 6 | | Packing cycle | The package lift will start after these cycles have elapsed |
| 133 | yes | 50 | 1/100 sec | Delay 10 | After ejecting the banded stacks, the side loader will start after this amount of time has elapsed. |
| 134 | yes | 50 | 1/100 sec | Delay 11 | After conveying the banded stacks to the package lift using the side loader, the lift table will start after this value has elapsed. |

| Code nr. | Password protected | Set value | Unit | Title | Description |
|----------|--------------------|-----------|----------------------|----------|--|
| 135 | | | | | |
| 136 | no | | | | Set-up time |
| 137 | yes | 0 1 | not active active | | Cycle time reduction - Welding heads starts as the same time as elevation table "up". |
| 140 | | | | | Display for actual sheet length |
| 141 | | | | | Display for the result of the measurement of the last bad sheets. |
| 142 | | | m/min | | Display for the speed of the transport belts |
| 143 | | | date | | Last software change |
| 144 | yes | | 1/1000 sec | Delay 12 | Welding time monitoring - if the heating dies are heated for a long time, the machine is stopped with Error 18 |
| 145 | no | | | | Display for cycles until machine stops with Error 42 running out of banding. |
| 150 | yes | 0 1 | not active active | | By activating Total Reset, all memory will be deleted. All variable values will be deleted. All code values will return to basic setup |
| 170 | no | 0 1 | | | Operating mode paper banding Operating mode plastic PE-banding |
| 171 | no | 40 | 1/100 sec | Delay 13 | Heating time for PE-banding |
| 172 | no | 3 | 1/100 sec | Delay 14 | Cutting time for PE-banding |
| 173 | no | 100 | 1/100 sec | Delay 15 | Cooling time for PE-banding |
| 175 | yes | 1 | | Delay 17 | Starting delay for small-package facility |
| 176 | yes | 1 | | Delay 18 | Switch-off delay for small-package facility |
| 203 | no | | | | Input display - Inputs can be checked during operation using cursor up / cursor down keys |
| 204 | no | | | | Output display - Outputs can be checked during operation using cursor up / cursor down keys |

14 Code list TC161

BA700 102-13B
BA900 103- from 15
TC161

Software: BAx07-16 / TC161
 Software: BAx07-17 /

Check software version:
Code: 102

| Code-Nr. | Password protected | Set value | Limit - | Limit + | Unit | Title | Description |
|----------|--------------------|-----------|---------|---------|------|-----------------------|--|
| 100 | no | | | | | Password | 1021 |
| 102 | | | | | | Program version | |
| 103 | no | 450 | 300 | 1000 | ms | Heating time paper | Heating time for paper banding |
| 104 | no | 1500 | 500 | 4000 | ms | Cooling time paper | Cooling time for paper banding |
| 105 | | | | | | Cycle counter | |
| 106 | yes | 400 | 100 | 800 | ms | Heating delay | Delay in heating (Y17) depends on B2 |
| 107 | no | 750 | 100 | 2000 | ms | Timing pressing rails | In single sheet mode (in the operating position) the start of the pressing rails is delayed by the set time. |
| 108 | yes | 0 | 0 | | ms | Delay 1 | Delay in moving elevation table up (Y18) after reaching intermediate position (B18) |
| 109 | yes | 0 | 0 | | ms | Delay 2 | Delay in moving elevation table up (Y18) after ejecting the banded parcels depends on B16 |
| 110 | yes | 1000 | 0 | | ms | Delay 3 | After completing a package cycle, the machine only goes to destacking mode after this length of time |
| 111 | no | 10 | 0 | | mm | Tolerance | Tolerance depends on calibrated value |
| 112 | no | 200 | 0 | | mm | Direction counter 1 | In stream feeding mode, the stream is gathered together for this length after reaching the pre-selected batch piece value |
| 113 | no | 130 | 0 | | mm | Direction counter 2 | After reaching the pre-selected batch piece value the elevation table, in stream delivery mode, only moves to the intermediate position after this value has elapsed |
| 114 | no | 80 | 0 | | ms | Direction counter 3 | After reaching the pre-selected batch piece value the elevation table, in single sheet mode, only moves to the intermediate position after this time has elapsed |
| 115 | yes | 1000 | 0 | | ms | Delay 4 | Photocell B19 must be continuously covered for this length of time so that the elevation table goes down |

| Code-Nr. | Password protected | Set value | Limit - | Limit + | Unit | Title | Description |
|----------|--------------------|------------------|---------|---------|--------------------------|--|--|
| 116 | yes | 50 | 0 | | | Direction counter 5 | In stream delivery mode, this is the maximum the belts move the sheet forward as it arrives. The distance is calculated from the calibrated value. Standard value is 50% of the calibrated sheet length. |
| 117 | yes | 50 | 0 | 200 | in % of the sheet length | Max. distance | Maximum distance of the deflector before a reaction has to occur. |
| 118 | yes | 259 | 0 | | mm | Direction counter 6 | In stream delivery mode, the start is triggered by photocells B8/B9/B11. The transport belts start after this value has elapsed |
| 119 | no | 0 1 2 3 | 0 | 3 | | Language 1 Language 2 Language 3 Language 4 | German English Dutch |
| 120 | no | 0 | | | | | Photocell on the sheet run 0=all, 1=B8, 2=B11, 3=B9 |
| 121 | yes | 2000 | 1000 | 5000 | ms | Delay 16 | Welding time monitoring. If the heating dies are heated for a long time, the machine stops with error 18. |
| 122 | no | 20 | 20 | 5000 | ms | Delay 6 | After reaching the pre-selected batch piece value, the elevation table moves into the intermediate position and stops after photocell B18 is released. Photocell B18 must remain free for at least this period of time before the elevation table stops. |
| 123 | no | 300 | 0 | 10000 | ms | Delay 7 | After reaching the intermediate position, the elevation table moves upwards until press sensor B5 responds. This is the maximum value during which it moves up. After this value, the elevation table is stopped and the welding process is triggered independently from B5. |
| 124 | no | 1500 | | | ms | Delay 8 | Only in connection with the option "Batch level compensator". Usually, the batch level gates are set so that they retract when they reach the intermediate position. This retraction can be delayed by increasing this value. |
| 125 | yes | 1500 | | | ms | Delay 9 | After activation, the pressing guides must be extended at the latest after this length of time (B3). If not, the machine will stop with Error 16. |
| 126 | no | 1 | | | | | Running out of banding, the machine stops with Error 42 (see also code 127). |

| Code-Nr. | Password protected | Set value | Limit - | Limit + | Unit | Title | Description |
|----------|--------------------|-------------------|---------|---------|----------------------|----------------------------|--|
| 127 | no | 1 | | | Zyklen | | Cycle selection after display of end of banding until machine stops with Error 42 |
| 128 | no | 0 | | | Stück | Counter | Only in connection with the option "Batch level compensator". After reaching this value, the batch level gates are set by the batch counter. |
| 129 | no | 1000 | 10000 | 100 | ms | | Flashing rate of signal indicator |
| 130 | no | 0 1 | | | nicht aktiv aktiv | | Operation of the banding delivery without package lift Operation of the banding delivery with package lift. |
| 131 | no | 1 0 | | | links rechts | | Operation of the package lift on the operator side Operation of the package lift on the control box side |
| 132 | no | 1,2,3,4,5 o. 6 | | | | Packing cycle | The package lift will start after these cycles have elapsed |
| 133 | yes | 500 | 500 | | ms | Delay 10 | After ejecting the banded stacks, the side loader will start after this amount of time has elapsed. |
| 134 | yes | 500 | 500 | | ms | Delay 11 | After conveying the banded stacks to the package lift using the side loader, the lift table will start after this value has elapsed. |
| 136 | yes | 100 | | | | | This time elapses after start is pressed. The machine starts. |
| 138 | yes | 15 | | | m/min | Monitoring of set-up speed | For press drive |
| 139 | yes | 8 | | | m/min | Monitoring of set-up speed | For band drive |
| 140 | | | | | | | Display for actual sheet length |
| 141 | | | | | mm | | Display for the result of the measurement of the last bad sheets. |
| 142 | | | | | m/min | | Display for the speed of the transport belts |
| 143 | | | | | date | | Last software change |
| 145 | | | | | cycle | | Display for cycles until machine stops with Error 42 running out of banding. |
| 150 | yes | 0 1 | | | not active active | | By activating Total Reset, all memory will be deleted. All variable values will be deleted. All code values will return to basic setup |
| 151 | yes PW2 | 0 | | | | | Erase RAM |
| 152 | yes PW2 | 0 | | | | | Erase RAM and switch over to programming mode. |

| Code-Nr. | Password protected | Set value | Limit - | Limit + | Unit | Title | Description |
|----------|--------------------|-----------|---------|---------|------|-----------------------------|---|
| 170 | yes | 0 1 | | | | | Operating mode paper banding Operating mode plastic PE-banding |
| 171 | no | 400 | 300 | 800 | ms. | Delay 13 | Heating time for PE-banding |
| 172 | no | 300 | 200 | 3000 | ms | Delay 14 | Cutting time for PE-banding |
| 173 | no | 1000 | 300 | 10000 | ms | Delay 15 | Cooling time for PE-banding |
| 175 | yes | 10 | 0 | 5000 | ms | Delay 17 | Starting delay for small-package facility |
| 176 | yes | 10 | 0 | 5000 | ms | Delay 18 | Switch-off delay for small-package facility |
| 177 | yes | 2500 | 0 | 5000 | ms | Waiting time valve manually | left |
| 178 | yes | 2500 | 0 | 5000 | ms | Waiting time valve manually | right |
| 181 | yes | 0 | 2000 | | ms | Delay external stop signal | |
| 182 | yes | 2500 | 0 | 5000 | ms | Waiting time valve | Side loader left |
| 183 | yes | 2500 | 0 | 5000 | ms | Waiting time valve | Side loader right |
| 185 | yes | 50 | 0 | | ms | Delay19 | Reaction time of the deflector valve |
| 186 | yes | 50 | 0 | | ms | Duration | How long the deflector valve is activated. |
| 196 | | BA700 | | | | Display BA type | BA700, BA900, BA700-A |
| 197 | yes | | | | | Automatic sheet counter | Simulates the sheet counter. The product infeed can be simulated. |
| 203 | no | | | | | | Input display - Inputs can be checked during operation using cursor up / cursor down keys |
| 204 | no | | | | | | Output display - Outputs can be checked during operation using cursor up / cursor down keys |

15 Error list TC166

BA700 102-12 – 102-14
BA900 103-11 – 103-15

Software: 102F-103.h86
BA707-16a

| Error nr. | Conditions | In- / Output | Description | Possible Causes |
|-----------|---|--------------|--|---|
| 04 | Machine Start | B8/B9/B11 | Photocells covered for longer then 2 seconds whilst press drive is running Infeed press | 1. Paper jam before pressing rollers 2. Photocell or cable defective |
| 05 | Machine Start | B7 | There is no signal transmitted from the slotted disc initiator B7 to the control system Drive slip press | 1. Drive belt defective 2. Motor/frequency converter M1 defective 3. Sensor B7 defective |
| 06 | Machine Start Single Sheet Operation | B12 | The photocell B12 before the shaft, is covered for longer than 2 seconds whilst the belts are running | 1. Paper jam before shaft 2. Single sheet mode selected during stream delivery operating mode 3. Input IN01.15 problem 4. Photocell wrongly adjusted and sensing continuously |
| 07 | Machine Start Belt Drive Start | B4/Y24 | There is no signal transmitted from the slotted disc initiator B4 to the control system | 1. V-belt defective 2. Motor/frequency converter M2 defective 3. Sensor B4 defective 4. Input IN01.9 problem |
| 09 | Machine Start Packing cycle | B18/B15 | Photocell B18 is covered when the elevation table has moved completely down after bundling | 1. Paper jam under pressing bars 2. Vertical belt has slipped off 3. Sensor B15 or sensor/cable B18 defective |
| 10 | Machine Start | B5/Y18 | If elevation table should move upwards (Y18), pressing sensor B5 is operated. | 1. Paper jam under pressing bars 2. Check pressing sensor's mechanical function |
| 11 | Machine Start Packing cycle | B16 | After ejecting bundled parcels, the reverse movement of the ejector last longer than 2 seconds. | 1. Paper jam in ejector area 2. Sensor B16 wrongly adjusted or defective 3. Input IN02.16 problem 4. Air pressure too low 5. Throttle D2 adjusted wrongly |
| 12 | Machine Start Packing cycle | | Bundling cycle has not been completed before the next bundling cycle commences. | 1. Number of pieces in batch too low 2. Bundling cycle interrupted by a fault 3. The machine's cycle time is exceeded |

| Error nr. | Conditions | In- / Output | Description | Possible Causes |
|-----------|--------------------------------|-----------------|--|--|
| 13 | Machine Start Packing cycle | B35 oder B36 | Side loader is not in the normal position | <ol style="list-style-type: none"> 1. Paper jam in the vicinity of the side loader 2. Side loader too slow 3. Sensor defective 4. Side loader is not connected 5. Air hose is not connected 6. Air pressure too low 7. Input IN03.8 / IN3.13 problem |
| 14 | Machine Start Packing cycle | B38 | Lifting table is not in the normal position | <ol style="list-style-type: none"> 1. Paper jam in the vicinity of the package lift 2. Sensor defective 3. Package lift too slow 4. Package lift plug loose or not connected 5. Air hose is not connected 6. Air pressure too low 7. Input IN03.9 problem |
| 15 | Machine Start Packing cycle | B39 | Package lift ejector is not in the normal position | <ol style="list-style-type: none"> 1. Paper jam in the vicinity of the package lift 2. Sensor defective |
| 16 | Machine Start Packing cycle | B3/Y7 | The pressing bars need more than 2 seconds to move into the shaft | <ol style="list-style-type: none"> 1. Paper jam in front of pressing bars 2. Air pressure too low 3. Sensor defective or wrongly adjusted 4. Support pressing bars moving against jogging plates |
| 17 | Machine Start Packing cycle | | Elevation table moves right to the top during packing cycle; Protection of welding dies | <ol style="list-style-type: none"> 1. No stack or too small a stack 2. Sensor B14 defective or malfunctioning |
| 18 | Machine Start Welding | | Welding process takes too long | <ol style="list-style-type: none"> 1. Relay K7 defective 2. Relay K5 defective or wrongly adjusted (1.0) 3. Code 121 wrongly adjusted (2000) |
| 20 | Machine Start Packing cycle | B18/B15 | Elevation table does not stop at the intermediate position, but continues to move right down | <ol style="list-style-type: none"> 1. Photocell B18 positioned in the wrong place 2. Paper jam in the vicinity of photocell B18 3. Photocell B18 or its cable defective 4. Sensor B15 covered or defective |
| 21 | Map Device | | Shaft protection with map device | <ol style="list-style-type: none"> 1. Paper jam in the shaft 2. Sensor B100/101/102 or its cable defective 3. Input IN03.6 problem |

| Error nr. | Conditions | In- / Output | Description | Possible Causes |
|-----------|--|--------------|---|---|
| 22 | | B30 | Guard open | <ol style="list-style-type: none"> 1. BA guard open 2. Folding machine guard open 3. Lower banding door of the BA open 4. Cover under the press (BA900) open/released 5. Cover in front of the press (B900) open 6. Cover after the press (BA900) open 7. Input IN02.5 or input IN02.6 problem 8. Wrong adapter used to connect with MBO folding machine with 18-pin plug |
| 23 | | | Emergency-Off folding machine | <ol style="list-style-type: none"> 1. Error message from the folding machine 2. Input IN02.13 problem |
| 24 | | | Emergency-Off button S1 | <ol style="list-style-type: none"> 1. Emergency-Off button on BA 700 pressed or defective 2. Input IN02.1 problem |
| 25 | | | Emergency-Off protective motor switch Q4 | <ol style="list-style-type: none"> 1. Protective motor switch on the jogging drive has switched off |
| 26 | Emergency-Off | K6 | Emergency-Off contactor K6 malfunction | <ol style="list-style-type: none"> 1. Emergency-Off contactor K6 does not fall away 2. Fuses F10 or F11 defective 3. Power unit defective 4. One of the sensor cables defective |
| 27 | Guard open | K33 | Guard contactor K33 malfunction | <ol style="list-style-type: none"> 1. Guard contactor K33 does not fall away |
| 28 | | B45 | Temperature switch-off of the motors | <ol style="list-style-type: none"> 1. Temperature switch in the motors Press drive motor too hot Belt drive motor too hot Elevation table drive motor too hot 2. Output 02.10 defective 3. Input IN02.11 problem 4. Code 123>50 adjusted |
| 29 | Machine Start Packing cycle Elevation Table down | B15 | Elevation table moves to delivery position and takes too long | <ol style="list-style-type: none"> 1. There is material under the elevation table 2. Elevation table down does not function 3. Sensor B15 or B21 defective 4. Elevation table motor defective 5. Frequency converter 6. Input IN01.7 problem (B15) |

| Error nr. | Conditions | In- / Output | Description | Possible Causes |
|-----------|---------------------------------------|--------------|---|--|
| 30 | Machine Start Packing cycle | B14 | Elevation table moves to starting position and takes too long | <ol style="list-style-type: none"> 1. Elevation table system fault (Motor, FRQ, etc.) 2. Parcel between pressing bars & elevation table 3. Sensors B14 or B20 defective 4. Input IN01.6 problem (B14) 5. Elevation table knocks against the jogging plates (bent) |
| 31 | Machine Start Packing cycle | B2 | Time for extending welding die exceeded welding die moves to working position | <ol style="list-style-type: none"> 1. Paper between the welding dies 2. Air pressure 3. Sensor B2 defective or wrongly adjusted 4. Input IN03.2 problem |
| 32 | Machine Start Packing cycle | B1 | Time for retracting welding die exceeded welding die moves to normal position | <ol style="list-style-type: none"> 1. Defective cylinder 2. Air pressure 3. Obstacle 4. Sensor B1 defective or wrongly adjusted 5. Input IN03.1 problem 6. Linear bearing defective |
| 34 | Machine Start Open Guard | | Drives turn at too high a speed during jogging operation | <ol style="list-style-type: none"> 1. Frequency converter defective 2. Tacho defective 3. Frequency converter set to wrong parameters |
| 35 | Destacking without counter release | B12 | Sensor B12 do not aware the product batch counter does not count, destacking sensor covered. | <ol style="list-style-type: none"> 1. Sensor B12 wrongly adjusted or defective |
| 37 | | B41 | Frequency converter pressing drive has switched off | <ol style="list-style-type: none"> 1. Fault with frequency converter A13 2. Protective motor switch Q3 has switched off |
| 38 | | B42 | Frequency converter belt drive has switched off | <ol style="list-style-type: none"> 1. Fault with frequency converter A14 2. Protective motor switch Q3 has switched off |
| 39 | | B43 | Frequency converter elevator table drive has switched off | <ol style="list-style-type: none"> 1. Fault with frequency converter A15 2. Protective motor switch Q3 has switched off |

| Error nr. | Conditions | In- / Output | Description | Possible Causes |
|-----------|--|--------------|---|--|
| 40 | Machine Start Packing cycle Stop-Reset-Start | B17 | Time for moving out ejectors exceeded | <ol style="list-style-type: none"> 1. Package jam in front of the ejector 2. Air pressure 3. Cylinder, cylinder switch 4. Sensor B17 defective 5. Input IN01.13 problem 6. Throttle D1 defective 7. Elevation table's lowest position set too low |
| 41 | Machine Start Normal position | B16 B1 | Machine goes into normal position and table does not go up | <ol style="list-style-type: none"> 1. Air pressure 2. Cylinder, cylinder switch ejector 3. Sensor B16 defective or wrongly adjusted 4. Sensor B1 defective 5. Input IN03.1 problem |
| 42 | Machine Start Band End | B13 | After "band end" has been shown on the display, the machine switches off after the pre-programmed number of cycles has been reached | <ol style="list-style-type: none"> 1. Change tapes 2. Change quantity of cycles with code 127 3. Cable defective 4. Input IN03.4 problem |
| 48 | | B16 | Elevation table moves down B16 is not covered | <ol style="list-style-type: none"> 1. Package jam in front of the ejector 2. Air pressure 3. Cylinder, cylinder switch |
| 49 | | B16 B1 | Elevation table moves up B16 or B1 are not covered | <ol style="list-style-type: none"> 1. Package jam in front of the ejector 2. Air pressure 3. Cylinder, cylinder switch |
| | | | | |

16 Error list TC161

BA700 102-13B
BA900 103-from15

Software: BAx07-16 / TC161

Software: BAx07-17 / TC161

Check Software version:
Code: 102

| Error nr. | Conditions | In- / Output | Description | Possible Causes |
|-----------|---|--------------|--|--|
| 04 | Machine Start | B8/B9/B11 | Photocells covered for longer then 2 seconds whilst press drive is running Infeed press | <ul style="list-style-type: none"> 3. Sensor B8, B9 or B11 covered 4. Sensor wrongly adjusted 5. Input problem 6. A Sensor can see the round belts |
| 05 | Machine Start | B7 | There is no signal transmitted from the slotted disc initiator B7 to the control system Drive slip press | <ul style="list-style-type: none"> 4. Drive belt defective 5. Motor/frequency converter M1 defective 6. Sensor B7 defective |
| 06 | Machine Start Single Sheet Operation | B12 | The photocell B12 before the shaft, is covered for longer than 2 seconds whilst the belts are running | <ul style="list-style-type: none"> 5. Paper jam before shaft 6. Single sheet mode selected during stream delivery operating mode 7. Input IN01.15 problem 8. Photocell wrongly adjusted and sensing continuously |
| 07 | Machine Start Belt Drive Start | B4/Y24 | There is no signal transmitted from the slotted disc initiator B4 to the control system | <ul style="list-style-type: none"> 5. V-belt defective 6. Motor/frequency converter M2 defective 7. Sensor B4 defective 8. Input IN01.9 problem |
| 09 | Machine Start Packing cycle | B18/B15 | Photocell B18 is covered when the elevation table has moved completely down after bundling | <ul style="list-style-type: none"> 4. Paper jam under pressing bars 5. Vertical belt has slipped off 6. Sensor B15 or sensor/cable B18 defective |
| 10 | Machine Start | B5/Y18 | If elevation table should move upwards (Y18), pressing sensor B5 is operated. | <ul style="list-style-type: none"> 3. Paper jam under pressing bars 4. Check pressing sensor's mechanical function |
| 11 | Machine Start Packing cycle | B16 | After ejecting bundled parcels, the reverse movement of the ejector last longer than 2 seconds. | <ul style="list-style-type: none"> 6. Paper jam in ejector area 7. Sensor B16 wrongly adjusted or defective 8. Input IN02.16 problem 9. Air pressure too low 10. Throttle D2 adjusted wrongly |
| 12 | Machine Start Packing cycle | | Bundling cycle has not been completed before the next bundling cycle commences. | <ul style="list-style-type: none"> 4. Number of pieces in batch too low 5. Bundling cycle interrupted by a fault 6. The machine's cycle time is exceeded |

| Error nr. | Conditions | In- / Output | Description | Possible Causes |
|-----------|--------------------------------|-----------------|--|--|
| 13 | Machine Start Packing cycle | B35 oder B36 | Side loader is not in the normal position | 8. Paper jam in the vicinity of the side loader 9. Side loader too slow 10. Sensor defective 11. Side loader is not connected 12. Air hose is not connected 13. Air pressure too low 14. Input IN03.8 / IN3.13 problem |
| 14 | Machine Start Packing cycle | B38 | Lifting table is not in the normal position | 8. Paper jam in the vicinity of the package lift 9. Sensor defective 10. Package lift too slow 11. Package lift plug loose or not connected 12. Air hose is not connected 13. Air pressure too low 14. Input IN03.9/IN3.10 defective |
| 15 | Machine Start Packing cycle | B39 | Package lift ejector is not in the normal position | 3. Paper jam in the vicinity of the package lift 4. Sensor IN3.11 defective |
| 16 | Machine Start Packing cycle | B3/Y7 | The pressing bars need more than 2 seconds to move into the shaft | 5. Paper jam in front of pressing bars 6. Air pressure too low 7. Sensor defective or wrongly adjusted 8. Support pressing bars moving against jogging plates |
| 17 | Machine Start Packing cycle | | Elevation table moves right to the top during packing cycle; Protection of welding dies | 3. No stack or too small a stack 4. Sensor B14 defective or malfunctioning |
| 18 | Machine Start Welding | | Welding process takes too long | 4. Relay K7 defective 5. Relay K5 defective or wrongly adjusted (1.0) 6. Code 121 wrongly adjusted (2000) |
| 20 | Machine Start Packing cycle | B18/B15 | Elevation table does not stop at the intermediate position, but continues to move right down | 5. Photocell B18 positioned in the wrong place 6. Paper jam in the vicinity of photocell B18 7. Photocell B18 or its cable defective 8. Sensor B15 IN 1.12 covered or defective |
| 21 | Map Device | | Shaft protection with map device | 4. Paper jam in the shaft 5. Sensor B100/101/102 or its cable defective 6. Input IN03.6 problem |

| Error nr. | Conditions | In- / Output | Description | Possible Causes |
|-----------|--|--------------|---|---|
| 22 | | B30 | Guard open | 9. BA guard open 10. Folding machine guard open 11. Lower banding door of the BA open 12. Cover under the press open/released 13. Cover in front of the press open 14. Cover after the press open 15. Input IN02.5 or input IN02.6 problem 16. Wrong adapter used to connect with MBO folding machine with 18-pin plug |
| 23 | | | Emergency-Off folding machine | 3. Error message from the folding machine 4. Input IN02.13 problem |
| 24 | | | Emergency-Off button S1 | 3. Emergency-Off button on BA 700 pressed or defective 4. Input IN02.1 problem |
| 25 | | | Emergency-Off protective motor switch Q4 | 2. Protective motor switch on the jogging drive has switched off |
| 26 | Emergency-Off | K6 | Emergency-Off contactor K6 malfunction | 5. Emergency-Off contactor K6 does not fall away 6. Fuses F10 or F11 defective 7. Power unit defective 8. One of the sensor cables defective |
| 27 | Guard open | K33 | Guard contactor K33 malfunction | 1. Guard contactor K33 does not fall away |
| 28 | | B45 | Temperature switch-off of the motors | 5. Temperature switch in the motors Press drive motor too hot Belt drive motor too hot Elevation table drive motor too hot 6. Output 02.10 defective 7. Input IN02.11 problem 8. Code 123>50 adjusted |
| 29 | Machine Start Packing cycle Elevation Table down | B15 | Elevation table moves to delivery position and takes too long | 7. There is material under the elevation table 8. Elevation table down does not function 9. Sensor B15 or B21 defective 10. Elevation table motor defective 11. Frequency converter 12. Input IN01.7 problem (B15) |

| Error nr. | Conditions | In- / Output | Description | Possible Causes |
|-----------|---------------------------------------|--------------|--|---|
| 30 | Machine Start Packing cycle | B14 | Elevation table moves to starting position and takes too long | 6. Elevation table system fault (Motor, FRQ, etc.) 7. Parcel between pressing bars & elevation table 8. Sensors B14 or B20 defective 9. Input IN01.6 problem (B14) 10. Elevation table knocks against the jogging plates (bent) |
| 31 | Machine Start Packing cycle | B2 | Time for extending welding die exceeded welding die moves to working position | 5. Paper between the welding dies 6. Air pressure 7. Sensor B2 defective or wrongly adjusted 8. Input IN03.2 problem |
| 32 | Machine Start Packing cycle | B1 | Time for retracting welding die exceeded welding die moves to normal position | 7. Defective cylinder 8. Air pressure 9. Obstacle 10. Sensor B1 defective or wrongly adjusted 11. Input IN03.1 problem 12. Linear bearing defective |
| 34 | Machine Start Open Guard | | Drives turn at too high a speed during jogging operation | 4. Frequency converter defective 5. Tacho defective 6. Frequency converter set to wrong parameters |
| 35 | Destacking without counter release | B12 | Sensor B12 do not aware the product batch counter does not count, destacking sensor covered. | 2. Sensor B12/B19 defective 3. Sensor B12/B19 not on the product 4. Sensor B12/B19 wrongly adjusted |
| 37 | | B41 | Frequency converter pressing drive has switched off | 3. Fault with frequency converter A13 4. Protective motor switch Q3 has switched off 5. Further information on the FU-Display |
| 38 | | B42 | Frequency converter belt drive has switched off | 3. Fault with frequency converter A14 4. Protective motor switch Q3 has switched off 5. Further information on the FU-Display |
| 39 | | B43 | Frequency converter elevator table drive has switched off | 3. Fault with frequency converter A15 4. Protective motor switch Q3 has switched off 5. Further information on the FU-Display |

| Error nr. | Conditions | In- / Output | Description | Possible Causes |
|-----------|--|--------------|---|---|
| 40 | Machine Start Packing cycle Stop-Reset-Start | B17 | Time for moving out ejectors exceeded | 8. Package jam in front of the ejector 9. Air pressure 10. Cylinder, cylinder switch 11. Sensor B17 defective 12. Input IN01.13 problem 13. Throttle D1 defective 14. Elevation table's lowest position set too low |
| 41 | Machine Start Normal position | B16 B1 | Machine goes into normal position and table does not go up | 6. Air pressure 7. Cylinder, cylinder switch ejector 8. Sensor B16 defective or wrongly adjusted 9. Sensor B1 defective 10. Input IN03.1 problem |
| 42 | Machine Start Band End | B13 | After "band end" has been shown on the display, the machine switches off after the pre-programmed number of cycles has been reached | 5. Change tapes 6. Change quantity of cycles with code 127 7. Cable defective 8. Input IN03.4 problem |
| 48 | | B16 | Elevation table moves down B16 is not covered | 4. Package jam in front of the ejector 5. Air pressure 6. Cylinder, cylinder switch |
| 49 | | B16 B1 | Elevation table moves up B16 or B1 are not covered | 4. Package jam in front of the ejector 5. Air pressure 6. Cylinder, cylinder switch |

