



# XDPP1100 Firmware Introduction

Ivan Seet  
10/1/2024





# Table of contents

- 1 XDPP1100 GUI Installation
- 2 XDPP1100 GUI Overview
- 3 Integrated Development Environment Setup Overview
- 4 Firmware Development Environment
- 5 Number Format
- 6 Useful Link

# XDPP1100 GUI Installation


# XDPP1100 Installation Package

- Install from Infineon Developer Center
- <https://softwaretools.infineon.com/tools>
- <https://softwaretools.infineon.com/tools/com.ifx.tb.tool.xdpp1100configuratoretool>



# Install USB700A/B Driver


- Click the “install.cmd”/ “DPIInst64.exe” in the SiLabsDriver” folder



# XDPP1100 GUI Overview


# XDPP1100 GUI

- XDPP1100 GUI
  - Firmware documentation, Registermap documentation and PMBus documentation open the html document.



# Firmware Documentation


## – Firmware details Document





# Registermap Documentation


## – Register map List



Peripheral Name	Baseline Address	Module Name	Content Summary
analog	70000400	<a href="#">analog</a>	All analog blocks (Loop independent)
vsen0	70000800	<a href="#">vsen</a>	VSEN input voltage sense (typically Loop 0 Vout)
vsen1	70000C00	<a href="#">vsen</a>	VRSEN input voltage sense (typically Loop 0 Vrect)
vsen2	70001000	<a href="#">vsen</a>	BVSEN_BVRSEN input voltage sense (typically Loop 1 Vout or Loop 0, phase 2 Vrect)
vcontrol0	70001400	<a href="#">vcontrol</a>	Loop 0 Vcontrol
vcontrol1	70001800	<a href="#">vcontrol</a>	Loop 1 Vcontrol
pid0	70001C00	<a href="#">pid</a>	Loop 0 PID compensation filter
pid1	70002000	<a href="#">pid</a>	Loop 1 PID compensation filter
isen0	70002400	<a href="#">isen</a>	ISEN input current sense
isen1	70002800	<a href="#">isen</a>	BISEN input current sense
pwm	70002C00	<a href="#">pwm</a>	PWM Generator (Loop independent)
common	70003000	<a href="#">common</a>	Loop independent and shared registers
telem0	70003400	<a href="#">telem</a>	Loop 0 Telemetry
telem1	70003800	<a href="#">telem</a>	Loop 1 Telemetry
fault0	70003C00	<a href="#">fault</a>	Loop 0 Faults
fault1	70004000	<a href="#">fault</a>	Loop 1 Faults
fan1	70004400	<a href="#">fan</a>	Fan1 (Loop independent)
fan2	70004800	<a href="#">fan</a>	Fan2 (Loop independent)
tsen	70004C00	<a href="#">tsen</a>	Telemetry Sense ADC (XADDR1, XADDR2, ATSEN, BTSEN, PRISEN, IMON inputs)
tlmcom	70005000	<a href="#">tlmcom</a>	Common Telemetry (Loop independent)

# PMBus Documentation

## – PMBus Commands List




Command Code	Command Name	Write Tx	Read Tx	Bytes	Description
0h	PAGE	Write Byte	Read Byte	1	The page command provides the ability to configure, control and monitor through only one physical address either: - Multiple outputs on one unit, or - Multiple non-PMBus devices through a PMBus device to non-PMBus device adapter or bridge.
1h	OPERATION	Write Byte	Read Byte	1	The OPERATION command is used to configure the operational state of the converter, in conjunction with input from the CONTROL pin. The OPERATION command is used to: - Turn the PMBus device output on and off with commands sent over the PMBus - Select the margin state of the device (margin off, margin high, margin low) - Select whether fault conditions caused by margining are ignored or acted upon - Select whether the output voltage is set by commands over the PMBus or AVSBus - Select whether the converter powers down immediately or follows the programmed TOFF_DELAY and TOFF_FALL commands when commanded to turn off the output
2h	ON_OFF_CONFIG	Write Byte	Read Byte	1	The ON_OFF_CONFIG command configures the combination of CONTROL pin input and serial bus commands needed to turn the unit on and off. This includes how the unit powers down.
3h	CLEAR_FAULTS	Send Byte		0	The CLEAR_FAULTS command is used to clear any fault bits that have been set. This command clears all bits in all status registers simultaneously. At the same time, the output if the device is asserting the SMBALERT# signal.
10h	WRITE_PROTECT	Write Byte	Read Byte	1	The WRITE_PROTECT command is used to control writing to the PMBus device. The intent of this command is to provide protection against accidental changes. This command can be used to: - Enable or disable writing to the PMBus device - Enable or disable writing to the PMBus device when the SMBALERT# signal is asserted
11h	STORE_DEFAULT_ALL	Send Byte		0	The STORE_DEFAULT_ALL command instructs the PMBus device to copy the entire contents of the Operating Memory to the matching locations in the non-volatile Default Store. Any items in Default Store that do not have matching locations in the Operating Memory are ignored.
12h	RESTORE_DEFAULT_ALL	Send Byte		0	The RESTORE_DEFAULT_ALL command instructs the PMBus device to copy the entire contents of the non-volatile Default Store memory to the matching locations in the Operating Memory. Any items in Default Store that do not have matching locations in the Operating Memory are ignored.
15h	STORE_USER_ALL	Send Byte		0	The STORE_USER_ALL command instructs the PMBus device to copy the entire contents of the Operating Memory to the matching locations in the non-volatile User Store. Any items in User Store that do not have matching locations in the Operating Memory are ignored.
16h	RESTORE_USER_ALL	Send Byte		0	The RESTORE_USER_ALL command instructs the PMBus device to copy the entire contents of the non-volatile User Store memory to the matching locations in the Operating Memory. Any items in User Store that do not have matching locations in the Operating Memory are ignored.
17h	STORE_USER_CODE	Write Byte		1	The STORE_USER_CODE command instructs the PMBus device to copy the parameter whose Command Code matches value in the data byte from the Operating Memory to the matching location in the User Store.

# Firmware development Environment

# Firmware Environment Installation Procedures

- Clone or download Bitbucket Repo.
- [https://bitbucket-dmz.infineon.com/projects/XDPPDPF/repos/xdpp1100\\_firmware\\_environment/browse](https://bitbucket-dmz.infineon.com/projects/XDPPDPF/repos/xdpp1100_firmware_environment/browse)
- Use myicp user account to login(same as myinfineon account).



The left screenshot shows the Bitbucket repository page for 'XDPP1100\_Firmware\_Environment'. The 'Clone in Sourcetree' button is highlighted with a red box. The right screenshot shows the 'Source' dropdown menu with the 'Download' option highlighted with a red box.


File	Version	Size	Last Modified
.gitattributes	new version	8 B	11 Oct 2023
.gitignore	update version	647 B	13 Oct 2023
build_shell.bat	new version	384 B	11 Oct 2023
git_projects.cfg	new version	80 B	11 Oct 2023
License.txt	new version	3.13 KB	11 Oct 2023
README.md	update version	865 B	13 Oct 2023
ReleaseNotes.txt	latest version	590 B	30 Oct 2023
start_eclipse.bat	new version	850 B	11 Oct 2023
user_env.bat	update projects setting	337 B	08 Nov 2023

# XDPP1100 Firmware Environment Installation Procedures

- Python 2.7
  - <https://www.python.org/downloads/release/python-2710/>
- Eclipse neon 3 version or latest
  - [https://www.eclipse.org/downloads/download.php?file=/oomph/epp/2023-09/R/eclipse-inst-jre-win64.exe&mirror\\_id=1135](https://www.eclipse.org/downloads/download.php?file=/oomph/epp/2023-09/R/eclipse-inst-jre-win64.exe&mirror_id=1135)


\*Note: If other version of eclipse is install, Java version will be different. <https://wiki.eclipse.org/Eclipse/Installation>

# XDPP1100 file structure



# Eclipse Workbench Setup

- Start by installing version of java, eclipse, python.
- If using git for firmware repository install this as well.
- Edit  
C:\XDPP1100\XDPP1100\_fw\user\_env.bat
- Set paths to required tools in this file:
  - Git, PYTHON and ECLIPSE.
  - JAVAHOME (optional, do not set it if it is included in Eclipse installation)



```
*user_env.bat - Notepad
File Edit Format View Help
A new version of Notepad is available. Launch
@echo off


:: User should use this to setup their local env, just edit paths to tool installs
set GIT_INSTALL_DIR_BIN=C:\Program Files\Git\bin
set RUBY_INSTALL_DIR_BIN=c:\sofit\shasta_fw\ruby\bin
set GCC_INSTALL_DIR_BIN=C:\cygwin64\bin
set PYTHON_INSTALL_DIR=c:\Python27
set MIKTEX_DIR=C:\Progloc\MiKTeX 2.9\miktex\bin\x64
set ECLIPSE_DIR=C:\eclipse\eclipse
set JAVAHOME="C:\Program Files\Java\jre1.8.0_361\bin"
```

# Integrated Development Environment Setup Overview




# Start Eclipse Environment





- Start eclipse by double clicking ....\xdpp1100\_fw\start\_eclipse.bat



- Select a Workspace. E.g select location XDPP1100\_fw






# Step 1. Import existing patch\_user\_app




## Step 2. Copy patch\_user\_app and Paste to create new project

- › Key the project name (e.g patch\_example\_1) and select location as ..\XDPP1100\XDPP1100\_fw\projects\patch\_example\_1.




## Step 3. New Project Created

- › New project is created for new firmware patch development





## Step 4. Compile new created project

- Expand the “Build Targets” to clean and compile patch using “patch TOOLCHAIN==ARM\_GCC”



# Board Connections with GUI



# Number Format

## Q-number Format

- Q-number format enables representation of fractions and decimal points by signed integers, making rational numbers possible in the CPU.
- Q-number format is usually denoted as **Qm.n**, where:
  - **m** represents the **integers**
  - **n** represents the **decimal points/fractions**
- Using Q-number format perspective:
  - **Unsigned integer** representation can be denoted as **Ux.0**
  - **Signed integer** representation can be denoted as **Sx.0**

Format	Bit length	Min. value		Max. value	
		BIN	DEC	BIN	DEC
U8.0	8	0000 0000	0	1111 1111	255
S8.0	8	1000 0000	-128	0111 1111	127



## Q-number Format

- Adding decimal points/fractions can be done by setting the value of “n”.
  - Setting **n** to **3** on the above U8.0 and S8.0 examples yields Q-numbers of U8.3 and S8.3, respectively.
  - Adding “n” will also lengthen the binary numbers from 8 to 11, and therefore the new bit length can be calculated as:  $length(N) = m + n$
- In U8.0 and S8.0, every increment of LSB corresponds to an increased value of 1 in DEC value.
  - In U8.3 and S8.3, however, every increment of LSB corresponds to a different value.
    - This property is called “LSB weight”, which can be calculated as:  $LSB\ weight = 2^{-(n)}$

Format	Bit Length	LSB Weight	Min Value (DEC)	Max Value (DEC)
U8.3	$8 + 3 = 11$	$2^{(-3)} = 0.125$	0	$(2^{(11)} - 1) * (2^{(-3)}) = 255.875$
S8.3	$8 + 3 = 11$	$2^{(-3)} = 0.125$	$(-(2^{(11)} - 1))) * (2^{(-3)}) = -128$	$(2^{(11)} - 1) - 1 * (2^{(-3)}) = 127.875$

Format	Bit Length	LSB Weight	Min Value (BIN)	Max Value (BIN)
U8.3	$8 + 3 = 11$	$2^{(-3)} = 0.125$	0000 0000.000	1111 1111.111
S8.3	$8 + 3 = 11$	$2^{(-3)} = 0.125$	1000 0000.000	0111 1111.111

## Example


Format	Bit Length	LSB Weight	Min Value (DEC)	Max Value (DEC)
U8.3	$8 + 3 = 11$	$2^{(-3)} = 0.125$	0	255.875
U3.8	$8 + 3 = 11$	$2^{(-8)} = 0.00390625$	0	7.99609375
S8.3	$8 + 3 = 11$	$2^{(-3)} = 0.125$	-128	127.875
S3.8	$8 + 3 = 11$	$2^{(-8)} = 0.00390625$	-4	3.99609375

Format	Bit Length	LSB Weight	Min Value (DEC)	Max Value (DEC)
U8.-3	$8 + (-3) = 5$	$2^{(-(-3))} = 8$	0	248
U3.-8	$3 + (-8) = -5$ (Invalid)			
S8.-3	$8 + (-3) = 5$	$2^{(-(-3))} = 8$	-128	120
S3.-8	$3 + (-8) = -5$ (Invalid)			

Format	Bit Length	LSB Weight	Min Value (DEC)	Max Value (DEC)
U-8.3	$-8 + 3 = -5$ (Invalid)			
U-3.8	$-3 + 8 = 5$	$2^{(-8)} = 0.00390625$	0	0.12109375
S-8.3	$-8 + 3 = -5$ (Invalid)			
S-3.8	$-3 + 8 = 5$	$2^{(-8)} = 0.00390625$	-0.0625	0.05859375

# LINEAR11

- Rational Numbers can also be represented in Exponent-Mantissa format



$e$  = Exponent bit-length


$m$  = Mantissa bit-length

$w$  = Weighting factor

Property	Formula	Representation
Bit Length	$e + m$	$R[(e + m - 1) : 0]$
Exponent		$R[(e + m - 1) : m]$
Mantissa	$2^m + R[(m - 1) : 0]$	$R[(m - 1) : 0]$
Rational Numbers	$\text{Mantissa} * 2^{\text{Exponent}} * 2^w$	$R[(e + m + 1) : 0]$

# LINEAR11

- PMBus Linear Data Format is represented as following



- The relation between Y, N and the “real world” value X is:
  - $X = Y \cdot 2^N$
  - Where X is “read world” value,
  - Y is an 11-bit, two’s complement integer (also called Mantissa)
  - N is a 5-bit, two’s complement integer (also called Exponent).

# Examples

Real World value (X)	Exponent (N)	Exponent (N)	Mantissa (Y)	Mantissa (Y)	16-bit Representation
Real World value (X)	DEC	BIN	DEC	BIN	16-bit Representation
0.5	-1	1 1111	1	000 0000 0001	0xF801
0.5	-9	1 0111	256	001 0000 0000	0xB900
0.5625	-4	1 1100	9	000 0000 1001	0xE009
0.5625	-5	1 1011	18	000 0001 0010	0xD812
-45.375	-3	1 1110	-363	110 1001 0101	0xEE95
-45.375	-4	1 1100	-726	101 0010 1010	0xE52A

# API use for Conversion

## – API that can be use for conversion

```
// LINEAR11 to Q-number
// This is equivalent to 36.0 in decimal.
uint16_t LIN11_num = 0xE920;

// Get the Mantissa
int32_t qNum_man = LINEAR11_TO_MANTISSA(LIN11_num);
// Get the Exponent
int32_t qNum_exp = LINEAR11_TO_EXPONENT(LIN11_num);

// Shift mantissa based on exponent and get original number
int32_t qNum = SHIFT_EXPONENT(qNum_man, qNum_exp);

printf("%d", qNum); // print out 36
```

```
// Q-Number to Linear11
// qNum is the Q number to be converted.
int32_t qNum = 36;
int8_t exponent = -3;

// Calculate LINEAR11 exponent
uint8_t LIN11_expo = TWOS_COMPLEMENT(5, exponent);
// Calculate LINEAR11 mantissa
int16_t LIN11_mant = qNum << -LIN11_expo;

// Shift mantissa based on exponent and get original number
uint16_t LIN11_num = LIN11_expo << 11 | LIN11_mant & 0x7FF;

printf("%x", LIN11_num); // print out 0xE920
```

## Others numbering system

- Some registers that are directly interfaced to the hardware block may already have pre-assigned binary point and LSB weighting.
  - Voltages referenced to the VS ADC's (e.g., internal vout, vrect and vcontrol) have a LSB at 1.25mV. This was chosen to match the VS ADC LSB weight.
  - Other voltages generally place the binary point at 1V to match PMBus.
  - Currents generally place the binary point at 1A to match PMBus.
  - Resistances (e.g., for Droop/loadline) generally place the binary point at 1mOhm to match PMBus.
  - Temperatures generally place the binary point at 1C to match PMBus.
  - Powers generally place the binary point at 1W to match PMBus.
  - Time parameters generally place the binary point based on the HW clock period associated with the parameter. Some variations in binary points are possible such as 5ns, 10ns, 20ns, etc. For some longer time parameters, binary points at 1ms is possible in order to match PMBus.

# Useful Link



## Useful Web Link

- Public
  - <https://www.infineon.com/cms/en/product/power/dc-dc-converters/digital-power-controllers/>
  - [https://www.infineon.com/dgdl/Infineon-DCDC\\_Converter\\_XDP\\_digital\\_power\\_XDPP1100\\_Firmware-Software-v01\\_00-EN.zip?fileId=5546d46279cccfdb0179ea3e3550019e&da=t](https://www.infineon.com/dgdl/Infineon-DCDC_Converter_XDP_digital_power_XDPP1100_Firmware-Software-v01_00-EN.zip?fileId=5546d46279cccfdb0179ea3e3550019e&da=t)
- myInfineon account (Public with myInfineon account)
  - <https://www.infineon.com/cms/en/myInfineon/p/profile/#/productRegistration>
  - <https://softwaretools.infineon.com/projects/create> (Register Demo board for documents)
- myInfineon Collaboration Platform (Required access right from PM)
  - [https://myicp.infineon.com/sites/power\\_management/SitePages/default.aspx](https://myicp.infineon.com/sites/power_management/SitePages/default.aspx)

