


# How Arduino Yun Rev. 2 Connect to IoTtalk?


Dr. Yun-Wei Lin  
NCTU

# Arduino Yún Rev. 2


- 與其他Arduino板子不同之處
  - ATmega32U4 (MCU), 運行Arduino環境
  - Atheros AR9331 (SoC), 運行Linux環境 (Linino)
    - Linino以OpenWRT為基礎修改而成
  - Ethernet
  - WiFi
  - USB A埠
  - micro SD卡插槽



# Arduino Yún Rev. 2上的三顆按鈕



# Arduino Yún上的三顆按鈕




# 電壓, 電流, 與電阻

- Arduino Yún針腳輸出5v, 40ma
- 紅光LED工作電壓約為2.2v, 20ma
- 所以要確保LED壽命較長，需要降壓2v~3v
- 根據 $V=I * R$ 
  - $2v=20ma * R$ ,  $R=100$ 歐姆

設定Arduino Yun連到Wi-Fi AP



## 0. 下載Arduino IDE



The screenshot shows a web browser window with the URL <https://www.arduino.cc/en/Main/Software>. The page has a teal header with navigation links: HOME, STORE, SOFTWARE (active), EDU, RESOURCES, COMMUNITY, and HELP. There is also a search icon, a shopping bag icon, and a SIGN IN link. The main content area is titled "Download the Arduino IDE". It features a large teal circle with the Arduino logo (an infinity symbol with a minus and plus sign) on the left. To the right of the logo, the text reads: **ARDUINO 1.8.8**. The open-source Arduino Software (IDE) makes it easy to write code and upload it to the board. It runs on Windows, Mac OS X, and Linux. The environment is written in Java and based on Processing and other open-source software. This software can be used with any Arduino board. Refer to the [Getting Started](#) page for Installation instructions. On the right side of the main content area, there is a teal sidebar with links to download the software for various operating systems: Windows Installer, for Windows XP and up; Windows ZIP file for non admin install; Windows app (Requires Win 8.1 or 10) with a "Get" button; Mac OS X 10.8 Mountain Lion or newer; Linux 32 bits; Linux 64 bits; and Linux ARM. Below these links are links for Release Notes, Source Code, and Checksums (sha512). At the bottom of the page, there are two sections: "HOURLY BUILDS" and "BETA BUILDS". The "HOURLY BUILDS" section has a yellow box indicating the "LAST UPDATE" as "6 December 2018 22:24:56 GMT". It describes downloading a "preview of the incoming release" with the most updated features and bugfixes. The "BETA BUILDS" section has a brown box with the Arduino logo and the word "BETA". It describes downloading the "Beta Version" of the Arduino IDE with experimental features, noting that this version should NOT be used in production.


檔案 (F) 編輯 (E) 檢視 (V) 歷史 (S) 書籤 (B) 工具 (I) 說明 (H)

Arduino - Software

<https://www.arduino.cc/en/Main/Software>

HOME STORE SOFTWARE EDU RESOURCES COMMUNITY HELP

Download the Arduino IDE



**ARDUINO 1.8.8**

The open-source Arduino Software (IDE) makes it easy to write code and upload it to the board. It runs on Windows, Mac OS X, and Linux. The environment is written in Java and based on Processing and other open-source software. This software can be used with any Arduino board. Refer to the [Getting Started](#) page for Installation instructions.

**Windows** Installer, for Windows XP and up  
Windows ZIP file for non admin install

**Windows app** Requires Win 8.1 or 10  
[Get](#)

**Mac OS X** 10.8 Mountain Lion or newer

**Linux** 32 bits  
**Linux** 64 bits  
**Linux** ARM

[Release Notes](#)  
[Source Code](#)  
[Checksums \(sha512\)](#)


**HOURLY BUILDS**

LAST UPDATE  
6 December 2018 22:24:56 GMT

Download a **preview of the incoming release** with the most updated features and bugfixes.

[Windows](#)


**BETA BUILDS**

 **BETA**

Download the **Beta Version** of the Arduino IDE with experimental features. This version should NOT be used in production.

[Windows](#)  
[Mac OS X](#) (Mac OS X Mountain Lion or later)


1. 將micro usb線串起ArduinoYun與PC
2. 在IDE上選則對應的COM port






# Arduino Yún 與電腦連結之驅動安裝

1. 接上Arduino Yun
2. 進入裝置管理員
3. 找到其他裝置中的Arduino
4. 於其上點右鍵選擇更新驅動程式
5. 將驅動程式目錄選擇到 Arduino IDE目錄下即可找到驅動程式進行安裝




# Arduino Yún與電腦連結成功


- 驅動程式若是安裝成功  
可在連接埠內看到  
Arduino Yun (COMX)  
X=1,2,3,...



### 3. 選擇範例程式YunFirstConfig




### 3.1. 上傳例程式YunFirstConfig到ArduinoYun板子上




```
YunFirstConfig | Arduino 1.8.3
檔案 編輯 草稿碼 工具 說明
YunFirstConfig
1
2 /*
3  Arduino Yún First configuration sketch
4
5  Configures the YunShield/Yún WiFi and infos via the Bridge
6  Works correctly if Line Ending is set as "NewLine"
7  If your board has two USB ports, use the Native one
8
9  The circuit:
10   Arduino YunShield
11   (or any Yun model with firmware > 1.6.1)
12
13   created March 2016
14   by Arduino LLC
15
16   This example code is in the public domain.
17
18   http://www.arduino.cc/en/Tutorial/YunFirstConfig
19  */
20
21 #include <Process.h>
22
23 #define MAX WIFI LIST 10
```

#### 4. 斷電重開，選擇序列埠監控視窗




## 5. 序列埠監控視窗的通訊模式要選 **NL(newline), 115200 baud**






6. 於上方輸入框中依序輸入問題的答案，按下右邊的傳送鈕傳送  
選擇正確 WiFi AP後，接著輸入密碼。



## 7. 設定登入帳號，請輸入 root




```
COM18 (Arduino Yún)
root
Let's start by communicating with the Linux processor
When LED (L13) will light up we'll be ready to go!
Waiting...
(in the meanwhile, if you are using the IDE's serial monitor, make sure that it's configured to send a "Newline")

It looks like you have 3 networks around you
Which one do you want to connect to?

0) MoMo~~~Room
1) planexuser
2) dlink-CD1E
0
It looks like you need a password to connect to MoMo~~~Room
Write it here: *****
We are almost done! Give a name and a password to your Yún
Name:
```

☒ 自動捲動 NL(newline) 115200 baud Clear output

## 8. 設定登入密碼，請輸入 **arduino**



```
COM18 (Arduino Yún)
arduino
When LED (L13) will light up we'll be ready to go!
Waiting...
(in the meanwhile, if you are using the IDE's serial monitor, make sure that it's configured to send a "Newli

It looks like you have 3 networks around you
Which one do you want to connect to?

0) MoMo~~~Room
1) planexuser
2) dlink-CD1E
0
It looks like you need a password to connect to MoMo~~~Room
Write it here: *****
We are almost done! Give a name and a password to your Yun
Name: root
Password:
```

☒ 自動捲動 NL(newline) 115200 baud

## 9. 國碼輸入TW


two letters county code (eg IT, US, DE):'. The bottom status bar shows '自動捲動' (checked), 'NL(newline)', '115200 baud', and 'C'."/>

```
COM18 (Arduino Yún)
US
(in the meanwhile, if you are using the IDE's serial monitor, make sure that it's configured to send a "Newlin
It looks like you have 3 networks around you
Which one do you want to connect to?

0) MoMo~~~Room
1) planexuser
2) dlink-CD1E
0
It looks like you need a password to connect to MoMo~~~Room
Write it here: *****
We are almost done! Give a name and a password to your Yun
Name: root
Password: *****
One last question: where do you live?
Insert a two letters county code (eg IT, US, DE):
```

☒ 自動捲動 NL(newline) 115200 baud C

## 10. 記住畫面所顯示的板子IP



```
COM18 (Arduino Yún)

0) MoMo~~~Room
1) dlink-CD1E
2) planexuser
0
It looks like you need a password to connect to MoMo~~~Room
Write it here: *****
We are almost done! Give a name and a password to your Yun
Name: root
Password: *****
One last question: where do you live?
Insert a two letters county code (eg IT, US, DE): US
Waiting for the Yun to connect to the network....

Great! You can now reach your Yun from a browser typing http://192.168.0.248
Press 'Enter' key twice to start a serial terminal


[ ] 自動捲動 NL(newline) 115200 baud CL
```

Arduino Yun 連接 IoTtalk




# 如何讓Arduino Yún 連結IoTtalk?

- Arduino Yún提供bridge架構，讓Linux環境與Arduino環境之間可以溝通
- Bridge架構




# 如何讓Arduino Yún 連結IoTtalk?

- 需在Arduino Yún板子中，載好與IoTtalk通訊的DAI.py, DAN.py, csmapi.py程式
- DAI: 負責與Arduino程式(IDA) 通訊
  - 使用者仍須修改custom.py來達成與IDA的通訊
- IDA: Arduino環境跑的程式
- DAN:負責跟IoTtalk通訊的程式




- DAI: device application to IoT device
- IDA: IoT device to device application
- DAN: device application to network

# 使用PuTTY連接Arduino Yún



# Google putty and download.



## Download PuTTY: latest release (0.70)

[Home](#) | [FAQ](#) | [Feedback](#) | [Licence](#) | [Updates](#) | [Mirrors](#) | [Key](#)  
Download: [Stable](#) · [Snapshot](#) | [Docs](#) | [Changes](#) | [V](#)

This page contains download links for the latest released version of PuTTY. Currently this is 0.70, released on 2017-07-08.

When new releases come out, this page will update to contain the latest, so this is a good page to bookmark or link to. Alternatively, here is a [permanent link to the 0.70 release](#).

Release versions of PuTTY are versions we think are reasonably likely to work well. However, they are often not the most up-to-date version of the code available. If you have a p those versions.

### Package files

You probably want one of these. They include all the PuTTY utilities.

(Not sure whether you want the 32-bit or the 64-bit version? Read the [FAQ entry](#).)

#### MSI ('Windows Installer')

32-bit: [putty-0.70-installer.msi](#) ([or by FTP](#)) ([signature](#))

64-bit: [putty-64bit-0.70-installer.msi](#) ([or by FTP](#)) ([signature](#))

#### Unix source archive

.tar.gz: [putty-0.70.tar.gz](#) ([or by FTP](#)) ([signature](#))

### Alternative binary files

# 登入Arduino Yún 上的Linino

- 帳號 : root
- 密碼 : arduino

[illegible]

設置python執行環境，安裝requests

請參考 <https://github.com/IoTtalk/Arduino-da>

**opkg update**

**opkg install python-pip**

**pip install requests** (斷電重開機後執行，不然一定會發生記憶體不足 Memory error)

**opkg update opkg install openssh-sftp-server**


註：上述順序不可改。如果裝requests時一直發生memory error記憶體不足，可試著手動依序安裝 idna, urllib3, chardet, certifi, requests 一旦遭遇記憶體不足就斷電重開機後執行後再繼續裝，如果怎樣都裝不起來，只能Factory reset後再試試看。



下載ArduinoYun Rev. 2連接 IoTtalk的程式，並用FTP軟體上傳到ArduinoYun Linux端  
<https://github.com/IoTtalk/ArduTalk-for-ArduinoYun/tree/master/Rev2>

Arduino端要燒入的程式範例

[https://github.com/IoTtalk/ArduTalk-for-ArduinoYun/tree/master/sketch\\_apr17a](https://github.com/IoTtalk/ArduTalk-for-ArduinoYun/tree/master/sketch_apr17a)



The screenshot displays the GitHub interface for the repository **IoTtalk / Arduino-da**. The repository has 9 stars, 0 forks, and 0 issues. The main content area shows the repository's statistics: 63 commits, 1 branch, 0 releases, and 1 contributor. A list of files is displayed, including `Arduino_code_example`, `Rev2`, `DAI.py`, `DAN.py`, `README.md`, and `autoStart.py`. A modal window is open, showing the 'Clone with HTTPS' option, which provides the URL `https://github.com/IoTtalk/Arduino-da.git` and buttons for 'Open in Desktop' and 'Download ZIP'.

# 設定Device Feature, Model, 與 Arduino傳遞資訊的變數

- 指令：vim custom.py

```
192.168.240.1 - PuTTY
root@Arduino:~# vim custom.py
```

```
192.168.240.1 - PuTTY
import DAN

def update_profile():
    DAN.profile['dm_name']='Arduino'
    DAN.profile['d_name']='Arduino Yun'
    DAN.profile['df_list']=['Pin', 'Camera_angle']


def assign():
    return [
        ('Pin', 0, 'PIN'),
        ('Camera_angle', 1, 'Reg_done'),
    ]
```

~ 想要傳送的 Device feature

~ Device feature的維度


~ 與Arduino中透過bridge傳遞的共通變數名稱，意即此變數在Arduino中也要一模一樣。IoTtalkt將device feature傳進此放在bridge中的變數(假設是PIN)在Arduino端就可在bridge中，從變數PIN取出數值

# 透過Bridge傳遞Output Device Feature 數值到Arduino



# 執行DAI.py連結IoTtalk

- 指令：python DAI.py



The screenshot shows a PuTTY terminal window titled "192.168.240.1 - PuTTY". The terminal output is as follows:

```
login as: root
root@192.168.240.1's password:

BusyBox v1.19.4 (2014-11-13 19:03:47 CET) built-in shell (ash)
Enter 'help' for a list of built-in commands.

  ____  .--..--..--..--.  |  |  |  |  |  |  |  |  |  |  |  |  |  |
  |  _  ||  _  |  _  |  ||  |  |  |  |  |  |  |  |  |  |  |
  |____||  _  |  _  |  ||  |  |  |  |  |  |  |  |  |  |  |
      |__| W I R E L E S S   F R E E D O M
-----

root@Arduino:~# python DAI.py
Searching for the EasyConnect server...
```

A small red square is visible at the bottom left of the terminal window.

# 設定Arduino Yún通電後自動連結IoTtalk

執行 `python autoStart.py`

`autoStart.py`會在 `/etc/rc.local` 加入一行

`(sleep 0;python -u /root/DAI.py)&`

# 避免下列行為，以免燒掉Arduino

1. 將任一個 I/O Pins 與 GND 連接形成短路
2. 將 I/O Pins 相互連接
3. 將過大的電壓導引到 I/O Pins 上
4. 外部電流反接
5. 電源由 5V 針腳導入,且外部電源電壓大於 5V
6. 電源由 3.3V 針腳導入,且外部電源電壓大於 3.3V
7. 連接 Vin 與 GND
8. 提供超過 13V 到 Reset Pin 上
9. 超過微控制器所能負載之電流量(200ma)