



Note:
- For 5V operation, jumper 3-5 & 4-6
- For 3.3V operation, jumper 1-3 & 2-4

C1 & C2 *MUST* be 1%, NP0/C0G

TITLE AMS AS3935 Lightning Sensor Breakout Board

FILE: ckt-as3935.sch

REVISION: v1.0

PAGE 1 OF 1

DRAWN BY: Nathan Holmes