

# **ProtoThrottle**

*Realistic Control Stand Throttle*

## MANUAL



IOWA SCALED ENGINEERING – ELECTRONICS MADE EASY!

[www.protothrottle.com](http://www.protothrottle.com)



IOWA SCALED ENGINEERING – ELECTRONICS MADE EASY!

[www.protothrottle.com](http://www.protothrottle.com)

Our goal was to design and develop a wireless throttle that provides the diesel modeler with the most realistic experience operating their model locomotives.

The ProtoThrottle comes with our commitment to your satisfaction. We warranty the throttle from manufacturing defects for one year, and if you should have any questions or issues with the ProtoThrottle, please contact us.

Scott Thornton      Michael Petersen      Nathan Holmes

## This image shows a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

**ProtoThrottle****Model: MRBW-CST, HW Version: 1.2**Iowa Scaled Engineering, LLC  
support@iascaled.com**This product is not a toy.** For ages 14 and over.**Contains FCC ID: MCQ-XBEE3**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modification to the device could void the user's authority to operate the equipment.

**Contains Model XBEE3, IC: 1846A-XBEE3**

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:


- (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Changes or modification to the device could void the user's authority to operate the equipment. Des changements ou des modifications à l'appareil pourraient annuler l'autorité de l'utilisateur à utiliser l'équipement.

## Table of Contents

ProtoThrottle Controls & Battery Install	4
Quick Start Guide	5
Main Screen	6
Engine Menu	7
Special Functions Menu	8
Load / Save Configuration Menus	9
Set Locomotive Menu	10
Force Function Menu	11
Configuration Function Menu	12
Notch Configuration Menu	14
Options Menu	15
System Menu	17
Communication Configuration Menu	18
Preferences Menu	19
Threshold Calibration Menu	21
Diagnostics Menu	22
Electronics Schematic	24
Licensing / Support	25
Open Source Development	26
Notes	27


## ProtoThrottle Controls & Battery Install



The ProtoThrottle is powered by 2 AA batteries (not included). The batteries can be alkaline or rechargeable NiMH.

To access the battery holder, unscrew the 4 phillips head screws on the corners of the throttle's faceplate; remove the box; **IMPORTANT:** when removing the batteries from the holder, use one hand to hold **both** sides of the holder to prevent it from bending away from the printed circuit board; insert batteries and reattach the box. **Do not over tighten the screws.**

**To conserve battery life:** make sure the throttle handle is in "idle" position and the reverser handle is in "centered" position when not in use. This will cause the throttle to go to sleep after 5 minutes. **To power down manually, see the instructions on page 6.**



[www.protothrottle.com](http://www.protothrottle.com)

### Open Design

Iowa Scaled Engineering is committed to creating open designs that users are free to build, modify, adapt, improve, and share with others.

### Hardware

The design of the ProtoThrottle hardware is open source hardware, and is made available under the terms of the Creative Commons Attribution-Share Alike v3.0 license, a copy of which is available from: <http://creativecommons.org/licenses/by-sa/3.0/>

Design files can be found on the Iowa Scaled Engineering's Github site: <https://github.com/IowaScaledEngineering/mrbw-cst>

### Firmware

The official Iowa Scaled Engineering firmware for the ProtoThrottle is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version. A copy of the GNU GPL can be found at: <http://www.gnu.org/licenses/gpl.html>

New firmware can be flashed into the ProtoThrottle through J2. The six pins are a standard AVR 6-pin ISCP programmer connection.

We encourage you to join the ProtoThrottle group forum:

<https://groups.io/g/ProtoThrottle>

The forum will help with general and technical questions regarding the ProtoThrottle.


**Visit the Iowa Scaled Engineering website to learn more about our full line of model railroad electronics.**

[www.iascaled.com](http://www.iascaled.com)  
[support@iascaled.com](mailto:support@iascaled.com)

© 2021 Iowa Scaled Engineering, LLC and Designgrid, LLC

Manual Version 1.2

[www.protothrottle.com](http://www.protothrottle.com)



## Quick Start Guide

The ProtoThrottle will work with any scale and with sound- or non-sound decoders (though using sound enhances the control stand experience significantly). Any DCC decoder compatible with the NMRA standards will work with the ProtoThrottle because it uses standard DCC commands and functions via your command station.. The ProtoThrottle is not a DCC system and will not replace the system you use.

Check the Iowa Scaled Engineering website for the most current list of supported DCC command stations: [www.iascaled.com](http://www.iascaled.com)

**NOTE: if the ProtoThrottle is in "sleep" mode the LCD screen will be dark, click any of the LCD buttons to wake the throttle.**

1. Configure your ProtoThrottle receiver using the instructions provided with the receiver.
  2. Using your DCC system, set **acceleration momentum (CV3) mid-range to moderately high** so that the ProtoThrottle will need to "notch up" to get the train moving.
  3. If using multiple ProtoThrottles, set each throttle to a unique ID. (See page 18.)
- Set deceleration momentum (CV4) high or maximum.** This will allow the train to "coast" when the throttle is in the idle position requiring the use of the brake to slow or stop the train.

3. **Input the locomotive number into the ProtoThrottle:**

1. Click the Menu button 5 times	0003	2. Click the Select button once	4003	3. Use the Up and Down buttons to change numbers
4003	4. Use the Menu button to move cursor right	4795	5. After number is input, click Select button to save	SAVED!

**NOTE: see page 10 for how to set a short (primary) address.**

**NOTE: the ProtoThrottle function settings are set to standard DCC function numbers by default. If you need to change any function number, the steps are explained below:**


4. **To check or set the horn, bell, and brake function numbers:**

1. Click the Menu button 7 times	HORN F02	2. Click the Select button once	HORN F07	3. Click the Up or Down button to change the function number
BRAKE F10	4. Click Menu button to toggle through the other function choices. Repeat step 3 to change additional function numbers.	SAVED!	5. Click the Select button to save all changes	

5. **Enjoy operating your locomotive!**  
Please read the entire manual to familiarize yourself with all the features of the ProtoThrottle. See our website for more specific instructions on programming.

In addition, our website has detailed operational scenarios developed by professional locomotive engineer, Tim Garland. If you are not familiar with prototype operation from an engineer's perspective, Tim's scenarios will give you insight on how to operate more realistically using the ProtoThrottle.

Main Screen



ELEMENT	DESCRIPTION
0250	Locomotive Address. Long (extended) addresses are displayed directly (e.g. 0250 0000 9999). Short (primary) addresses are displayed with an 's' prefix (e.g. s003 s000 s127).
	In certain situations the locomotive address may be replaced by an alert message: EMRG Emergency stop is active! <b>Note:</b> move the brake handle all the way left to deactivate. REV! Reverser was moved with the throttle not in idle
12:00A	The ProtoThrottle acts as a secondary display for Iowa Scaled Engineering's wireless fast clocks <a href="http://www.iascaled.com/store/MRBW-FCM">www.iascaled.com/store/MRBW-FCM</a> or the fast time provided by the NCE Cab Bus.  A 12-hour mode AM indicator P 12-hour mode PM indicator  No AM or PM indicator when in 24-hour mode.
Battery Status: [Battery Icon] Batteries good [Battery Icon] Batteries low [Battery Icon] Replace batteries	Display will show LOW BATTERY when the batteries are critically low. Operation will not be possible until the batteries are replaced.
%	When "AX" is on screen the auxiliary button is active
Up/Down Button Status	Up/Down Button Status. On the main screen, the Up and Down buttons can be assigned to functions. The on/off status of those assigned functions are displayed on the LCD screen.  □ Function off ● Function on
	<b>Note:</b> pressing and holding the Menu button (upper left LCD button) momentarily will return you to the main screen from any of the main menus.

POWER DOWN → Click "down button" to turn off throttle

Advance to Engine Menu  
Toggle backlight on/off; hold to power down throttle



Up  
Down  
**NOTE:** these buttons can be assigned a function using the Configure Function menu

Diagnostics Sub-Menu

ELEMENT	DESCRIPTION
BATTERY 2.30V	Battery Voltage
VERSION 1.1.0	ProtoThrottle Firmware Version
GIT REV 000000	ProtoThrottle Firmware Short Git Hash
BASE TYP CAB BUS	<b>Base Type.</b> The type of ProtoThrottle receiver to which the ProtoThrottle is connected.
BASE REV 000000	Base Unit Short Git Hash
FACTORY RESET 5→	<b>Factory Reset.</b> Press the Down button 5 times to reset the ProtoThrottle to factory settings. <b>WARNING: This will erase all configuration settings, except those in the Threshold Calibration menu, so use with caution!</b>

Cycle through diagnostics settings

Return to Diagnostics Menu



None

None

Diagnostics Menu

DIAGS  
←

Return to Main Menu ●

● None

Enter Diagnostics Sub-Menu ●

● None

LCD Screen

Diagnostics Sub-Menu

ELEMENT

DESCRIPTION

0 0% I N  
- 0 -

**Controls Display.** Shows the current status of the ProtoThrottle controls and buttons. Pressing the up/down buttons will toggle through the current DCC function status.

SLEEP  
300 sec

**Sleep Timeout.** Shows the number of seconds until the throttle goes to sleep.

ALERter  
OFF

**Alerter.** Shows the number of seconds until the alerter expires.

ENGINE  
HISTORY

**Engine History.** Use the up/down buttons to scroll through the engine state history stored in the throttle. The last eight engine on/off states are automatically stored, and recalled, when changing configurations or locomotive address.

PKT TIME  
[■■■■■■]

**Packet Timeout.** Timer reset by each packet received from the ProtoThrottle receiver. Communication is considered lost when the bar reaches zero.

RSSI  
-43dBm

**Received Signal Strength Indicator.** Reports the strength of the wireless connection to the throttle.

FT RATIO  
2.4:1

**Fast Time Ratio.** Reports the fast time ratio from the last update received.

Continued on next page

[www.protothrottle.com](http://www.protothrottle.com)

Engine Menu

ENGINE  
OFF

DESCRIPTION

The behavior of the Engine menu depends on the configuration of the ENG ON and ENG STOP settings in the **Configure Function menu**. For DCC decoders that take a single function on/off to turn the prime mover on/off (such as ESU Loksound or TCS WOWSound decoders), configure ENG ON to that function number and set ENG STOP to off (F--). The Engine menu will then change between OFF and ON when pressing the Up and Down buttons.

ENGINE  
OFF

ENGINE  
ON

If a decoder is edge triggered instead (requires a function on/off transition) to turn the prime mover on and off (such as Soundtraxx Tsunami2), set both ENG ON and ENG STOP to the appropriate function numbers. In this case, the Engine menu will display STARTING and STOPPING between the ON and OFF settings as the assigned functions are sent to the locomotive decoder.

ENGINE  
OFF

ENGINE  
STARTING

ENGINE  
ON

ENGINE  
STOPPING

ENGINE  
OFF

If the throttle is not in idle when attempting to turn off the prime mover, a warning will be displayed and the ENG STOP function will not be sent. Move the throttle back to idle to continue.

ENGINE  
NOT IDLE

**Example #1, F8 for ESU Loksound or F12 for TCS WOWSound:**

ENG ON = F08      ENG ON = F12  
ENG STOP = F--      ENG STOP = F--

**Example #2, F5 (on, RPM+) and F6 (off, RPM-) for Soundtraxx Tsunami 2:**

ENG ON = F05  
ENG STOP = F06

Advance to Tonnage Menu ●

● Start or turn on prime mover

Return to Main Screen ●

● Stop or turn off prime mover

LCD Screen

[www.protothrottle.com](http://www.protothrottle.com)

## Special Functions Menu

SPECIAL  
← FUNCS

Advance to Load Configuration Menu ●

Enter Special Function Sub-Menu ●

LCD Screen

None

None

Special Function Sub-Menu

BRAKE  
TEST →

ELEMENT

DESCRIPTION

BRAKE TEST

Enter Brake Test mode

None ●

LCD Screen

None

Return to Main Screen ●

Begin Selected Special Function

**What is a brake test?** (Note: this is a simplified explanation of train air brakes)

After an engine couples up to a string of cars and the air hoses are connected, the engineer and conductor will usually perform a brake test to ensure there are no air leaks, the pressure drop reaches the end of the train, and the air pressure through the brake lines is adequate. Each car in the train has a reserve air tank that is pressurized to apply the brakes. When the air pressure through the train line is approximately 90 psi, a valve on each car closes off the reserve air tank thus keeping the car free rolling. When the train line air pressure is **reduced** it causes the valve in each car to open releasing the pressurized air from the reserve tank thus applying the brakes. This process is called a "failsafe" because if the train loses it's train line pressure the train will automatically brake. A brake test is performed when the engineer reduces the train line pressure by approximately 20-26 psi thus applying the brakes and the conductor visually confirms the brakes being applied. To simulate this test with the ProtoThrottle, follow the steps below (**note:** the time is user-variable):

1. Release the brake handle and watch the pressure build to it's maximum of approximately ~89-91 psi (*air is simulated increasing into the train line; compressor sound is playing*).
2. Perform the brake test by moving the brake handle to the right. A 26 psi reduction will show on the gauge. (*air is simulated reduced through the train line; air letoff sound plays*).

3. Release the brake handle and let the pressure return to the maximum (*compressor sound starts; once ~90 psi is reached the compressor will silence*).
4. Press the "Return to Main Screen" key to return the throttle to normal operation and the train can now be moved.

[www.protothrottle.com](http://www.protothrottle.com)

## Threshold Calibration Menu

THRSHOLD  
← CAL

Advance to Diagnostics Menu ●

Enter Threshold Calibration Sub-Menu ●

LCD Screen

None

None



**NOTE: These settings are factory calibrated and do not, under most circumstances, need to be changed. Modify them at your own risk!**

**NOTE:** Only displayed if Advanced Functions are ON in the SYSTEM menu

Threshold Calibration Sub-Menu

HORN ○  
240

ELEMENT

DESCRIPTION

NAME

Control Name. The name of the ProtoThrottle control to be calibrated. Hold the control in the desired location and press the Up button to set the new calibration value.

HORN Threshold for the horn function activation

BRAKE Threshold for the brake function activation

BRAKE LOW Left brake handle stop

BRAKE HIGH Right brake handle stop; also threshold for emergency stop

○

Control Status. Shows the on/off status of the selected control.

○ OFF

● ON

240

Internal ADC value for the selected control. Can normally be ignored, unless you're developing code for the ProtoThrottle or are just a nerd.

Cycle through Control Names ●

Save threshold settings and return to Threshold Calibration Menu ●

LCD Screen

Set new calibration value

None

[www.protothrottle.com](http://www.protothrottle.com)



Continued from previous page

#### Preferences Sub-Menu

#### ELEMENT

#### DESCRIPTION

REV LOCK  
ON

**Reverser Lock.** When set to ON, the reverser can only change the locomotive direction when then throttle is in idle, just like the prototype (in fact, on the prototype, the reverser handle is locked and cannot be moved). If the reverser is moved when the throttle is not in idle, the direction will remain the same and the Main Screen will display REV!. When set to OFF, the reverser is allowed to change the locomotive direction regardless of the throttle setting.

STRICT  
SLP OFF

**Strict Sleep.** When ON, the reverser must be centered for the throttle to automatically go to sleep. When set to OFF, the reverser position does not matter and the throttle will go to sleep with the reverser in any position.

Cycle through preference settings

Save preference settings and  
return to Preferences Menu

LCD Screen

Increase value or turn on setting

Decrease value or turn off setting

20

## Load / Save Configuration Menus

LOAD CNF  
01: 0250

SAVE CNF  
01: 0250

LOAD CNF: Advance to SAVE CNF  
SAVE CNF: Advance to Set  
Locomotive Menu

Load selected configuration  
(and return to Main Screen) or  
Save current configuration  
(and return to Main Screen)

LCD Screen

Increase configuration number

Decrease configuration number

#### Load / Save Configuration Sub-Menu

LOAD CNF  
01: 0250

SAVE CNF  
01: 0250

#### ELEMENT

#### DESCRIPTION

LOAD CNF  
01: 0250

SAVE CNF  
01: 0250


CONFIRM  
LOAD? →

CONFIRM  
SAVE? →

**01:** Configuration Number. Up to 20 distinct configurations (locomotive address, function mappings, throttle notch settings, options) can be stored in the ProtoThrottle and loaded quickly using this menu.  
**0250** Locomotive Address. This is the locomotive address associated with the selected configuration number.

Save Configuration screen saves the **current loaded configuration** (with any changes you've made) into whatever configuration slot is on the screen. In order to copy an established configuration, you must load it into the throttle first before "saving" it to another slot.

Both the Load Configuration and Save Configuration functions will ask you to confirm before executing by pressing the Down button. To cancel, click the Menu button.



9

Set Locomotive Menu

← SET  
LOCO

Advance to Force Function Menu ●

Enter Set Locomotive Sub-Menu ●

LCD Screen

● None

● None

Set Locomotive Sub-Menu

0250  
^

ELEMENT

DESCRIPTION

0250

Locomotive Address.

^

Digit Selector.

Move Digit Selector to the next digit ●

Save locomotive address and return to  
Set Locomotive Menu ●

LCD Screen

● Increase selected digit.

● Decrease selected digit.

**NOTE:** To set a short (primary) address, the first digit will need to display an "s". To do so, make sure the other three digits are first set to a valid short address value (<128). Then, cycle through the first digit until the "s" appears.

10

Preferences Menu

← PREFS

Advance to Diagnostics Menu ●

Enter Preferences Sub-Menu ●

LCD Screen

● None

● None

Preferences Sub-Menu

ELEMENT

DESCRIPTION

SLEEP  
DLY: 5M

**Sleep Delay.** Time until the throttle automatically enters low power mode. The throttle handle must be in idle, the reverser handle in centered position, and no buttons or controls actuated for this time. Range from 1 to 99 minutes.

ALERter  
DLY: 60s

**Alerter Delay.** Maximum time allowed without moving any controls. Ten seconds prior to this time, the LCD screen will flash and display ALRT. The Alerter function will also be activated. To cancel the alerter, move and lever or push any button. If the time expires without any lever being moved or button pressed, the speed will be set to zero and the brake function activated. To then reset the alerter, place the throttle in idle and center the reverser.

TIMEOUT  
CLK: 10s

**Clock Timeout.** Maximum time between fast clock time packets. If no time information is received in this interval, the clock display will show dashes to indicate it has lost communication with the fast clock master. Range from 1 to 25 seconds.

PUMP  
RATE: 4

**Pump Rate.** Pumping rate in the brake test special function. Total pumping time can be varied from ~8 seconds to 2 minute 45 seconds. A setting of 4 is approximately 35 seconds.

LED BLNK  
ON

**LED Blink.** When set to ON, the LED on the ProtoThrottle will blink green when communication with a ProtoThrottle receiver is active. When set to OFF, the LED will remain off when communication is active. The LED will always blink red when no communication link has been established.

Continued on next page

19

## Communication Configuration Menu

← COMM  
CFG

Advance to Preferences Menu

Enter Communication  
Configuration Sub-Menu

LCD Screen

None

None

Communication Configuration Sub-Menu

THRTL ID  
A

### ELEMENT

### DESCRIPTION

THRTL ID  
A

**Throttle ID.** Set each throttle to a unique ID using letters A-Z

BASE ADR  
00

**Base Address.** Set to the address of the ProtoThrottle receiver – see receiver instructions.

TIME ADR  
BASE

**Time Source Address.** Selects the fast time source. Set to “BASE” to display time information received from the command station by the ProtoThrottle receiver. To use an Iowa Scaled Engineering Wireless Fast Clock Master, set to the Node Address of the clock (0x01 to 0xFE). Set to “ALL” to display any time information received by the ProtoThrottle. The “ALL” setting works well with a single receiver in a private setting, but may result in erratic time display when multiple ProtoThrottle receivers are in close proximity (e.g. a public train show).

TX INTVL  
1s

**Transmit Interval.** Time between periodic wireless transmissions to the ProtoThrottle receiver. This setting can only be changed if Advanced Functions are ON in the SYSTEM menu.

TX HLD OF  
0.15s

**Transmit Holdoff.** Minimum time between wireless transmissions to the ProtoThrottle receiver. This setting can only be changed if Advanced Functions are ON in the SYSTEM menu.

Cycle through Address/ID Names

LCD Screen

Increase

Save Address/ID settings and return to  
Communication Configuration Menu

Decrease

[www.protothrottle.com](http://www.protothrottle.com)

18

## Force Function Menu

← FORCE  
FUNC

Advance to Configure Function Menu

Enter Force Function Sub-Menu

LCD Screen

None

None

**NOTE:** The Force Function menu allows any of the 29 standard DCC functions to be turned ON or OFF, regardless of any other ProtoThrottle lever or button. These can be used to test functions or control additional features of the decoder such as auxiliary, class, or lesser used lights.

Force Function Sub-Menu

F00 ---

### ELEMENT

### DESCRIPTION

F00

Function Number. Available range from function 0 to function 28.

---

Function Setting.

--- Function can be controlled by a ProtoThrottle button or lever  
ON Function forced on, regardless of any other button or control  
OFF Function forced off, regardless of any other button or control

Cycle through Function Numbers

LCD Screen

Cycle through Function Settings

Save function settings and return to  
Force Function Menu

Cycle through Function Settings

**NOTE:** In the Force Function menu, the horn lever does not activate the horn function. Instead, it will activate the currently selected function number if the function setting is ---.

[www.protothrottle.com](http://www.protothrottle.com)

11

## Configure Function Menu

CONFIG  
← FUNC

Advance to Notch Configuration Menu ●

Up ●

Enter Configure Function Sub-Menu ●

Down ●

LCD Screen

Configure Function Sub-Menu

HORN  
F02

### ELEMENT

### DESCRIPTION

HORN

Control Name. The name of the ProtoThrottle button or handle to which a function can be assigned.

HORN Horn lever

BELL Bell button

BRAKE Brake lever, when brake is activated

BRK OFF Brake lever, when in the full left position

AUX Aux button

ENG ON Prime mover ON/start function (see Engine menu for details)

ENG STOP Prime mover stop function (see Engine menu for details)

THR UNLK Function which, when active due to another control, allows the throttle to send speed commands when the reverser is in centered position. (e.g. Loksound Drive Hold)

REV SWAP Function which, when active due to another control, flips the direction of the reverser

CENTERED Reverser center position

ALERTER Function activated when the alerter timer is about to expire

COMPRSR Compressor sound for the brake test mode

BKR TEST Brake test (air release sound)

F.HEAD Front headlight; active in the Bright and Ditch Lights settings

F.DITCH Front ditch lights; active in the Ditch Lights setting

F.DIM #1 Front dim headlight function #1; active in the Dim setting

F.DIM #2 Front dim headlight function #2; active in the Dim setting

R.HEAD Rear headlight; active in the Bright and Ditch Lights settings

R.DITCH Rear ditch lights; active in the Ditch Lights setting

R.DIM #1 Rear dim headlight function #1; active in the Dim setting

R.DIM #2 Rear dim headlight function #2; active in the Dim setting

*Continued on next page*

## System Menu

SYSTEM  
←

Advance to Communication  
Configuration Menu ●

None ●

Enter System Sub-Menu ●

None ●

LCD Screen

Options Sub-Menu

MENU LCK  
ON

### ELEMENT

### DESCRIPTION

MENU LCK  
OFF

When set to ON, only the following menus are available: ENGINE, TONNAGE, LOAD CNF, SET LOCO, FORCE FUNC, and SYSTEM.

ADV FUNC  
OFF

When set to ON, advanced functions in the throttle are enabled. These include the Threshold Calibration menu and the Transmit Interval and Transmit Holdoff settings in the Preferences menu.

BAT OKAY  
2.2V

**Battery OK Voltage.** The voltage above which the batteries are considered good. ■

BAT WARN  
2.0V

**Battery Warning Voltage.** The batteries are low when the voltage is between the OK and Warning levels. ■

BAT CRIT  
1.8V

**The batteries need to be replaced** when the voltage is between the Warning and Critical levels. ■

**NOTE:** When the voltage falls below the Critical level, LOW BATTERY will be displayed and operation of the throttle will not be possible.

Continued from previous page

#### Options Sub-Menu

##### ELEMENT

##### DESCRIPTION

BRK RATE  
0.5s

NOTE: Only displayed if variable brake is ON and brake type is PULSE

BRK ESTP  
ON

REV SWAP  
OFF

##### Brake Pulse Rate

This sets the rate (0.2-1.0 second) at which brake commands are sent during pulse braking. A smaller value results in smoother braking but can result in a less responsive DCC system due to more commands being sent on the throttle bus.

**E-Stop on Brake Handle.** When set to ON, the brake handle can set emergency stop for the selected locomotive when moved completely to the right. When set to OFF, the brake handle will not cause an emergency stop to be set.

**Reverser Swap.** When set to ON, the reverser directions are swapped. This can be used to correct for a locomotive whose direction is set incorrectly or when changing the leading end of a back-to-back consist. When set to OFF, the reverser directions are normal.

16

Cycle through Options

Save setting and return to Options Menu

LCD Screen

Increase or set option value

Decrease or set option value

Continued from previous page

	UP BTN Main screen Up button
	DOWN BTN Main screen Down button
F00	Function Number. The function to be activated when the associated ProtoThrottle button is pressed or control is moved. Available settings are none (F--) and functions 0 (F00) to 28 (F28).
MOM	Momentary / Latching Function. Only appears for the Up and Down button assignments.  MOM Momentary – the function is only active while the button is pressed LAT Latching – the function toggles on and off with each press of the button
EMRG BRK	Activate the emergency brake. Only appears for the Up and Down button assignments.
BRK TEST	Active the brake test special function. Only appears for the Up and Down button assignments.

UP BTN  
F00 MOM

#### Configure Function Sub-Menu

13

Cycle through Control Names

Save function settings and return to Configure Function Menu

LCD Screen

Increase Function Number

Decrease Function Number. Pressing this button when the Function Number equals zero turns the function off – no function will be activated when the control is operated.

## Notch Configuration Menu

← NOTCH  
CFG

Advance to Options Menu ●

● None

Enter Notch Configuration Sub-Menu ●

● None

LCD Screen

Notch Configuration Sub-Menu

NOTCH #  
102

### ELEMENT

### DESCRIPTION

#

Notch Number.

102

Speed Step. The speed step to send when the throttle is in the selected Notch Number. Range from 1 to 126 (128 speed step mode only). Idle is always speed step zero.

14

Cycle through Notch Numbers ●

● Increase Speed Step

Save notch settings and return to Notch Configuration Menu ●

● Decrease Speed Step

LCD Screen

## Options Menu

← OPTIONS

Advance to System Menu ●

● None

Enter Options Sub-Menu ●

● None

LCD Screen

Options Sub-Menu

VAR BRK  
ON

### ELEMENT

### DESCRIPTION

VAR BRK  
OFF

**Variable Brake.** When set to ON, the brake effect will be proportional to the brake handle position. It is recommended to disable the emergency brake when variable braking is enabled. When set to OFF, the brake will be a simple on/off function.

BRK TYPE  
PULSE


NOTE: Only displayed if variable brake is ON

Brake type:

- PULSE braking
- STEP braking (works with TCS WOWSound function)

**Pulse braking.** The brake function will be pulsed at a duty cycle corresponding to the brake handle position, simulating varying amounts of braking force.

**Step braking.** This feature is for use with TCS WOWSound decoders only. As the brake handle is moved to the right, a greater percentage of the brake is applied.



**NOTE:** the only way to disengage the brake is to fully release the brake handle completely to the left. Also, the emergency brake feature must be disabled for step braking to work correctly.

15

Continued on next page