


Welcome to Teensy® 4.1

32 Bit Arduino-Compatible Microcontroller


To begin using Teensy, please visit the website & click [Getting Started](http://www.pjrc.com/teensy).

www.pjrc.com/teensy



Teensy® 4.1 Features

Special Features and Additional Pins



For solutions to the most common issues
and technical support, please visit:

www.pjrc.com/help

Teensy 4.1 pins are
not 5 volt tolerant.
Do not apply more
than 3.3V to any pin,
except VIN & VUSB.

Teensy 4.1 System Requirements:

PC computer with Windows 7, 8, 10, 11 or later
or Ubuntu Linux 14.04 or later
or Macintosh MacOS 10.10 or later
USB Micro-B Cable

