



Read this manual before operation

- The content include of electric connections and operating steps
- Read the manual to ensure electric connection

LFS-PM-T43 Live Focus System Operating Manual V1.0

RuiDa Technology Co., Ltd

Addr: 1TH FLOOR,5TH BUILDING,NANYOU TIANAN
INDUSTRIAL ZONE,SHENZHEN

Tel: 0755--26066687

Fax: 0755--26982287

E-mail: sales@rd-accs.com

Web: www.rd-accs.com

COPY RIGHT

RuiDa technology keep the right of the following:

1. Ruida technology owns all the patent right and property right of the products. Ruida will preserve the right to pursue legal actions against copying , producing this product.
2. Ruida have the right to modify the content of the manual and reserved the right to modify the related document of the product.
3. User should read the manual carefully. Ruida have no duty to be responsible for the direct, indirect and incidental loss because of the faulty operations of the users.
 - Operation does not follow the manual
 - Operation does not follow the related standards.
4. During the motion, it is dangerous because of the laser and mechanical motion. User should ensure the protection measues.

Contents

CHAPTER 1	INTRODUCTION	1
1.1	PRODUCT INTRODUCTION	1
CHAPTER 2	FUNCTIONS	2
2.1	4.3" TOUCH SCREEN	2
2.2	CONTROL FUNCTIONS	3
2.2.1	Main Interface Introduction	3
2.2.2	Parameter Setting	3
2.2.3	Parameter Management	5
2.2.4	Alarm Information	6
2.2.5	Calibration	6
2.2.6	Auxiliary Gas Test	7
2.2.7	System Info	7
2.2.8	System Time	8
CHAPTER 3	ELECTRICAL CONNECTION	9
3.1	INTERFACE OF THE DISTANCE CONTROLLER	9
3.1.1	Sensor Interface	10
3.1.2	CN1----RS232 Interface	10
3.1.3	CN2----Analog Interface	10
3.1.4	CN3----General Input And Output	10
3.1.5	CN4----Control Input And Output	11
3.1.6	CN5----Power Input	11
3.1.7	CN6----External Power Input	11
3.1.8	CN7----General Input And Output	11
3.1.9	CN8----Motor Control Interface For Step Mode	12
3.1.10	MOTOR Control Interface For Servo Mode	12
3.1.11	HMI Interface	13
3.1.12	USB Interface	13
3.2	LED INDICATOR	13
CHAPTER 4	TEST AND RUN	15
4.1	DISTANCE CONTROLLER TEST	15
4.2	CUTTING TEST	17
CHAPTER 5	ALARM INFORMATION	20
5.1	DESCRIPTION OF THE ALARM	20
5.1.1	System Error	20
5.1.2	Upper/Lower Limit Trigger	20
5.1.3	Reset Error	20



5.1.4	Capacitance Smaller	20
5.1.5	Crash Alarm	21
5.1.6	Emergency Stop	21
5.1.7	Too Large Following Error	21
5.1.8	Multiple Error	21
CHAPTER 6 INSTALLING		22
6.1	SIZE OF THE DISTANCE CONTROLLER	22
6.2	SIZE OF THE AMPLIFIER	22
APPENDIX: TROUBLE SHOOTS		23

Chapter 1 Introduction

1.1 Product Introduction

LFS-PM-T43 is a automatic distance control system that based on the capacity sensor. This system has a 4.3" TFT touch screen and can display the work status and detecting capacity value. An advanced capacity detecting technology has been applied to have a stable and anti-interference capacity result. With this sensor detecting technology, the responsibility and accuracy have been improved. The key functions are just like following:

- 1) Control servo or step motors, high responsibility and accuracy.
- 2) Support crash alarm, limit trigger protection and servo alarm protection.
- 3) Automatic calibration and can compatible with the third party's laser head.
- 4) Support focus distance modified on line. capacitor detecting scale is 0~9.9mm.
- 5) Work status of the laser head indicates and alarm indicates.
- 6) Support different setting of the rising height. Rising speed can be modified.
- 7) Auxiliary gas control. Support 3 channels auxiliary gas control.
- 8) Firmware updated by U disk.


Chapter 2 Functions

2.1 4.3" Touch Screen

This distance controller is included of a 4.3" touch TFT screen. The resolution is 480*272. the laser head work status is displayed in the monitor and parameters can be modified with the monitor. the display area is function button area, data display area, running status display area and alarm display area.

The main interface is just as the following:

- Function button area: touch the buttons can enter different function control menu.
- Data display: here is used to display the detecting value of the capacitor sensor and other set values.
- Focus position: the distance between the nozzle and the work piece.
- Actual position: the actual value of the capacitor detected.
- Following error: the error between the focus position and the actual position.
- Capacitor value: the value that the controller has detect from the capacity sensor.
- Running status : display the status of the laser head.
- Alarm display: alarm status display. If there are several alarm triggered at the same time, user can touch the "Alarm Info" to check the alarm information in detail.



Main interface



The communication between the controller and the touch screen monitor is by RS232.

If all the electrical connections has been done correctly, when power on the controller, the monitor of the controller will go to the main interface. If there are no error happened, that means the automatic distance controller work well.

But if the monitor indicate that connection failed because of the cable fault or other reasons, "connect failure" will be popped up. User should check the cable and the sensor devices.


2.2 Control Functions

2.2.1 Main Interface Introduction

- ◆ **“FOLLOW ON/OFF”**: Enable or disable the tracing function. If it is tracing on, the color of the button will changed into green, which means the controller is under the tracing status. If the height of work sheet changes, the laser head will tracing the movement of the work sheet and always keep the distance to be a constant value. If it is tracing off, the tracing function is disabled. If the height of the work piece changes, the laser head has no response to that during the motion of the cutting system.
- ◆ **“SPEED LOW/HIGH”**: is used to switch the manual speed to faster or slow.
- ◆ **“Menu”**: there are children menus in the menu to set some functions.
- ◆ **“Reset”**: To reset the distance controller. Before running reset function, be sure that the upper limit has been installed correctly.
NOTICE: There is danger during the reset operation because of the mechanical motion. So all the section should be checked before that and try to avoid of human harm.
- ◆ **“±0.1”**: modify the distance between the nozzle and the work sheet. Press one time, 0.1mm will increase or decrease.
- ◆  : to control the laser head to move up or move down. If the button is pressed, the laser head will be always moving until the button is released.
- ◆ **“Alarm Info”**: Press the button; user will go to the alarm information records interface. User can check the alarm information that happened recently. The maximum number of the alarm record is 9.
- ◆ **“Function”**: go to the auxiliary gas test and capacitor calibration menu.
- ◆ **“System Info”**: check the version of the controller and multi-language selection.
- ◆ **“System time”**: modify the system time.

2.2.2 Parameter Setting

Press “Menu” to enter the interface of craft parameter setting, height parameter setting, velocity parameter setting, machine parameter setting and other parameters.



Notice: Before operating the distance controller, be sure that the parameters has already set correctly.

The sense of the parameters is shown as the table:

Technical Para	Filter Factor	Increase the value will improve the responsibility of the laser head.
	Alarm Filter	Filter time for crash alarm protection. If the value is too small, the crash alarm will usually triggered because of the metal dross during cutting. If the value is too big, this will decrease the responsibility of the crash alarm protection.
	Blow Delay	Auxiliary gas release time before cutting or punch.
	Punch Gas	Auxiliary gas selection for punch.
	Cutting Gas	Auxiliary gas selection for cutting.
Height Para	Rise Height	The rising height for laser head during jump motion.
	Alarm Height	When the alarm triggered, the laser head is on the stop height.
	Standby Height	When the cutting task is finished, the laser head is on the position.
	Focus Position	The distance between the nozzle and the work piece.
	Reset Height	When reset the laser head, the laser head will trigger the limit switch and move reversely for this distance.
	Max Follow error	During a close control, the error between the actual position and referenced poison should never beyond the value. If that happened, system protection will be executed and generate the alarm of following error over limit.
Speed Para	Rise Speed	Rising speed.
	Follow Speed	The maximum tracing speed.
	Reset Speed	Laser head reset speed.
	Manual Speed High	The manual fast speed.
	Manual Speed	The manual slow speed.

	Low	
Machine Para	Direction Polarity	Set the rotation of the motor.
	Acceleration	Motion acceleration.
	Screw Pitch	Screw pitch.
	Circle Pulse Number	When the motor rotate one round, the number of control pulse should sent to the motor drive.
Other Para	Enable Power On Reset	Enable or disable the reset when power on.
	Enable Crash Protect	If the crash alarm is enabled, when the laser head has touched the work piece for a certain time(over the filter time), system will rise up the laser head and stop the motion of the cutting system. If it is disabled, the crash alarm will be neglected.
	Limit Polarity	Set the sense of the limit switch. If a NPN limit switch is installed, user should set the polarity to be negative. If it is PNP, the polarity should be set to positive.
	Enable Limit	If the limit protection is enabled, when the limit is triggered, the motion protection will take affect such as rising the laser head and stop motion.

2.2.3 Parameter Management


Parameters management is used to save and restore the parameters of the distance controller. Not everybody can operate this function. There are passwords for user to manage this function. When user has configured all the parameters correctly, then these parameters can be set to be default. So if the parameters have been changed, user can restore the right parameters from the default. We suggest that user must save the correct parameters to be default when all the parameters have been tuned correctly.



2.2.4 Alarm Information

On the main menu, press “ALARM INFO” to go to “ALARM INFO” interface.

User can check the alarm information. The information include of the alarm time and alarm source. The maximum records are 9 records that is saved. Press the “Clear”, all the information is cleared. User still can press “Page Up” or “Page Down” to check the information.



2.2.5 Calibration

In the main menu, press “FUNCTION” to go to “CALIBRATION” interface.

Calibration is very important for a correct application of the distance controller. If the laser head has stand by for a very long time or the environment has changed a lot, a calibration should be done. If user has change or replace some parts of the capacitor, the calibration must be done again.


Before calibration, slowly moving the laser head to close to metal work piece and let the laser head to be standby status. Make sure that the metal sheet has been connected to the EARTH well and the machine also connects to the EARTH well. Then we can start a calibration. If the metal sheet is not connected to the earth well, the calibration may be failed. If the laser head is always moving down to touch the metal sheet and never stop, user should check the metal sheet conduct with the machine well or not. If the conduction is ok, then check the electrical connection and the capacitor sensor is good or not.

The normal calibration is just as the following:

- Laser head move down toward the metal sheet
- Touch the metal sheet and stop for while
- Then rise up to reach a position
- Then move down slowly
- Touch the metal sheet again then rise up to standby position

When the calibration is finished, a calibration curve will drew on the screen. The detection scale is also displayed. The curve indicates the response of the capacitor when the distance is changed. If the curve is smooth and the value is in the desired scale, that means the calibration is successful. User can press “ENTER” to save the calibration data.

If the calibration is not smooth and there are noises on it, that means the calibration is failed. User can press “CANCEL” to ignore the result. User should not save the calibration data. User should check the reason that has caused this situation and do the calibration again and again until the curve is smooth.



Because the capacitor is a sensitive to temperature and humidity of the environment, user should wait 3~5 minutes when power on to let the sensor and amplifier to reach a stable temperature.


2.2.6 Auxiliary Gas Test

In the main menu, press “FUNCTION” to go to the “AUXI GAS” interface.

This function is used to test the auxiliary gas is good or not. Auxiliary gas testing include of 3 channels auxiliary gas testing.

Testing steps: example for test the auxiliary gas with high pressure, press “High Pressure”, then the auxiliary gas channel is turned on. Release the button, then turn of the channel.

Notice: Before testing the auxiliary gas, make sure the control system is in the standby status. Or the testing can not be done.



2.2.7 System Info

Press “SYSTEM INFO” to go to system information interface.

This page include of the language selection and the version of the controller.




Language: ENGLISH

Version: 3.01.100

Enter Cancel

2.2.8 System Time

In the main menu, press the “date and time” to go to modify the date and time.



Change date and time

Date: 2016 Year 12 Month 15 Day


Time: 14 Hour 40 Minute 32 Seconds

Enter Cancel

Chapter 3 Electrical Connection

3.1 Interface Of The Distance Controller

The wiring diagram is just as follows:



3.1.1 Sensor Interface

This interface is to connect the amplifier and distance controller.

When installing the amplifier, the shield of the amplifier should be have good conduction with the laser head (sensor and nozzle). There a wiring terminal on the shield of the amplifier. User can connect the terminal to the laser head. The metal sheet should still have a good conduction with the machine. Or the capacity sensor will not work normally.

3.1.2 CN1----RS232 Interface

PIN	SIGNAL	DEFINITION	DESCRIPTION
PIN 1	TXD	Send data	—
PIN 2	RXD	Receive data	—
PIN 3	GND	GND	—

3.1.3 CN2----Analog Interface

PIN	SIGNAL	DEFINITION	DESCRIPTION
PIN1	AGND	Analog GND	
PIN2	Analog In	Analog input	Input scale: 0—10V
PIN3	Analog Out	Analog output	Output scale: 0—10V

3.1.4 CN3----General Input And Output


PIN	SIGNAL	DEFINITION	DESCRIPTION
PIN1	Lmt+	UP limit	24V level
PIN2	Lmt-	Down limit	24V level
PIN3	EmStp	Emergency input	Low level valid
PIN4	In1	General input	—
PIN5	In2	General input	—
PIN6	In3	General input	—

Limit switch include of up limit and down limit in the Z axis. support N.C and N.O mode. If the limit is N.O, the polarity should be set to be negative. If the limit is N.C, the polarity should be set to be positive.

The limit switch can be mechanical, opto-electric and magic type. But all the limit should be 24V standard. It can be OC interface mode.

3.1.5 CN4----Control Input And Output

PIN	SIGNAL	DEFINITION	DESCRIPTION
PIN1	Trace	Trace signal	When low level, the LFS will control the laser head to trace down. When high level or open, the LFS will rise the laser head.
PIN2	Punch	Punch signal	Come from the controller When high level (+24V), that means the controller is punching.
PIN3	WrkOk	Work status indicator	controller work status. The signal comes from the controller.
PIN4	UpOk	Rising up status	Low level valid
PIN5	DnOk	Going down status	Low level valid
PIN6	AlmOut	Crash alarm output	When the laser head crash to the metal plate, the AlmOut output 24V.



3.1.6 CN5----Power Input

PIN	SIGNAL	DEFINITION	DESCRIPTION
PIN1	+24V_IN	+24V Power	+24V, Drive ability above 2A
PIN2	GND	GND	—
PIN3	PGND	EARTH	—

3.1.7 CN6----External Power Input

PIN	SIGNAL	DEFINITION	DESCRIPTION
PIN1	OGND	OGND	—
PIN2	OVCC	External +24V Power	—


3.1.8 CN7----General Input And Output

PIN	SIGNAL	DEFINITION	DESCRIPTION
PIN1	Blow_H	High pressure gas control	Drive relay
PIN2	Blow_L	Low pressure gas control	Drive relay
PIN3	Air	Air control	Drive relay
PIN4	Out1	General output	—
PIN5	Out2	General output	—
PIN6	Out3	General output	—

3.1.9 CN8----Motor Control Interface For Step Mode

PIN	SIGNAL	DEFINITION	DESCRIPTION
PIN1	Pulse-	—	—
PIN2	Pulse+	—	—
PIN3	Dir-	—	—
PIN4	Dir+	—	—
PIN5	GND	—	—

- 1) To control step motor, differential mode and common-anode mode can be applied.
We recommend user to select differential mode .



- 2) To control servo motor, please set the parameters correctly according to the operation manual of the servo drive.
 - ◆ Set the servo drive to work at the position mode.
 - ◆ The polarity of the pulse and direction.
 - ◆ The number of pulse/per round.

3.1.10 MOTOR Control Interface For Servo Mode

PIN (color of wire)	signal	definition
PIN1 (yellow)	SPEED	+/-10V speed command
PIN2 (blue)	OS	Zero speed
PIN3 (black)	A+	Encoder A+
PIN4 (orange)	B+	Encoder B+
PIN5 (red)	Z+	Encoder Z+

PIN6 (green)	SON	Servo on
PIN7 (green/white)	CLR	Alarm clear
PIN8 (brown)	+24V	+24V output
PIN9 (yellow/white)	AGND	Analog GND
PIN10 (blue/white)	GND	GND
PIN11 (black/white)	A-	Encoder A-
PIN12 (orange/white)	B-	Encoder B-
PIN13 (red/white)	Z-	Encoder Z-
PIN14 (purple)	ALM	Servo alarm input
PIN15 (brown/white)	GND	GND

3.1.11 HMI Interface

The connection between the distance controller and the displayer is shown as follows:



3.1.12 USB Interface

USB is a U disk interface that used to upgrade the firmware.

LAN is a ETHERNET interface.

3.2 Led Indicator

LED name	Description
+24V	24V Power indicator
Run	System running indicator
Trace	Tracing signal indicator
Punch	Piercing indicator
WrkOk	Work finish indicator
UpOk	Rising up ok indicator
DnOk	Tracing down ok indicator
AlmOut	Alarm indicator

Lmt+	Up limit indicator. Low level input will turn on the led
Lmt-	Down limit indicator. Low level input will turn on the led
EmStp	Emergency stop input. Low level input will turn on the led
In1	Low level input will turn on the led
In2	Low level input will turn on the led
In3	Low level input will turn on the led
Status	U disk status
Alm	Servo alarm input. Low level input will turn on the led
Clr	Servo alarm clear. Low level input will turn on the led
Os	Zero speed status. Low level input will turn on the led
Son	Low level input will turn on the led
Pulse	Pulse signal indicator. Low level input will turn on the led
Dir	Direction signal indicator. Low level input will turn on the led
Blow_H	High pressure gas control output. Low level input will turn on the led
Blow_L	Low pressure gas control output. Low level input will turn on the led
Air	Air control output. Low level input will turn on the led
Out1	Low level input will turn on the led
Out2	Low level input will turn on the led
Out3	Low level input will turn on the led

Chapter 4 Test and Run


Test and run is based the RDC6332M cutting controller and the control software is Metal Cut.

4.1 Distance Controller Test

Before we start the distance controller test and run, the cutting control system and the distance controller should be wired correctly.


When you want to start a normal testing, the user parameter and vendor parameter should be configured correctly. Shown as the following:

MetalCut→FILE→VENDOR SETTING→OTHERS→ to enable “ENABLE PROTECT”:





MetalCut→VENDOR SETTING→SPECIAL→(the password is rdtmm)→height controller type(common)→check follow up(use trigger)→check follow(use trigger).

Shown as following:



User still can select the “check follow up” to be “use delay” and the “check follow” to be “using trigger”.

The first operation should be careful. The following step should be noticed:


- 1) If the drive is servo drive, please set the parameters correctly according to the operating manual of the servo drive.
- 2) Then power on the distance controller, go to the “MENU”→“Setting”. Configure the parameters correctly.
- 3) To check the limit switch is good or not. User can trigger the limit manually. If it work well , the information of up limit trigger or down limit trigger will be displayed in the screen. That means the limits are working well.
If the polarity of the limit is wrong, please check and modify the polarity of the limit in the menu.
Then check the crash alarm is good or not. Just move the laser head or the work piece to keep they touch each other. If there are crash alarm information displays in the screen, which means the crash alarm is ok.
- 4) Press  , check the moving direction of the laser head, if the direction is not the desired direction, then modify the “motor polarity”.
- 5) Calibration. If the calibration result is good, then save the data.
- 6) Press “trace off”, the button will changed into green and the text will change into “trace on”. Press the “.” on the operating panel of the cutting system. The laser head will tracing down to the work piece and enter the tracing mode. Press “.” again, the laser head will rise to a certain position.
- 7) If all the steps is ok, that means the distance controller work well.

4.2 Cutting Test


Before start a cutting, user should configure the parameters of the machine correctly.
please reference to the RDC6332M controller operating manual.

Cutting test should follow the steps:

- 1) Open MetalCut, draw a cutting rectangle with the drawing tools.



- 2) Set the layer parameter





For laser piercing, the motion controller support CW piercing and pulse piercing mode. To set the piercing mode in the user parameters and layer parameters.

If laser CW piercing has been enabled, there is a continuous laser on the metal work piece for a certain time and then start a normal cutting. If it is pulse piercing, then the piercing time is decided by the piercing times (n) and single piercing time (Ton).

$$\text{Piercing time} = n \cdot T_{on}$$

Pulse piercing is used to be applied for thick metal sheet cutting.


The following is a example for pulse piercing. The piercing times are 4 and the single piercing time is Ton. The interval time between 2 pulse is Toff.



The total piercing time = $50 \cdot 4 = 200\text{ms}$;

User can set the laser power for laser piercing and the laser power for cutting.

3) User parameter setting



4) Auxiliary test

Press the "function" to go to "auxiliary test" page. This used to test the piercing gas and the cutting gas.

5) Laser emission test

In the operating panel of the motion controller, press "pulse" to test the laser.

6) Reference position

Move the laser head to a referenced position. Press "reference" and the current position is set to be the zero position.

7) Frame

After set the referenced position, press "Frame" to execute a frame motion.

8) Start cutting

Press "start" to start a normal cutting.

Chapter 5 Alarm Information

5.1 Description Of The Alarm

During the running, there maybe some alarm happened because of some undesired conditions. The alarm information will be considered and some protection should be executed. The alarm information include of upper limit trigger, lower limit trigger, reset error, crash alarm, too large following error, emergency stop and capacitance smaller. When one or several alarm happened, the information will be displayed on the displayer. User should check the reasons that have caused the alarm and clear the alarm.

5.1.1 System Error

It is a system fault. When the hardware or the firmware is failed, the alarm happened. When the alarm happened, the system will stop motion. User should check the distance controller and power on it again. If the alarm is still there, user should take a new controller to replace that one.

5.1.2 Upper/Lower Limit Trigger

When the limit protection has been enabled, the system will display the limit trigger information once the limit is triggered. If there are limit triggered, there may be the following reason:

- ◆ The sense of the limit switch is set incorrectly.
- ◆ Wrong wiring.
- ◆ Limit switch fault or the voltage level is not 24V.

5.1.3 Reset Error

There may be the following reasons to cause the reset error:

- ◆ When resetting, the laser head have no motion or the speed is too low and has caused a timeout action. Please check the parameters of the distance controller.
- ◆ The polarity of the motor is wrong. When resetting, the laser head move down to trigger the down limit.

5.1.4 Capacitance Smaller

If the current detected capacity value is too small, then the capacity fault will

displayed. There may be the following reasons:

- ◆ Do not do a calibration for a long time or the humidity and temperature has changed a lot. Do a calibration again to clear this fault.
- ◆ Part of the sensor has been replaced and installed again. Do a calibration again to clear this fault.
- ◆ There are bad connections of the wire. Check the wire connections.
- ◆ Work piece do not have a good conduction with the shield of the amplifier. Check the wire to the earth and the wire on the amplifier shield.
- ◆ Parts of the laser spot are located on the capacity sensor and cause the temperature rising. Please check the optical path and the optical devices.

5.1.5 Crash Alarm

When the laser head has touched the metal work piece for a certain time, the crash alarm will be displayed on the displayer. If the laser head do not touch the metal sheet, there is still crash alarm displayed. There may be the following reasons:

- ◆ There is a short between the nozzle and the shield of the amplifier.
- ◆ The axial cable between the amplifier and the capacity sensor is damaged or the amplifier does not work.
- ◆ The capacity value of the sensor has been out of the detecting range of the distance controller.

5.1.6 Emergency Stop

When a low level signal is input to the emergency port, system will stop all the motion immediately. If the input is keep high level and there is still a emergency triggered, the following reasons may cause that.

- ◆ Wrong wiring.
- ◆ Machine electrical interference. Please check the wiring connection to the EARTH.

5.1.7 Too Large Following Error


There is big error between the referenced distance and the actual distance of the laser head. Please modify the filter factor parameters or increase the limit value.

5.1.8 Multiple Error


When there are several alarm triggered at the same time, the multi-alarm information will be displayed on the displayer. User can go to “Alarm info” to check the alarm information in detail.

Chapter 6 Installing

6.1 Size Of The Distance Controller



6.2 Size Of The Amplifier



Appendix: Trouble Shoots

FAULT	MAIN REASON	SOLVED
Manual moving up and down function failed	Wiring of DIR+、DIR-、PULSE+、PULSE-is not correct	Reference to the manual to ensure a right connection
	Parameters of Servo drive is not correct	Reference to the servo drive operating manual
	There is no serve on to the drive	Enable the servo drive internal or by external signal
	Connection between the distance controller and the displayer is not correct	Check the wiring
	Emergency trigger	Release the emergency input
“connect failure” on the displayer	Wrong connection between the displayer and the distance controller	Check the wiring
	The displayer do not match with the distance controller	Check the version of the distance controller
	Controller hardware port is damaged.	—
	Displayer hardware port is damaged	—
“touch screen not match” on the displayer	The firmware is not match with the displayer	Check the version of the distance controller
During calibration, the laser head moving down and no stop when touch the metal sheet.	Dross on the nozzle has caused the capacity changed a lot	Clear the nozzle
	Metal sheet do not have a good conduction with machine	Have a good conduction between the metal sheet and the machine
	Metal sheet have a plastic film	Clear the plastic film
During calibration , calibration failed is displayed.	During the calibration, “stop” is pressed	—
	When calibration, the laser head is too far away from the	When calibration, move the laser head close to the metal

	metal sheet	sheet.
	During the calibration, up limit or down limit triggered	Before calibration, check the position of the laser head. Move the laser head away from the limit
	There is no motion and cause a time out	Check the parameters of the servo drive and can run a jog motion
“write para” can not write the parameters into the distance controller	The laser head is in the running status	Stop motion and set laser head to be standby status
	wrong connection between the displayer and the distance controller	Check the wire and the interface
There is big error between the actual height and the referenced height	no calibration for a long time	Calibration again
	Has changed some parts of the sensor but do not do the calibration	Calibration again
	Some laser beam is located on the capacity sensor or the lens is dirty and make the sensor's temperature increasing	Check the lens is clean and the position of the laser beam
	Auxiliary gas has caused the capacity changing	Check the cleanliness and the humidity of the auxiliary gas
Laser head shaking during tracing	Shield of the amplifier do not have good conduction with the machine	Check the EARTH wire is connected well
	Filter factor parameter is not normal	Decrease the filter factor parameter and decrease the responsibility of the distance controller
	Before start a normal cutting. Calibration is not done or the calibration result is not so good	Calibration again
	Servo stiffness is too big	Decrease the stiffness
	Servo electrical interference	Check the shield of servo drive is connect to the EARTH

Thank you for your selection of our production!

All the copyright of this manual is owned by Ruida technology. Any person or company can not copy upload and send the manual without Ruida's permission.

Content will be revised or modified. We will not send message to every users.

If there are any question or suggestion about our products and manuals, please tells us.

Tel: (086)0755-26066687

Fax: (086)0755-26982287

Adress: 1B-1 buiding 5, Tian'an Nanyou industrial area,Dengliang road,Nanshan district, Shenzhen, Guangdong , China.

Website: www.rd-accs.com