

Getting started with the STMicroelectronics X-CUBE-BLE1 software package for STM32CubeMX

Introduction

This document provides the guidelines to configure and use the X-CUBE-BLE1 software package V4.4.0 for STM32CubeMX (minimum required version V5.2.0). The document contains a description of the provided sample applications, a description of the steps required to configure a generic project using the BLE middleware, as well as a description of the steps to configure and use the sample application provided in the package.

Information and documentation related to the ST BlueNRG-MS network processor, the X-NUCLEO-IDB05A1 expansion board and the X-CUBE-BLE1 expansion software for Bluetooth Low Energy are available on www.st.com.

Contents

Introduction	1
Contents.....	2
List of figures.....	3
1 Acronyms and abbreviations	4
2 What is STM32Cube?	5
3 License	5
4 Sample Applications Description	6
4.1 SensorDemo	6
4.2 SensorDemo_BLESensor-App.....	6
4.3 SampleApp	6
4.4 Beacon.....	7
4.5 VirtualCOMPort.....	7
5 Installing the X-CUBE-BLE1 pack in STM32CubeMX.....	7
6 Starting a new project	9
7 HCI_TL and HCI_TL_INTERFACE Configuration	11
8 STM32 Configuration Steps.....	12
8.1 Use of Expansion Software without sample applications	13
8.2 Use of Expansion Software with sample applications	17
9 Generated Folders Structure	22
10 Known Limitations and workarounds	23
9 References	24
10 Revision history	25

List of figures

Figure 1 Managing embedded software packs in STM32CubeMX	8
Figure 2 Installing the X-CUBE-BLE1 pack in STM32CubeMX	8
Figure 3 The X-CUBE-BLE1 pack in STM32CubeMX	9
Figure 4 STM32CubeMX main page.....	9
Figure 5 STM32CubeMX MCU/Board Selector windows	10
Figure 6 STM32CubeMX Configuration window.....	10
Figure 7 STM32CubeMX Additional Software Component Selection window	11
Figure 8 BlueNRG-MS software block scheme.....	11
Figure 9 STM32 Nucleo 64 pins and X-NUCLEO-IDB05A1.....	12
Figure 10 STM32 Nucleo 144 pins and X-NUCLEO-IDB05A1	13
Figure 11 X-NUCLEO-IDB05A1 pinout.....	13
Figure 12 Pinout view	14
Figure 13 STMicroelectronics.X-CUBE-BLE1 Mode and Configuration view	15
Figure 14 NVIC Mode and Configuration view.....	15
Figure 15 Advanced Settings	16
Figure 16 Project Manager view	16
Figure 17 Pinout view	17
Figure 18 STMicroelectronics.X-CUBE-BLE1 Mode and Configuration view	18
Figure 19 BLE Connection Parameter Settings	19
Figure 20 NVIC Mode and Configuration view.....	20
Figure 21 STM32CubeMX SPI Configuration.....	20
Figure 22 USART Configuration	21
Figure 23 Advanced Settings	22
Figure 24 Project Manager view	22
Figure 25 Application Structure.....	23

1 Acronyms and abbreviations

Table 1: list of acronyms

Acronym	Description
BLE	Bluetooth Low Energy
HAL	Hardware Abstraction Layer
HID	Human Interface Device
IOT	Internet Of Things
IP	Internet Protocol
LAN	Local Area Network
NVIC	Nested Vectored Interrupt Controller
PCB	Printed Circuit Board
RTC	Real Time Clock
RTOS	Real Time Operating System
SPI	Serial Peripheral Interface
UID	Unique Identifier
URL	Uniform Resource Locator
U(S)ART	Universal (Synchronous) Asynchronous Receiver Transmitter
USB	Universal Serial BUS
TCP	Transmission Control Protocol

2 What is STM32Cube?

STM32Cube™ represents an original initiative by STMicroelectronics to ease developers' life by reducing development effort, time and cost. STM32Cube covers the STM32 portfolio. Version 1.x of STM32Cube includes:

- STM32CubeMX, a graphical software configuration tool that allows the generation of C initialization code using graphical wizards.
- A comprehensive embedded software platform, delivered per series (such as the STM32CubeF4 for STM32F4 series).
 - STM32Cube HAL, an STM32 abstraction layer embedded software, ensuring maximized portability across the STM32 portfolio;
 - a consistent set of middleware components, such as RTOS, USB, TCP/IP, graphics;
 - all embedded software utilities, including a full set of examples.

3 License

The software provided in this package is licensed under [Software License Agreement SLA0077](#).

4 Sample Applications Description

In this section a short overview of the sample applications included in the X-CUBE-BLE1 pack is provided.

The sample applications:

- are ready-to-use projects that can be generated through the STM32CubeMX for any board equipped with an STM32 MCU and using the BlueNRG-MS chip;
- show the users how to use the BLE APIs, provided by the BlueNRG-MS middleware, for correctly initialize and use a BLE device.

4.1 SensorDemo

This sample application, that could be considered the BlueNRG-MS “Hello Word” application, shows how to use the BlueNRG-MS expansion board to send data from an STM32 Nucleo board to a BLE device such as a smartphone. In this example the stack composed by the STM32 and the BlueNRG-MS expansion boards act as Server-Peripheral, while the smartphone act as Client-Central. On the smartphone it is required to have installed and running the “BlueNRG” app, freely available on both [Play Store](#) and [iTunes](#).

After establishing the connection between the STM32 board and the smartphone:

- by pressing the USER button on the board, the cube showed by the app on the smartphone in the MOTION tab will rotate on the three axes (x,y,z);
- in the ENVIRONMENT tab of the app the temperature, pressure and humidity emulated values sent by the STM32 Nucleo to the smartphone are shown;
- in the OTHER tab of the app the RSSI value is shown.

4.2 SensorDemo_BLESensor-App

This sample application contains an example that shows how to implement the Sensor Demo application tailored for interacting with the "ST BLE Sensor" app for Android/iOS devices.

The "ST BLE Sensor" app is freely available on both [Play Store](#) and [iTunes](#).

The source code of the "ST BLE Sensor" app is also available on GitHub for both [iOS](#) and [Android](#) devices.

After establishing the connection between the STM32 board and the smartphone:

- the temperature and the pressure emulated values are sent by the STM32 board to the mobile device and are shown in the ENVIRONMENTAL tab;
- the emulated sensor fusion data sent by the STM32 board to the mobile device reflects into the cube rotation showed in the app's MEMS SENSOR FUSION tab
- the plot of the emulated data (temperature, pressure, sensor fusion data, accelerometer, gyroscope and magnetometer) sent by the board are shown in the PLOT DATA tab;
- in the RSSI & Battery tab the RSSI value is shown.

According to the value of the `#define USE_BUTTON` in file `app_x-cube-ble1.c`, the environmental and the motion data can be sent automatically (with 1 sec period) or when the User Button is pressed.

4.3 SampleApp

This sample application shows how to simply use the BLE Stack.

To test this application you need two STM32 Nucleo boards with their respective BlueNRG-MS STM32 expansion boards. One board needs to be configured as Server-Peripheral role, while the other needs to be configured as Client-Central role. Before flashing the boards, please make sure to use the right configuration by enabling/disabling the `#define SERVER_ROLE` in file `app_x-cube-ble1.c`.

Once the two STM32 Nucleo boards have been configured (one as Client and the other as Server) and flashed, the connection between the two boards establishes (when the LED2 on

the CLIENT turns off).

By pressing the USER button on one board, the LD2 LED on the other one gets toggled and viceversa.

If you have only one STM32 Nucleo board, you can program it as SERVER and use as CLIENT the [BLE IOT](#) app for Android devices.

4.4 Beacon

This example application shows how to use the BlueNRG Bluetooth Low Energy (BLE) expansion board to implement an Eddystone Beacon device.

An Eddystone Beacon is a smart Bluetooth Low Energy device that transmits a small data payload at regular intervals using Bluetooth advertising packets.

Beacons are used to mark important places and objects. Typically, a beacon is visible to a user's device from a range of a few meters, allowing for highly context-sensitive use cases.

[Eddystone](#) is an open beacon format from Google that works with Android and iOS.

Two different kinds of devices can be selected through `#define EDDYSTONE_BEACON_TYPE` in file `app_x-cube-ble1.c`:

- `EDDYSTONE_UID_BEACON_TYPE`: a UID beacon broadcasts a unique ID that provides proximity and general location information.
- `EDDYSTONE_URL_BEACON_TYPE`: a URL beacon broadcasts a packet containing an URL code usable by compatible applications.

To locate the beacon, it is necessary to have a scanner application running on a BLE-capable smartphone, such as one of the following ones for Android:

- [Physical Web](#)
- [iBeacon & Eddystone Scanner](#)
- [Beacon Radar](#)

An alternative is to use a *Physical Web* compatible browser like Google Chrome (version ≥ 44).

4.5 VirtualCOMPort

VirtualCOMPort is the application to be used for updating the BlueNRG-MS firmware on the X-NUCLEO-IDB05A1 expansion boards.

It must be used along with the flashUpdater java tool enclosed in the generated application folders at:

Middlewares\ST\BlueNRG-MS\Utilities\PC_Software\FirmwareUpdaterTool

The User can also use this sample application in order to port the BlueNRG-MS VCOM application to his specific BlueNRG-MS PCB (assuming that the customer PCB has a USB or RS232 I/O port available for PC connection).

This application provides an interface compliant with the Bluetooth Low Energy DTM test commands. Anyway, this application is not a reference application to be used for BlueNRG-MS application development and evaluation.

5 Installing the X-CUBE-BLE1 pack in STM32CubeMX

After downloading (from www.st.com), installing and launching the STM32CubeMX (V≥5.0.0), the X-CUBE-BLE1 pack can be installed in few steps.

1. From the top menu bar, select [Help](#) → [Manage](#) embedded software packages




Figure 1 Managing embedded software packs in STM32CubeMX

- From the Embedded Software Packages Manager window, press the **Refresh** button to get an updated list of the add-on packs. Go to the **STMicroelectronics** tab to find the X-CUBE-BLE1 pack.




Figure 2 Installing the X-CUBE-BLE1 pack in STM32CubeMX

- Select the X-CUBE-BLE1 pack checking the corresponding box and install it pressing the **Install Now** button. After accepting the license terms and once the installation is completed, the corresponding box will become green, the **Close** button can be pressed and the configuration of a new project can start.




Figure 3 The X-CUBE-BLE1 pack in STM32CubeMX

6 Starting a new project

After launching the STM32CubeMX, click either the [ACCESS TO MCU SELECTOR](#) or the [ACCESS TO BOARD SELECTOR](#) button in the GUI to start a project for your MCU or board.




Figure 4 STM32CubeMX main page

The [MCU/Board selector](#) window will pop up. From this window, the STM32 MCU or Board can be selected.




Figure 5 STM32CubeMX MCU/Board Selector windows

After selecting the MCU or the Board, the selected STM32 pinout will appear (the user can either choose to Initialize all peripherals with their default Mode or not). From this window the user can set up the project, by adding one or more Additional Software and peripherals and configuring the clock.




Figure 6 STM32CubeMX Configuration window

To add the X-CUBE-BLE1 additional software to the project, the button **Additional Softwares** must be clicked.

From the Additional Software Component Selection window, the user can either chose to generate, for the selected MCU/Board, one of the enclosed sample applications or a new project. In this latter case, the user must just implement the main application logic without bothering with the pinout and peripherals configuration code that will be automatically generated by STM32CubeMX.




Figure 7 STM32CubeMX Additional Software Component Selection window

7 HCI_TL and HCI_TL_INTERFACE Configuration

The HCI_TL (Host Controller Interface Transport Layer) and the HCI_TL_INTERFACE (Host Controller Interface Transport Layer Interface) are the interfaces between the HAL/BSP layer and both the Middleware Core Layer and the Application Layer.




Figure 8 BlueNRG-MS software block scheme

Two different configurations may be used for both the components.

- HCI_TL
 - *Basic* the user can use a basic set of already implemented APIs
 - *Template* the user can implement his own APIs for building his own customized HCI TL
- HCI_TL_INTERFACE
 - *UserBoard* the user can use a basic set of already implemented APIs
 - *Template* the user can implement his own APIs for building his own customized HCI TL Interface.

For generating a ready to work sample application, the *Basic* and *UserBoard* configurations must be selected.

8 STM32 Configuration Steps

The X-NUCLEO-IDB05A1 interfaces with the STM32 microcontroller via the SPI pin. Hence, assuming a user wants to interface the ST X-NUCLEO-IDB05A1 expansion board with a STM32 Nucleo 64 pins board (e.g. a Nucleo-F401RETx) or a STM32 Nucleo 144 pins board (e.g. a Nucleo F429ZITx), the following steps must be executed in STM32CubeMX before generating a project.



Figure 9 STM32 Nucleo 64 pins and X-NUCLEO-IDB05A1

If a Nucleo 144 pins is used, to correctly set the SPI clock on pin D13, the D3 pin and the D13 pin of the Arduino connector on the X-NUCLEO-IDB05A1 expansion board must be bridged (alternatively the resistor R9 must be open and a 0 Ohm resistor must be soldered on R6).




Figure 10 STM32 Nucleo 144 pins and X-NUCLEO-IDB05A1




Figure 11 X-NUCLEO-IDB05A1 pinout

8.1 Use of Expansion Software without sample applications

This section outlines how to configure STM32CubeMX when the use of the sample

applications is not required. With such setup, only middleware and driver layers will be configured. This setup is useful when the user does not intend to leverage the sample application provided in the package.

From the **Pinout & Configuration** tab:

- from the **Pinout view**, if PB3 pin is already assigned, click on it and reset its state;
- from the **Pinout → Clear Pinouts** menu option reset the state of all pins (only for Nucleo 144);
- from the **Connectivity >** menu:
 - check that the ETH is disabled (only for Nucleo 144);
 - enable the SPI1 in Full-Duplex Master Mode;
 - if not enabled yet, enable the USART2 in Asynchronous mode (for Nucleo 64)
 - if not enabled yet, enable the USART3 in Asynchronous mode (for Nucleo 144).

From the **Pinout view** set:

Nucleo 64		Nucleo 144	
PA0	GPIO_EXTIO	PA3	GPIO_EXTI3
PA1	GPIO_Output	PC0	GPIO_Output
PA8	GPIO_Output	PF13	GPIO_Output




Figure 12 Pinout view

From the **Additional Software >** menu, click on the **STMicroelectronics.X-CUBE-BLE1.x.y.z** pack. Check the **Wireless BlueNRG-MS** box and set the following **Platform Settings**:

Name	IPs or Components	Found solutions		BSP Api
		Nucleo 64	Nucleo 144	
Exti Line	GPIO:EXTI	PA0	PA3	HAL_EXTI_DRIVER
BUS IO driver	SPI:Full-Duplex Master	SPI1	SPI1	BSP_BUS_DRIVER
CS Line	GPIO:Output	PA1	PC0	Unknown
Reset Line	GPIO:Output	PA8	PF13	Unknown




Figure 13 STMicroelectronics.X-CUBE-BLE1 Mode and Configuration view

From the [System view](#), click on [NVIC](#) button under [System Core](#) category to enable the EXTI line interrupt:

Nucleo 64	Nucleo 144
EXTI line 0 interrupt	EXTI line 3 interrupt




Figure 14 NVIC Mode and Configuration view

From the [System view](#), click on [SPIx](#) button under [Connectivity](#) category and:

- check that the Data size is 8 Bits;
- set the Prescaler (for Baud Rate) to a value so that the HClock/Prescaler is less or equal


to 8MHz (the maximum supported SPI speed)

From the [System view](#), click on [USARTx](#) button under Connectivity category and check that:

- Baud Rate is 115200 Bits/s;
- Word Length is 8 Bits (including Parity)
- Parity is None
- Stop Bits is 1

Once all the above described steps have been performed, from the [Project Manager](#) tab the Project Name, the Project Location, the Toolchain/IDE, the Firmware Package Name and Version and so on can be set.

Hence, after checking that in the [Advanced Settings](#) tab the following options are set



Rank	Function Name	IP Instance Name	<input type="checkbox"/> Not Generate Function Call	<input type="checkbox"/> Visibility (Static)
1	MX_GPIO_Init	SPIO	<input type="checkbox"/>	<input type="checkbox"/>
2	SystemClock_Config	RCC	<input type="checkbox"/>	<input type="checkbox"/>
3	MX_USART2_UART_Init	USART2	<input type="checkbox"/>	<input checked="" type="checkbox"/>
4	MX_SPI1_Init	SPI1	<input type="checkbox"/>	<input checked="" type="checkbox"/>
5	MX_X_CUBE_BLE1_Init	STMicroelectronics.X-CUBE-BLE1.1.1.0	<input type="checkbox"/>	<input checked="" type="checkbox"/>
6	MX_X_CUBE_BLE1_Process	STMicroelectronics.X-CUBE-BLE1.1.1.0	<input type="checkbox"/>	<input checked="" type="checkbox"/>

Figure 15 Advanced Settings

the source code of the project using the **STMicroelectronics X-CUBE-BLE1** software can be generated clicking the [GENERATE CODE](#) button.




Figure 16 Project Manager view

8.2 Use of Expansion Software with sample applications

This section outlines how to configure STM32CubeMX when the use of the sample applications is required. With such setup, all the components of the expansion software package, including applications, will be properly configured.

From the [Pinout & Configuration](#) tab:

- from the [Pinout view](#), if PB3 pin is already assigned, click on it and reset its state;
- from the [v Pinout](#) → [Clear Pinouts](#) menu option reset the state of all pins (only for Nucleo 144);
- from the [Connectivity >](#) menu:
 - check that the ETH is disabled (only for Nucleo 144);
 - enable the SPI1 in Full-Duplex Master Mode;
 - if not enabled yet, enable the USART2 in Asynchronous mode (for Nucleo 64)
 - if not enabled yet, enable the USART3 in Asynchronous mode (for Nucleo 144).

From the [Pinout view](#) set:

Nucleo 64			Nucleo 144		
<i>PIN</i>	<i>Mode</i>	<i>Label</i>	<i>PIN</i>	<i>Mode</i>	<i>Label</i>
PA0	GPIO_EXTI0		PA3	GPIO_EXTI3	
PA1	GPIO_Output		PC0	GPIO_Output	
PA8	GPIO_Output		PF13	GPIO_Output	
PA2	USART2_TX	USART_TX	PD8	USART3_TX	USART_TX
PA3	USART2_RX	USART_RX	PD9	USART3_RX	USART_RX
PA5	GPIO_Output	LD2 [Green Led]	PB7	GPIO_Output	LD2[Blue]
PC13	GPIO_EXTI13	B1 [Blue PushButton]	PC13	GPIO_EXTI13	USER_Btn[B1]

Pins in the green rows are used only by the SensorDemo, SensorDemo_BLESensor-App and SampleApp sample applications.




Figure 17 Pinout view

From the [Additional Software >](#) menu, click on the STMicorelectronics.X-CUBE-BLE1.x.y.z pack. Check the Wireless BlueNRG-MS box and set the following [Platform Settings](#):

Name	Supported IPs	Found solutions		BSP Api
		Nucleo 64	Nucleo 144	
BUS IO driver	SPI:Full-Duplex Master	SPI1	SPI1	BSP_BUS_DRIVER
Exti Line	GPIO:EXTI	PA0	PA3	HAL_EXTI_DRIVER
CS Line	GPIO:Output	PA1	PC0	Unknown
Reset Line	GPIO:Output	PA8	PF13	Unknown
BSP LED	GPIO:Output	PA5	PB7	BSP_COMMON_DRIVER
BSP BUTTON	GPIO:EXTI	PC13	PC13	BSP_COMMON_DRIVER
BSP USART	USART:Asynchronous	USART2	USART3	BSP_COMMON_DRIVER

Pins in the green rows are used only by the SensorDemo, SensorDemo_BLESensor-App and SampleApp sample applications.




Figure 18 STMicorelectronics.X-CUBE-BLE1 Mode and Configuration view

From the [Parameter Settings](#) tab, some parameters for the data logging, the debugging and for the BLE scanning, advertising and connection can be set.

For all the sample applications, a part from the Beacon one, the default parameters can be used.

For the Beacon sample application the Advertising Type and the Minimum and Maximum Advertising Intervals must be set as in the following table:

Beacon Sample Application	
Advertising Type (ADV_DATA_TYPE)	Non Connectable Undirected Advertising (ADV_NONCONN_IND)
Minimum Advertising Interval (ADV_INTERV_MIN)	1600

Beacon Sample Application

Maximum Advertising Interval (ADV_INTERV_MAX)	1600
---	------




Figure 19 BLE Connection Parameter Settings

From the **Configuration** tab, click on NVIC button under System to enable the EXTI line interrupts for both the SPI IRQ and the User Button (when used):

Name	Nucleo 64	Nucleo 144
Exti Line	EXTI line 0 interrupt	EXTI line 3 interrupt
BSP BUTTON	EXTI line 13 interrupt	EXTI line 13 interrupt

EXTI line interrupt in the green row must be enabled only for the SensorDemo, SensorDemo_BLESensor-App and SampleApp sample applications.




Figure 20 NVIC Mode and Configuration view

From the **System view**, click on **SPIx** button under **Connectivity** category and:

- check that the Data size is 8 Bits;
- set the Prescaler (for Baud Rate) to a value so that the HClock/Prescaler is less or equal to 8MHz (the maximum supported SPI speed).




Figure 21 STM32CubeMX SPI Configuration

From the **System view**, click on **USARTx** button under **Connectivity** category and check that the following configuration is set:

Baud Rate	115200 Bits/s
Word Length	8 Bits (including Parity)
Parity	None
Stop Bits	1

Also, from the [GPIO Settings](#) tab, be sure the USART_TX and USART_RX labels are set.




Figure 22 USART Configuration

Once all the above described steps have been performed, from the [Project Manager](#) tab the Project Name, the Project Location, the Toolchain/IDE, the Firmware Package Name and Version and so on can be set.

Hence, after checking that in the [Advanced Settings](#) tab the following options are set

Advanced Settings	Generated Function Calls					
	Rank	Function Name	IP Instance Name	<input type="checkbox"/> Not Generate Function Call	<input type="checkbox"/> Visibility (Static)	
	1	MX_GPIO_Init	GPIO	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
	2	SystemClock_Config	RCC	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
	3	MX_USART2_UART_Init	USART2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
	4	MX_SPI1_Init	SPI1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
	5	MX_X_CUBE_BLE1_Init	STMicroelectronics.X-CUBE-BLE1.1.1.0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
	6	MX_X_CUBE_BLE1_Process	STMicroelectronics.X-CUBE-BLE1.1.1.0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	

Figure 23 Advanced Settings

the source code of the project using the **STMicroelectronics X-CUBE-BLE1** software can be generated clicking the **GENERATE CODE** button.




Figure 24 Project Manager view

9 Generated Folders Structure

When generating a project, two models of folders structure can be adopted when using a high level firmware component (i.e. a middleware in the STM32Cube MCU package):

- **Basic Structure:** the basic structure is often used with HAL examples and single middleware projects. This structure consists of having the IDE configuration folder in the same level as the sources (organized in *Inc* and *Src* subfolders).
- **Advanced Structure:** the advanced structure provides a more efficient and organized folders model that allows ease middleware applications integration when several middlewares are used.

In the Advanced mode *Src* and *Inc* are generated under folder *Core*.

For each middleware, the list of the generated files is under *<MW_Name>* (*X-CUBE-BLE1* for the X-CUBE-BLE1 pack), at the same level as *Core* and either in *App* or in *Target* subfolder.




Figure 25 Application Structure

10 Known Limitations and workarounds

- For sample applications using any low power feature, such as **Beacon**, the ST-Link reset must be set in *Connect during reset* mode into the generated project configuration options.
- The Virtual_COM_Port sample application must be used with the following configuration for the HCI Transport Layer (HCI_TL) and the HCI Transport Layer Interface (HCI_TL_INTERFACE):
 - HCI_TL → Basic
 - HCI_TL_INTERFACE → UserBoard
 Other configurations using the template files are not supported yet.
- No support to **Low Level (LL) Driver** is provided yet for the SPI interface used by the BlueNRG-MS chip.

9 References

- [1] [UM1873](#) – User Manual - *Getting started with the X-CUBE-BLE1 Bluetooth Low Energy software expansion for STM32Cube* (see section 3.4 "Guide for writing applications")
- [2] [AN4642](#) – Application Notes – *Overview of the BLE Profiles application for X-CUBE-BLE1, expansion for STM32Cube*
- [3] [AN4979](#) – Application Notes – *Bluetooth Low Energy beacons with Eddystone*

10 Revision history

Table 2: Document revision history

Date	Version	Changes
15-Dec-2017	1	Initial release
25-Jun-2018	2	Add pack installation instructions
		Add HCI_TL and HCI_TL_INTERFACE configuration description
31-Aug-2018	3	Update pictures
12-Oct-2018	4	Add SensorDemo_BlueMS-App sample application description
13-Nov-2018	5	Align screenshots to STM32CubeMX v5.0.0 GUI
18-Feb-2019	6	Align to BlueNRG-MS pack v4.3.0

IMPORTANT NOTICE – PLEASE READ CAREFULLY

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2017 STMicroelectronics – All rights reserved