

How-To Guide: Epson P5000 Photo Printer



Preparing the Printer

1. If you haven't done so already, please **reserve the workstation** on BookIt

1. Login to BookIt using your JHED and myJHU password.
2. Click "Book by Category" > "Spaces & Workstations".
3. Add the "Mac & Epson P5000 Photo Printer (IM01)" to your cart.
4. Reserve the equipment for your expected duration of use.

- If this is your **first time** using this printer, we recommend at least 1-hour for your booking.

bookit.dmc.jhu.edu



2. **Check in** at the front desk to let them know about your reservation

3. **Login** into the iMac Workstation connected to the printer

- Login using your JHED and myJHU password.
- You may skip any account setup prompts.

4. Ensure the printer is **turned on**

- If the screen is not on, press the grey power button.

5. Ensure the paper type is set to **sheet**, not roll

- This is indicated by the **paper icon**.
- If it is not sheet, press the left-arrow button to switch.

6. Ensure the correct **black-ink type**

- You must first decide on the type of paper to use.
- To switch the ink type, press the very **bottom-left button**.



Glossy & Luster:
Photo Black

Matte:
Matte Black



You must first prepare your images using **Adobe Photoshop**
Refer to the supplemental Photoshop How-To Guide for assistance

Print Settings

1. Press **⌘ + P** or click "File">"Print"

2. Select printer "**SC-P5000Series-FCD981 (IP)**"

3. Select the **orientation** of your image

- Verify this is correct by using the **print preview**.
- **Note:** paper must still be loaded vertically; this setting just rotates the final image on the paper.

4. Set "Color Handling" to "**Photoshop Manages Colors**"

5. Select the "**Printer Profile**" depending on your paper type:


Glossy: SC-P5000_Series_V_PremiumGlossyPhotoPaper

Luster: SC-P5000_Series_V_PremiumLusterPhotoPaper

Matte: SC-P5000_Series_V_EnhancedMattePaper_MK

6. Click "**Print Settings**"

Continued on next page



Print Settings Continued

7. Set “Presets” to “**Default Settings**”

- If you cannot see these settings, click “Show Details”.

8. Select correct “**Paper Size**”

Note: Make sure to match the name below exactly

8.5” x 11”: US Letter (Sheet, Borders - Maximum)


11” x 17”: US B 11x17 (Sheet, Borders - Maximum)

17” x 22”: US C 17x22 (Sheet, Borders - Maximum)

13” x 19” or other: Manage custom sizes. Enter paper dimensions and set “Margins” to “User-Defined” with 0.5 for all four sides.

9. Change dropdown to “**Printer Options**”

10. Select info button next to “**Printer Settings**”



11. Set “Paper Source” to “**Manual Feed**”

12. Set “**Media Type**” to match paper type

Note: Make sure to match the name below exactly

Glossy: Photo Paper > “Premium Photo Paper Glossy”

Luster: Photo Paper > “Premium Photo Paper Luster”

Matte: Matte Paper > “Ultra Premium Presentation Paper Matte”

13. Ensure “**Ink**” is correct for paper type


Glossy & Luster: Photo Black

Matte: Matte Black

14. Ensure “Output Resolution” is set to “**SuperPhoto-1440 dpi**”

15. Click “**OK**”

16. Click “**Save**”



Loading the Paper

1. Obtain photo paper from the front desk staff

- Note: you won't need to pay for these until you are finished.
- You may also bring in your **own** paper and only pay for ink.

2. Determine which paper side is the **printable side**

- Luster and glossy paper will be shiny on the printable side.
- Matte paper will be whiter on the printable side.
- Feel free to ask the staffer on duty for help!

3. Slide the **grey paper guide** to the **very left**



4. Printable side facing towards you, **insert the paper** vertically along the right edge until it meets resistance halfway

5. Align the **paper guide** with the paper

6. Ensure the paper is as **straight** as possible

7. Press the **down button** to load the paper

- The screen should display "**Ready**".
- If an error occurs, try reloading the paper.
- If an error persists, ask a staff member for help.



Print & Finish

1. Click "**Print**" in Photoshop in the Printer Setup menu



2. Initially look through the top printer window to

3. **ensure everything is printing correctly**

4. **Be careful of wet ink** and fingerprints when handling finished prints

5. You can **trim** your print using one the DMC's small or large paper cutters

- Ask for assistance if this is your first time using the paper cutter.



Pay and Checkout



Add J-Cash

1. Ensure you have **enough J-Cash** to pay for all your prints

- The DMC only accepts J-Cash.
- Reload J-Cash using the e-accounts app or in-browser by scanning the QR code.

2. Tell the staff at the **front desk** that you would like to pay now

- Inform them of the type, size, and amount of paper you used.

3. If you are finished using the printer, let the staffer know that you are done and would like to **checkout**

4. Remember to **log out** of the computer and to **take all your things**