

# Awesomizing P2DX Manual Deliverable 2

Wadie Assal	Jeroen Rooijmans	Jasper Timmer
6398693	5887410	5995140

Maarten de Waard	Maarten Inja (vz)
5894883	5872464

June 25, 2011

## 1 Intro

This manual is part of deliverable 2 of the Awesomizing P2DX team. Status of the project: far behind. What is in this release: Coordinator translates USAR messages to AP2DX messages, sends them to the sensor module that creates a visualisation window of the sensor data. Planner sends a drive message to the reflex, that sends it to the motor, coordinator and finally the simulator. If the sensordata shows that something is too close, the robot stops moving (reflex does this based on sensor data).

## 2 Requirements

To Run AP2DX Software you need Java Runtime Enviroment 1.6.

## 3 How to run

To start the AP2DX Software, you first need to run an USARsim Server. Then change the `sim_address` and `sim_port` in the folder `/jar/coordinator/AP2DX.coordinator.json` to your setup. On windows, start all components with `start_all.bat`, or start the components by starting `start.bat` on windows or `start.sh` on linux in this order:

- Coordinator
- Motor
- Reflex
- Planner
- Mapper
- Sensor