

This is a supplement document and is to be used in conjunction with the Jost standard maintenance instructions (LT-SK37U-03) for all Low Lube Fifth Wheels. Be sure to follow the maintenance instructions provided with your Owner's Manual included with the Standard Fifth Wheel.



- 1. FAILURE TO FOLLOW THESE INSTRUCTIONS COULD CAUSE A HAZARDOUS CONDITION!**
- 2. PERFORM ALL MAINTENANCE WITH TRACTOR UNCOUPLED FROM TRAILER.**
- 3. ALL PROCEDURES MUST BE PERFORMED BY QUALIFIED PERSONNEL.**
- 4. DO NOT USE ANY FIFTH WHEEL THAT FAILS TO OPERATE PROPERLY!**

**A. NEW PRODUCT BREAK IN LUBRICATION:**

Apply a light coating of a lithium-based grease with EP additive (extreme pressure) to the low lube liner plates. The low lube plates require No further lubrication.

**B. INSPECTIONS AND ADJUSTMENTS:**

(Perform the following every 3 months or 30,000 miles)

1. Inspect the low lube plates and replace if damaged or when the plate wears down to the securing bolts. It is normal for the outside edges of the plate to pucker slightly. This will not affect their performance.

**C. LUBE PLATE REPLACEMENT PROCEDURES (using kit SK3106-003):**

1. Remove the securing bolts. If the bolts take a 6mm hex, remove the jam nuts below the topplate first. If the bolts take a T45 torques, just spin off.
2. Remove the plates and clean any debris from the Low Lube pockets of the topplate.
3. Install the new plates.
4. Install the T45 torques securing bolts and tighten to 34 FT-LBS.

For complete parts list and replacement kit order numbers refer to the Owner's Manual provided with your fifth wheel.

or

Contact our sales department at:  
**800-253-5105**