

Overview

Platform

RVC

Features

Depth

Deployment

PoE deployment guide

USB deployment guide

Getting started with FFC

Deploy with Raspberry Pi

Deploy with NVIDIA's Jetson

Deploy with RockPi

Integrating DepthAI into products

End of Life (EOL) Policy

Frame synchronization

Connectors M8, M12

Camera Sensors

Environmental Specifications

Comparisons



Deploy with NVIDIA's Jetson

Connecting OAK devices to NVIDIA Jetson SBCs unleashes powerful edge AI capabilities. To install the DepthAI library on a Jetson device, follow the steps to install dependencies and the library itself through `pip`. DepthAI provides **prebuilt wheels** for Jetson on [PyPi](#).



Installing DepthAI on Jetson

To install DepthAI on [Jetson Nano](#) or [Jetson Xavier](#), perform the following steps, after completing a fresh

ON THIS PAGE

Deploy with NVIDIA's Jetson

Installing DepthAI on Jetson

apt update/upgrade

SWAP size

Dependencies

venv

DepthAI repo

.bashrc

Powering OAK from Jetson

Interface Options

