

Manual Transmission Component Location Index**TRANSMISSION**[Removal and Installation](#)[Disassembly and Reassembly](#)[Transmission Fluid Inspection and Replacement](#)**GEARSHIFT MECHANISM**[Removal and Installation](#)**NEUTRAL POSITION SENSOR**[Removal and Installation](#)**BACK-UP LIGHT SWITCH**[Test](#)[Removal and Installation](#)**MTF COOLER**[Removal and Installation](#)**MTF COOLER HOSE**[Removal and Installation](#)

