



DTC		Detection Item
B0050	-F0	Driver's Seat Belt Buckle Switch Malfunction
C0010	-49	Inlet Solenoid (Left Front) Circuit Failure
C0011	-49	Outlet Solenoid (Left Front) Circuit Failure
C0014	-49	Inlet Solenoid (Right Front) Circuit Failure
C0015	-49	Outlet Solenoid (Right Front) Circuit Failure
C0018	-49	Inlet Solenoid (Left Rear) Circuit Failure
C0019	-49	Outlet Solenoid (Left Rear) Circuit Failure
C001C	-49	Inlet Solenoid (Right Rear) Circuit Failure
C001D	-49	Outlet Solenoid (Right Rear) Circuit Failure
C0023	-12	Brake Diag Circuit ON Failure
	-14	Brake Diag Circuit OFF Failure
C0030	-38	Magnetic Encoder (Left Front) Failure (Pulse Missing)
C0031	-14	Left Front Wheel Speed Sensor Circuit Failure (Circuit Short To Ground or Open)
	-62	Left Front Wheel Speed Sensor Signal Compare Failure
C0033	-38	Magnetic Encoder (Right Front) Failure (Pulse Missing)
C0034	-14	Right Front Wheel Speed Sensor Circuit Failure (Circuit Short To Ground or Open)
	-62	Right Front Wheel Speed Sensor Signal Compare Failure
C0036	-38	Magnetic Encoder (Left Rear) Failure (Pulse Missing)
C0037	-14	Left Rear Wheel Speed Sensor Circuit Failure (Circuit Short To Ground or Open)
	-62	Left Rear Wheel Speed Sensor Signal Compare Failure
C0039	-38	Magnetic Encoder (Right Rear) Failure (Pulse Missing)
C003A	-14	Right Rear Wheel Speed Sensor Circuit Failure (Circuit Short To Ground or Open)
	-62	Right Rear Wheel Speed Sensor Signal Compare Failure
C0040	-62	Brake Lamp Switch Failure (Stuck)
C0044	-49	Master Cylinder Pressure Sensor Failure (Internal Circuit Failure)
C0049	-7B	Brake Fluid Level Too Low
C0051	-54	Steering Angle Neutral Position Learning Incomplete
	-62	Steering Angle Sensor Failure (Signal Compare Failure)
	-96	Steering Angle Sensor Failure (Sensor Detects Internal Failure)
C0061	-62	Lateral Acceleration Sensor Failure (Signal Compare Failure)
	-F0	Lateral Acceleration Sensor Malfunction
C0062	-62	Longitudinal Acceleration Sensor Failure (Signal Compare Failure)
	-F0	Longitudinal Acceleration Sensor Malfunction
C0063	-62	Yaw Rate Sensor Failure (Signal Compare Failure)
	-97	SRS Sensor Unit Supply Voltage Abnormally
	-F0	Yaw Rate Sensor Malfunction
C0072	-00	Brake Pad Temperature too High
C1000	-94	ABS/VSA Activation Time Too Long
C1014	1C	Left Front Brake Caliper Pressure Sensor Failure (Internal Circuit Failure)
C1015	1C	Right Front Brake Caliper Pressure Sensor Failure (Internal Circuit Failure)
C1020	-49	VSA Master Cut Valve Failure (Unexpected Operation)
C1021	-49	VSA Suction Valve Failure (Unexpected Operation)
C1022	-14	Power Source Failure for Pump Motor
C1100	-48	Electric Parking Brake Abnormal Operation Monitoring
	-53	Electric Parking Brake System in Maintenance Mode
	-54	Piston Position Not Learned
	-92	Decelerating Abnormally Detection
	-94	Brake Fluid Leakage
	-98	Electric Parking Brake Continuous Operations Detected
C1110	-11	Left Rear Electric Parking Brake Actuator Circuit Short to Ground
	-13	Left Rear Electric Parking Brake Actuator Circuit Open
	-79	Left Side Electric Parking Brake Doesn't Work Correctly
	-96	Left Side Electric Parking Brake Actuator Malfunction
C1111	-11	Right Rear Electric Parking Brake Actuator Circuit Short to Ground
	-13	Right Rear Electric Parking Brake Actuator Circuit Open
	-79	Right Side Electric Parking Brake Doesn't Work Correctly