

Electronic Wiring Diagram

 in.honda.com/RJANISIS/pubs/sm/1/2/Contents/ewd/app/ewd.htm

Fuse No.	Ampere	Schematic	Fuse/Relay Box Location
A1-1	60A	Adaptive Damper System (A1-1)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Under-Hood Fuse/Relay Box (A1-1)	
A1-3	30A	Climate Control (A1-3)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Fans (A1-3)	
		Under-Hood Fuse/Relay Box (A1-3)	
A1-4	30A	Navigation System (A1-4)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Telematics/HandsFreeLink System (A1-4)	
		Under-Hood Fuse/Relay Box (A1-4)	
A1-5	30A	Adaptive Damper System (A1-5)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Brake Lights (A1-5)	
		Charging System (A1-5)	
		Climate Control (A1-5)	
		Cruise Control (A1-5)	
		Energy Management System (A1-5)	
		Entry Light Control System and Ignition Key Light (A1-5)	
		EPS (A1-5)	
		Fans (A1-5)	
		Gauges (A1-5)	
		Idle Control System (A1-5)	
		Keyless Access System (A1-5)	
		Keyless/Power Door Locks/Security System (A1-5)	
		Low Oil Pressure Indicator, Reminder Systems, Safety Indicator (A1-5)	
		MIL Circuit (A1-5)	
		Navigation System (A1-5)	
		PCM (All) (A1-5)	
		Power Mirrors (A1-5)	
		Power Supply (A1-5)	
		Power Windows (A1-5)	
		Power, Grounds and Diagnostics (A1-5)	
		Rear Window/Power Mirror Defoggers (A1-5)	
		SRS (A1-5)	
		Telematics/HandsFreeLink System (A1-5)	
		Under-Hood Fuse/Relay Box (A1-5)	
		VSA/TPMS (Tire Pressure Monitoring System) (A1-5)	
		Wiper/Washer (Rear Window) (A1-5)	
		Wiper/Washer (Windshield) (A1-5)	
A1-6	30A	Headlights (A1-6)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Power, Grounds and Diagnostics (A1-6)	
		Under-Hood Fuse/Relay Box (A1-6)	

Fuse No.	Ampere	Schematic	Fuse/Relay Box Location
A1-7	125A	Ambient Lights, Cargo Area Lights, Ceiling Lights, Console Lights, Courtesy Lights, Footwell Lights, Glove Box Lights, Individual MAP Lights, Trunk Lights and Vanity Mirror Lights (A1-7)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Cable Reel (A1-7)	
		Charging System (A1-7)	
		Climate Control (A1-7)	
		Cruise Control (A1-7)	
		Dashlights (A1-7)	
		DLC (A1-7)	
		Energy Management System (A1-7)	
		Entry Light Control System and Ignition Key Light (A1-7)	
		Fog Lights (A1-7)	
		Gauges (A1-7)	
		Headlights (A1-7)	
		Horns (A1-7)	
		Idle Control System (A1-7)	
		Keyless Access System (A1-7)	
		Keyless/Power Door Locks/Security System (A1-7)	
		License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights (A1-7)	
		Low Oil Pressure Indicator, Reminder Systems, Safety Indicator (A1-7)	
		MIL Circuit (A1-7)	
		Navigation System (A1-7)	
		PCM (All) (A1-7)	
		Power Mirrors (A1-7)	
		Power Windows (A1-7)	
		Power, Grounds and Diagnostics (A1-7)	
		Rear Window/Power Mirror Defoggers (A1-7)	
		SRS (A1-7)	
		Starting System (A1-7)	
		Telematics/HandsFreeLink System (A1-7)	
		Under-Hood Fuse/Relay Box (A1-7)	
		VSA/TPMS (Tire Pressure Monitoring System) (A1-7)	
		Wiper/Washer (Rear Window) (A1-7)	
		Wiper/Washer (Windshield) (A1-7)	
A2-1	70A	EPS (A2-1)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Under-Hood Fuse/Relay Box (A2-1)	
A2-2	30A	Accessory Power Sockets (A2-2)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Ambient Lights, Cargo Area Lights, Ceiling Lights, Console Lights, Courtesy Lights, Footwell Lights, Glove Box Lights, Individual MAP Lights, Trunk Lights and Vanity Mirror Lights (A2-2)	
		Back-Up Lights (A2-2)	
		Brake Lights (A2-2)	
		Charging System (A2-2)	
		Cruise Control (A2-2)	
		Dashlights (A2-2)	
		Energy Management System (A2-2)	

Fuse No.	Ampere	Schematic	Fuse/Relay Box Location
		Entry Light Control System and Ignition Key Light (A2-2)	
		EPS (A2-2)	
		Fog Lights (A2-2)	
		Fuel Supply System (A2-2)	
		Gauges (A2-2)	
		Headlights (A2-2)	
		Idle Control System (A2-2)	
		Keyless Access System (A2-2)	
		Keyless/Power Door Locks/Security System (A2-2)	
		License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights (A2-2)	
		Low Oil Pressure Indicator, Reminder Systems, Safety Indicator (A2-2)	
		MIL Circuit (A2-2)	
		Navigation System (A2-2)	
		PCM (All) (A2-2)	
		PGM-FI System (A2-2)	
		Power Mirrors (A2-2)	
		Power Supply (A2-2)	
		Power Windows (A2-2)	
		Power, Grounds and Diagnostics (A2-2)	
		Rear Window/Power Mirror Defoggers (A2-2)	
		Reverse Lockout System (A2-2)	
		SRS (A2-2)	
		Starting System (A2-2)	
		Telematics/HandsFreeLink System (A2-2)	
		Under-Hood Fuse/Relay Box (A2-2)	
		VSA/TPMS (Tire Pressure Monitoring System) (A2-2)	
		Wiper/Washer (Rear Window) (A2-2)	
		Wiper/Washer (Windshield) (A2-2)	
A2-4	60A	Accessory Power Sockets (A2-4)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Keyless Access System (A2-4)	
		Keyless/Power Door Locks/Security System (A2-4)	
		Power Mirrors (A2-4)	
		Power Windows (A2-4)	
		Power, Grounds and Diagnostics (A2-4)	
		Rear Window/Power Mirror Defoggers (A2-4)	
		Starting System (A2-4)	
		Under-Hood Fuse/Relay Box (A2-4)	
A2-5	30A	Under-Hood Fuse/Relay Box (A2-5)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Wiper/Washer (Windshield) (A2-5)	
A2-6	30A	Headlights (A2-6)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Keyless/Power Door Locks/Security System (A2-6)	
		Under-Hood Fuse/Relay Box (A2-6)	

Fuse No.	Ampere	Schematic	Fuse/Relay Box Location
A3-1	40A	Climate Control (A3-1)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Under-Hood Fuse/Relay Box (A3-1)	
A3-2	40A	Under-Hood Fuse/Relay Box (A3-2)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		VSA/TPMS (Tire Pressure Monitoring System) (A3-2)	
A3-3	40A	Under-Hood Fuse/Relay Box (A3-3)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		VSA/TPMS (Tire Pressure Monitoring System) (A3-3)	
A3-4	40A	Cable Reel (A3-4)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Dashlights (A3-4)	
		Gauges (A3-4)	
		Navigation System (A3-4)	
		Telematics/HandsFreeLink System (A3-4)	
		Under-Hood Fuse/Relay Box (A3-4)	
A3-5	30A	PCM (All) (A3-5)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Starting System (A3-5)	
		Under-Hood Fuse/Relay Box (A3-5)	
A3-6	40A	Rear Window/Power Mirror Defoggers (A3-6)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Under-Hood Fuse/Relay Box (A3-6)	
A6	15A	Under-Hood Fuse/Relay Box (A6)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Wiper/Washer (Rear Window) (A6)	
		Wiper/Washer (Windshield) (A6)	
A7	15A	ETCS (Electronic Throttle Control System) (A7)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Fuel Supply System (A7)	
		Ignition System (A7)	
		PCM (All) (A7)	
		PCM Power and Ground (A7)	
		PGM-FI System (A7)	
		Under-Hood Fuse/Relay Box (A7)	
A8	10A	Brake Lights (A8)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Cruise Control (A8)	
		Idle Control System (A8)	
		Keyless Access System (A8)	
		PCM (All) (A8)	
		Starting System (A8)	
		Under-Hood Fuse/Relay Box (A8)	
		VSA/TPMS (Tire Pressure Monitoring System) (A8)	
		Wiper/Washer (Rear Window) (A8)	
		Wiper/Washer (Windshield) (A8)	
A9	15A	Climate Control (A9)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		EVAP System (A9)	
		Fans (A9)	
		PCM (All) (A9)	
		PCM Power and Ground (A9)	
		PGM-FI System (A9)	
		Under-Hood Fuse/Relay Box (A9)	

Fuse No.	Ampere	Schematic	Fuse/Relay Box Location
A10	20A	Climate Control (A10)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Fans (A10)	
		Under-Hood Fuse/Relay Box (A10)	
A11	5A	Climate Control (A11)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		EVAP System (A11)	
		Fans (A11)	
		PCM (All) (A11)	
		PGM-FI System (A11)	
		Under-Hood Fuse/Relay Box (A11)	
A12	10A	PCM (All) (A12)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		PCM Power and Ground (A12)	
		PGM-FI System (A12)	
		Under-Hood Fuse/Relay Box (A12)	
A13	15A	License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights (A13)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Power, Grounds and Diagnostics (A13)	
		Under-Hood Fuse/Relay Box (A13)	
A15	15A	Ignition System (A15)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		PCM (All) (A15)	
		Under-Hood Fuse/Relay Box (A15)	
A17	10A	License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights (A17)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Under-Hood Fuse/Relay Box (A17)	
A18	10A	Ambient Lights, Cargo Area Lights, Ceiling Lights, Console Lights, Courtesy Lights, Footwell Lights, Glove Box Lights, Individual MAP Lights, Trunk Lights and Vanity Mirror Lights (A18)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Cable Reel (A18)	
		Cruise Control (A18)	
		Dashlights (A18)	
		DLC (A18)	
		Entry Light Control System and Ignition Key Light (A18)	
		Gauges (A18)	
		Headlights (A18)	
		Keyless Access System (A18)	
		Keyless/Power Door Locks/Security System (A18)	
		License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights (A18)	
		Low Oil Pressure Indicator, Reminder Systems, Safety Indicator (A18)	
		MIL Circuit (A18)	
		Navigation System (A18)	
		Power Mirrors (A18)	
		Power Windows (A18)	
		Power, Grounds and Diagnostics (A18)	
		Rear Window/Power Mirror Defoggers (A18)	
		SRS (A18)	
		Starting System (A18)	

Fuse No.	Ampere	Schematic	Fuse/Relay Box Location
		Telematics/HandsFreeLink System (A18)	
		Under-Hood Fuse/Relay Box (A18)	
		VSA/TPMS (Tire Pressure Monitoring System) (A18)	
		Wiper/Washer (Rear Window) (A18)	
		Wiper/Washer (Windshield) (A18)	
A19	15A	Navigation System (A19)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Telematics/HandsFreeLink System (A19)	
		Under-Hood Fuse/Relay Box (A19)	
A20	10A	Ambient Lights, Cargo Area Lights, Ceiling Lights, Console Lights, Courtesy Lights, Footwell Lights, Glove Box Lights, Individual MAP Lights, Trunk Lights and Vanity Mirror Lights (A20)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Dashlights (A20)	
		Keyless/Power Door Locks/Security System (A20)	
		License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights (A20)	
		Under-Hood Fuse/Relay Box (A20)	
A21	10A	Ambient Lights, Cargo Area Lights, Ceiling Lights, Console Lights, Courtesy Lights, Footwell Lights, Glove Box Lights, Individual MAP Lights, Trunk Lights and Vanity Mirror Lights (A21)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Energy Management System (A21)	
		Entry Light Control System and Ignition Key Light (A21)	
		Under-Hood Fuse/Relay Box (A21)	
A22	15A	Fog Lights (A22)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Under-Hood Fuse/Relay Box (A22)	
A23	10A	Climate Control (A23)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Idle Control System (A23)	
		PCM (All) (A23)	
		Under-Hood Fuse/Relay Box (A23)	
A24	10A	Charging System (A24)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Energy Management System (A24)	
		Horns (A24)	
		Keyless/Power Door Locks/Security System (A24)	
		Under-Hood Fuse/Relay Box (A24)	
B1	10A	Accessory Power Sockets (B1)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Navigation System (B1)	
		Power Supply (B1)	
		Telematics/HandsFreeLink System (B1)	
		Under-Dash Fuse/Relay Box (B1)	
B2	5A	Keyless Access System (B2)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Power Supply (B2)	
		Power, Grounds and Diagnostics (B2)	
		Under-Dash Fuse/Relay Box (B2)	
B3	10A	Power Supply (B3)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Under-Dash Fuse/Relay Box (B3)	
		Wiper/Washer (Rear Window) (B3)	
B5	10A	Adaptive Damper System (B5)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Brake Lights (B5)	

Fuse No.	Ampere	Schematic	Fuse/Relay Box Location
		Power Supply (B5)	
		Under-Dash Fuse/Relay Box (B5)	
		VSA/TPMS (Tire Pressure Monitoring System) (B5)	
B6	10A	Power Supply (B6)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		SRS (B6)	
		Under-Dash Fuse/Relay Box (B6)	
B7	10A	Charging System (B7)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Cruise Control (B7)	
		Energy Management System (B7)	
		EPS (B7)	
		Gauges (B7)	
		Keyless Access System (B7)	
		Keyless/Power Door Locks/Security System (B7)	
		Low Oil Pressure Indicator, Reminder Systems, Safety Indicator (B7)	
		MIL Circuit (B7)	
		Navigation System (B7)	
		Power Supply (B7)	
		Power, Grounds and Diagnostics (B7)	
		SRS (B7)	
		Telematics/HandsFreeLink System (B7)	
		Under-Dash Fuse/Relay Box (B7)	
		VSA/TPMS (Tire Pressure Monitoring System) (B7)	
		Wiper/Washer (Rear Window) (B7)	
		Wiper/Washer (Windshield) (B7)	
B8	20A	Accessory Power Sockets (B8)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Ambient Lights, Cargo Area Lights, Ceiling Lights, Console Lights, Courtesy Lights, Footwell Lights, Glove Box Lights, Individual MAP Lights, Trunk Lights and Vanity Mirror Lights (B8)	
		Back-Up Lights (B8)	
		Brake Lights (B8)	
		Charging System (B8)	
		Dashlights (B8)	
		Energy Management System (B8)	
		Entry Light Control System and Ignition Key Light (B8)	
		Fog Lights (B8)	
		Fuel Supply System (B8)	
		Gauges (B8)	
		Headlights (B8)	
		Idle Control System (B8)	
		Keyless Access System (B8)	
		Keyless/Power Door Locks/Security System (B8)	
		License Plate Lights, Side Marker Lights, Parking/Daytime Running Light, Taillights and Turn Signal/Hazard Warning Lights (B8)	
		Low Oil Pressure Indicator, Reminder Systems, Safety Indicator (B8)	
		MIL Circuit (B8)	

Fuse No.	Ampere	Schematic	Fuse/Relay Box Location
		PCM (All) (B8)	
		PGM-FI System (B8)	
		Power Mirrors (B8)	
		Power Supply (B8)	
		Power Windows (B8)	
		Power, Grounds and Diagnostics (B8)	
		Rear Window/Power Mirror Defoggers (B8)	
		Reverse Lockout System (B8)	
		SRS (B8)	
		Under-Dash Fuse/Relay Box (B8)	
		Wiper/Washer (Rear Window) (B8)	
		Wiper/Washer (Windshield) (B8)	
B9	10A	Climate Control (B9)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Entry Light Control System and Ignition Key Light (B9)	
		Fans (B9)	
		Idle Control System (B9)	
		Keyless/Power Door Locks/Security System (B9)	
		PCM (All) (B9)	
		Power Mirrors (B9)	
		Power Supply (B9)	
		Power Windows (B9)	
		Rear Window/Power Mirror Defoggers (B9)	
		Under-Dash Fuse/Relay Box (B9)	
B12	10A	Keyless/Power Door Locks/Security System (B12)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Under-Dash Fuse/Relay Box (B12)	
B13	10A	Keyless/Power Door Locks/Security System (B13)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Under-Dash Fuse/Relay Box (B13)	
B14	20A	Power Windows (B14)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Under-Dash Fuse/Relay Box (B14)	
B15	20A	Keyless/Power Door Locks/Security System (B15)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Power Mirrors (B15)	
		Power Windows (B15)	
		Rear Window/Power Mirror Defoggers (B15)	
		Under-Dash Fuse/Relay Box (B15)	
B16	20A	Keyless/Power Door Locks/Security System (B16)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Under-Dash Fuse/Relay Box (B16)	
B21	10A	Back-Up Lights (B21)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Brake Lights (B21)	
		Cruise Control (B21)	
		Idle Control System (B21)	
		PCM (All) (B21)	
		PGM-FI System (B21)	
		Power Supply (B21)	
		Reverse Lockout System (B21)	

Fuse No.	Ampere	Schematic	Fuse/Relay Box Location
		Starting System (B21)	
		Under-Dash Fuse/Relay Box (B21)	
		Wiper/Washer (Rear Window) (B21)	
B22	10A	Power Supply (B22)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Power, Grounds and Diagnostics (B22)	
		Under-Dash Fuse/Relay Box (B22)	
B24	5A	Cable Reel (B24)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Dashlights (B24)	
		Gauges (B24)	
		Navigation System (B24)	
		Telematics/HandsFreeLink System (B24)	
		Under-Dash Fuse/Relay Box (B24)	
B25	10A	Keyless/Power Door Locks/Security System (B25)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Under-Dash Fuse/Relay Box (B25)	
B26	10A	Keyless/Power Door Locks/Security System (B26)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Under-Dash Fuse/Relay Box (B26)	
B27	20A	Power Windows (B27)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Under-Dash Fuse/Relay Box (B27)	
B28	20A	Keyless/Power Door Locks/Security System (B28)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Power Mirrors (B28)	
		Power Windows (B28)	
		Rear Window/Power Mirror Defoggers (B28)	
		Under-Dash Fuse/Relay Box (B28)	
B29	20A	Accessory Power Sockets (B29)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Under-Dash Fuse/Relay Box (B29)	
B30	10A	Keyless Access System (B30)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Power, Grounds and Diagnostics (B30)	
		Starting System (B30)	
		Under-Dash Fuse/Relay Box (B30)	
B34	10A	EPS (B34)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Power Supply (B34)	
		Under-Dash Fuse/Relay Box (B34)	
		VSA/TPMS (Tire Pressure Monitoring System) (B34)	
B35	10A	Power Supply (B35)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		SRS (B35)	
		Under-Dash Fuse/Relay Box (B35)	
B36	20A	Under-Dash Fuse/Relay Box (B36)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
B38	10A	Keyless/Power Door Locks/Security System (B38)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Under-Dash Fuse/Relay Box (B38)	
B39	10A	Keyless/Power Door Locks/Security System (B39)	Fuse/Relay Boxes > Under-Dash Fuse/Relay Box > Front Side
		Under-Dash Fuse/Relay Box (B39)	
C26	10A	Headlights (C26)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Keyless/Power Door Locks/Security System (C26)	

Fuse No.	Ampere	Schematic	Fuse/Relay Box Location
		Under-Hood Fuse/Relay Holder A (C26)	
C27	10A	Headlights (C27)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Keyless/Power Door Locks/Security System (C27)	
		Under-Hood Fuse/Relay Holder A (C27)	
C29	10A	Headlights (C29)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Power, Grounds and Diagnostics (C29)	
		Under-Hood Fuse/Relay Holder A (C29)	
C30	10A	Headlights (C30)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Power, Grounds and Diagnostics (C30)	
		Under-Hood Fuse/Relay Holder A (C30)	
D31	15A	Adaptive Damper System (D31)	Fuse/Relay Boxes > Under-Hood Fuse/Relay Box
		Under-Hood Fuse/Relay Holder B (D31)	