

例 : A 0 8 0 1 0 0 4

AC/DC Power Fail

A : (fixed value)
Reserved Area
0-E Reserved
F The error happens frequently due to the main body breakdown etc.
Step No.
00-7F Step Number of Power On Sequence
80 Static state(PowerOn)
90 Static state(PowerOFF)
A0 Static state(Immediately after syscon reset)
Error Category
Error Information

A	X	XX	XXX	
A	0	XX	Category1 :System error	1 0 0 1 BE VRAM Power Fail
				1 0 0 2 RSX VRAM Power Fail
				1 0 0 4 AC/DC Power Fail
				1 1 0 3 Thermal Error
				1 2 0 0 BE Thermal Error
				1 2 0 1 RSX Thermal Error
				1 2 0 3 BE VR Thermal Error
				1 2 0 4 SB Thermal Error
				1 2 0 5 EE+GS Thermal Error
				1 3 0 1 BE PLL Unlick
				1 4 F F Check Stop
				1 6 0 1 BE Livelock Detection
				1 7 0 1 BE Attention
				1 8 0 2 RSX INIT
				1 9 0 0 RTC Error (voltage drop)
				1 9 0 1 RTC Error (oscillation stop)
				1 9 0 2 RTC Error (Access Error)
			Category2 :Fatal Error	2 0 0 1 BE Error (IC1001)
				2 0 0 2 RSX Error (IC2001)
				2 0 0 3 SB Error (IC3001)
				2 0 1 0 Clock Generator Error (IC5001)
				2 0 1 1 Clock Generator Error (IC5003)
				2 0 1 2 Clock Generator Error (IC5002)
				2 0 1 3 Clock Generator Error (IC5004)
				2 0 2 0 HDMI Error (IC2502)
				2 0 2 2 DVE Error (IC2406)
				2 0 3 0 Thermal Sensor Error (IC1101)
				2 0 3 1 Thermal Sensor Error (IC2101)
				2 0 3 3 Thermal Sensor Error (IC3101)
				2 1 0 1 BE Error (IC1001)
				2 1 0 2 RSX Error (IC2001)
				2 1 0 3 SB Error (IC3001)
				2 1 1 0 Clock Generator Error (IC5001)
				2 1 1 1 Clock Generator Error (IC5003)
				2 1 1 2 Clock Generator Error (IC5002)
				2 1 1 3 Clock Generator Error (IC5004)
				2 1 2 0 HDMI Error (IC2502)
				2 1 2 2 DVE Error (IC2406)
				2 1 3 0 Thermal Sensor Error (IC1101)
				2 1 3 1 Thermal Sensor Error (IC2101)
				2 1 3 3 Thermal Sensor Error (IC3101)
				2 2 0 3 SB Error (IC3001)
			Category3 :Fatal booting Error	3 0 0 0 POWER FAIL
				3 0 0 1 POWER FAIL
				3 0 0 2 POWER FAIL
				3 0 0 3 POWER FAIL
				3 0 0 4 POWER FAIL
				3 0 1 0 BE Error (IC1001)
				3 0 1 1 BE Error (IC1001)
				3 0 1 2 BE Error (IC1001)
				3 0 2 0 BE Error (IC1001)
				3 0 3 0 BE Error (IC1001)
				3 0 3 1 BE Error (IC1001)
				3 0 3 2 BE Error (IC1001)
				3 0 3 3 BE Error (IC1001)
				3 0 3 4 BE Error (IC1001)
				3 0 3 5 BE-RSX Error (IC1001-IC2001)
				3 0 3 6 BE-RSX Error (IC1001-IC2001)
				3 0 3 7 BE-RSX Error (IC1001-IC2001)
				3 0 3 8 BE-SB Error (IC1001-IC3001)
				3 0 3 9 BE-SB Error (IC1001-IC3001)
				3 0 4 0 Flash controller Error (IC3801)
			Category4 :Data Error	4 0 0 1 BE Error (IC1001)
				4 0 0 2 RSX Error (IC2001)
				4 0 0 3 SB Error (IC3001)
				4 0 1 1 BE Error (IC1001)
				4 1 0 1 BE Error (IC1001)
				4 1 0 2 RSX Error (IC2001)
				4 1 0 3 SB Error (IC3001)
				4 1 1 1 BE Error (IC1001)
				4 2 0 1 BE Error (IC1001)
				4 2 0 2 RSX Error (IC2001)
				4 2 0 3 SB Error (IC3001)
				4 2 1 1 BE Error (IC1001)
				4 2 1 2 RSX Error (IC2001)
				4 2 1 3 BE Error (IC1001)
				4 2 2 2 RSX Error (IC2001)
				4 2 2 3 BE Error (IC1001)
				4 2 3 1 BE Error (IC1001)
				4 2 6 1 BE Error (IC1001)
				4 3 0 1 BE Error (IC1001)
				4 3 0 2 RSX Error (IC2001)
				4 3 0 3 SB Error (IC3001)
				4 3 1 1 BE Error (IC1001)
				4 3 1 2 RSX Error (IC2001)
				4 3 2 1 BE Error (IC1001)
				4 3 2 2 RSX Error (IC2001)
				4 3 3 2 RSX Error (IC2001)
				4 3 4 1 BE Error (IC1001)
				4 4 0 1 BE or RSX Error (IC1001 or IC2001)
				4 4 0 2 BE or RSX Error (IC1001 or IC2001)
				4 4 0 3 BE or SB Error (IC1001 or IC3001)
				4 4 1 1 BE or RSX Error (IC1001 or IC2001)
				4 4 1 2 BE or RSX Error (IC1001 or IC2001)
				4 4 2 1 BE or RSX Error (IC1001 or IC2001)
				4 4 2 2 BE or RSX Error (IC1001 or IC2001)
				4 4 3 2 BE or RSX Error (IC1001 or IC2001)
				4 4 4 1 BE or SB Error (IC1001 or IC3001)