



Part No.	S4-4-4-14	 control devices, LLC
Order No.	391742	
Order Qty	50	
Distinguishing Traceability Numbers		
Flare Nuts	Six digit no. located on the box label under box quantity.	
Brazing Rings	Located on the box label, directly above the word "heat."	
Copper Tubing	Located on the spool label, starting with the letter "M."	
Flare Tubes	Use their work order number and date on the box label.	
Snap Rings	Located on the bag followed by "Lot Number."	
Caps/Plugs	Do not require traceability.	

Component(s)	Heat Lot/Traceability No(s)
SF4-4-4	391742
CUTU-3-1/2	391742
CUTU-14-1/4	
BRZ01	
BRZ05	
CP13	

Part No.	S4-4-4-14	 control devices, LLC
Order No.	391742	
Order Qty	50	
Distinguishing Traceability Numbers		
Flare Nuts	Six digit no. located on the box label under box quantity.	
Brazing Rings	Located on the box label, directly above the word "heat."	
Copper Tubing	Located on the spool label, starting with the letter "M."	
Flare Tubes	Use their work order number and date on the box label.	
Snap Rings	Located on the bag followed by "Lot Number."	
Caps/Plugs	Do not require traceability.	

Component(s)	Heat Lot/Traceability No(s)
SF4-4-4	391742
CUTU-3-1/2	391742
CUTU-14-1/4	
BRZ01	
BRZ05	
CP13	

[illegible]

Special Notes / Instructions		First Part Inspection Record						
Down Time Codes	Date Part Submitted	Time Of Day	Approved Yes / No	Mtrl Check	Rev Letter	Inspector	Notes	
1 Maintenance								
2 Tooling								
3 Setup								
4 FAIR								
5 Training								
6 Meeting								

BRAZING PRODUCTION RECORD