


Part No.	GR5-R	
Order No.	397824	
Order Qty	12	
Distinguishing Traceability Numbers		
Flare Nuts	Six digit no. located on the box label under box quantity.	
Brazing Rings	Located on the box label, directly above the word "heat."	
Copper Tubing	Located on the spool label, starting with the letter "M."	
Flare Tubes	Use their work order number and date on the box label.	
Snap Rings	Located on the bag followed by "Lot Number."	
Caps/Plugs	Do not require traceability.	

[illegible][illegible]

ROUTING:									
Special Notes / Instructions		Down Time Codes		First Part Inspection Record					
1	Maintenance	Date Part Submitted	Time Of Day	Approved Yes / No	Mtrl Check	Rev Letter	Inspector	Notes	
2	Tooling								
3	Setup								
4	FAIR								
5	Training								
6	Meeting								

BRAZING PRODUCTION RECORD

Test Form 11/14/15