

Vin - battery
9V can be used
or either
on Arduino itself.

9V battery as Vin & Gnd.

5V Arduino → Relay Vcc
Gnd // → Relay GND
② In2 pin to any Arduino - 6

1) NO — Ve terminal of Vin —
+ Ve terminal of Vin — Pump (-ve)
Middle of relay — Pump (+ve)