



**Home Sewing Machine**

## **PARTS REFERENCE LIST**

**MODEL: LS-2720/LS-2820/LS-2920/LS-2725  
LS-2825/LS-1520/LS-2129/LS-2125  
LS-2125i/LS-2130/LS-2150/LS-2125b  
SL-7/JS-23/VX-1435/X-5  
LX-3125/LS-2160**

**MECHANISMS & ELECTRONICS**

# CONTENTS


(1) PRINCIPAL PARTS.....	2
(2) UPPER SHAFT AND NEEDLE BAR.....	4
(3) FEED MECHANISM .....	6
(4) PATTERN SELECTION, SHUTTLE HOOK AND UPPER TENSION.....	8
(5) LAMP AND MOTOR.....	10
(6) OTHER PARTS .....	12

**Note on parts:**

We keep performance parts for this sewing machine for at least 8 years after this model is discontinued. Performance parts are the necessary parts to maintain the function of the sewing machine.


## (1) PRINCIPAL PARTS

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
1	XD0289021	FRONT COVER	050102	20	XD0793021	ACCESSORY TABLE (OTHER)	050102
	XE2150001	FRONT COVER (LS-2130, LX-3125)	1000008671		XE2218001	ACCESSORY TABLE (LS-2130, LX-3125)	1000008671
2	0A0211850	PIN SPRING ROLL BW2		21	X58361021	RUBBER CUSHION	
3	X53625121	UPPER COVER THREAD GUIDE		22	X56474021	SPACER	
4	XC0730021	DECORATION PLATE (LS-2720)		23	X57297021	SCREW	
	XC0730022	DECORATION PLATE (LS-2820)		24	XA7932021	BASE PLATE	
	XC0730023	DECORATION PLATE (LS-2020, 2920)		25	XA1805021	BASE RUBBER A	
	XC0730024	DECORATION PLATE (LS-1520)		26	XA4687021	ADJUSTING SCREW ASSY	
	XC0730025	DECORATION PLATE (LS-2725)		27	060400816	SCREW BIND M4X8	
	XC0730026	DECORATION PLATE (LS-2825)		28	XA7769021	CUSHION	
	XC0730027	DECORATION PLATE (USA, CAN, ARG, CHL, TWN) (LS-2125, LS-2125b)					
	XC0730028	DECORATION PLATE (LS-2129)					
	XC0730029	DECORATION PLATE (LS-2125 : OTHER)					
	XC0730031	DECORATION PLATE (SL-7)					
	XC0730032	DECORATION PLATE (LS-2125i)					
	XC0730033	DECORATION PLATE (JS-23)					
	XC0730034	DECORATION PLATE (VX-1435)					
	XC0730035	DECORATION PLATE (X-5)	1000001349				
	XC0730036	DECORATION PLATE (LS-2150)	1000005185				
	XC0730037	DECORATION PLATE (LS-2160)	1000008821				
	XE2338001	DECORATION SHEET (LS-2130, LX-3125)	1000008671				
5	138172021	SCREW,PAN(S/P WASHER)M4X10					
6	053400806	SCREW, PAN (T WASHER) M4X8					
7	XC1201121	REAR COVER ASSEMBLY	1000009386				
8	XA6106021	THREAD GUIDE ASSY	040161				
9	0A5301006	SCREW, PAN (S/P WASHER) M3X10					
10	021300106	NUT 1 M3					
11	XC8701021	SPOOL PIN (OTHER)	1000009210				
	XE6223001	SPOOL PIN (LS-2125:U.S.A., LS-2125i:U.S.A., VX-1435:U.S.A., LX-3125:U.S.A.)					
12	XA0628121	SPOOL PIN SPRING	1000012082				
13	XA8851021	SPOOL PIN STAND	050073				
14	X59864221	BOBBIN PRESSER	040152				
15	052301606	SCREW, PAN (S/P WASHER) M3X16					
16	X57891021	REFLECTOR					
17	XA7926021	HINGED DOOR					
18	X53638121	SPRING					
19	XA9974021	FACE PLATE					
	XE2217001	FACE PLATE (LS-2130, LX-3125)	1000008671				




## (2) UPPER SHAFT AND NEEDLE BAR

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
UPPER SHAFT				28	XA1112121	THREAD TAKE-UP ASSY	
1	XE3693001	UPPER SHAFT SUPPLY ASSY	1000006160	29	XA0648120	THREAD TAKE-UP LEVER STUD	
2	012400432	SET SCREW SOCKET (FT) M4X4		30	048050346	RETAINING RING E5	1000001452
3	XA0637120	CLUTCH PLATE		31	X57913021	TAPTITE,BIND S M4X16	
4	XA0636020	CLUTCH SPRING		32	128437020	PRESSER BAR (EXCEPT: LS-1520:USA)	040158
5	XA0638120	TIMING PULLEY			XA2402020	PRESSER BAR (LS-1520: USA)	040158
6	048080346	RETAINING RING E8	1000001452	33	X55770021	PRESSER BAR SPRING (LS-21**, VX-1435, JS-23, X-5, SL-7, LX-3125)	1000008671
7	012500532	SET SCREW SOCKET (FT) M5X5	1000010653		X55770051	PRESSER BAR SPRING (OTHER)	
8	014400432	SET SCREW SOCKET (CP) M4X4		34	XA0975021	PRESSER BAR GUIDE BRACKET (LS-21**, VX-1435, JS-23, X-5, SL-7, LX-3125)	1000008671
9	X52478021	BUSHING PRESSER			XA0975051	PRESSER BAR GUIDE BRACKET (OTHER)	
10	X57908021	TAPTITE, BIND S M4X10		35	X52760021	SET SCREW, PAN M6 x 12	
11	XA0639021	BALANCE WHEEL		36	XA2511121	PRESSER FOOT LIFTER	
NEEDLE BAR				37	XA0977150	PRESSER FOOT LIFTER STUD	
12	XA2358121	NEEDLE BAR (EXCEPT: LS-2125i, LS-2130, LX-3125)		38	138135122	ZIGZAG PRESSER FOOT	
13	XA0642120	NEEDLE BAR THREAD GUIDE (EXCEPT: LS-2125i, LS-2130, LX-3125)		39	138134021	PRESSER FOOT HOLDER (EXCEPT: LS-2125i, LS-2130, LX-3125)	
14	XA0643121	NEEDLE CLAMP (EXCEPT: LS-2125i, LS-2130, LX-3125)			XC3015031	PRESSER FEED HOLDER ASSY (LS-2125i, LS-2130, LX-3125)	1000008671
15	XC8563031	NEEDLE CLAMP SCREW (LS-2125i, LS-2130, LX-3125)	1000008671	40	132730122	TIGHTENING SCREW 3.57	
	XA0644021	NEEDLE CLAMP SCREW (EXCEPT: LS-2125i, LS-2130, LX-3125)		41	XA1866021	WASHER, SPRING	050209
16	012400432	SET SCREW SOCKET (FT) M4X4		42	X53330020	WASHER	1000003111
17	XA8983021	NEEDLE BAR SUPPORTER (EXCEPT: LS-1520:USA)		New Spec			
	XC6386021	NEEDLE BAR SUPPORTER (LS-1520:USA)		43	XD1220131	NEEDLE BAR ASSY N (LS-2125i, LS-2130, LX-3125)	1000008671
18	XA3477021	NEEDLE BAR SUPPORTER STUD	1000002222				
19	X54369021	SPRING					
20	X56851021	LOCK NUT					
21	XE3167001	NEEDLE BAR SUPPORTER GUIDE (LS-21**/2020/2720: KOR/SIN, LS-2820:SIN,VX-1435, JS-23, X-5, SL-7, LX-3125)	1000008671				
	XA8380021	NEEDLE BAR SUPPORTER GUIDE (OTHER)					
22	XA1289121	NEEDLE BAR CRANK ROD ASSY					
23	XA1113221	NEEDLE BAR CRANK	1000001814				
24	132051022	SCREW, FLAT SM3.57-40X7 L					
25	XA3954121	ZIGZAG NEEDLE PLATE	1000011532				
26	X50487021	SCREW M4	1000010447				
27	X57908021	TAPTITE, BIND S M4X10					



### (3) FEED MECHANISM


No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
1	XA0978021	FEED CONNECTING ROD ASSY		43	XA4533021	REVERSE SEWING LEVER PLATE C	
2	XA0980021	SPRING		44	X59905051	SPRING	
3	XA0982020	HORIZONTAL FEED SHAFT		45	048040346	RETAINING RING E4	1000001452
4	XA0983121	HORIZONTAL FEED ARM ASSEMBLY		46	XA1004120	REVERSE SEWING SHAFT	
5	021400205	NUT 2 M4		47	XA9976021	REVERSE SEWING BUTTON (OTHER)	
6	060401416	SCREW BIND M4X14			XE2219001	REVERSE SEWING BUTTON (LS-2130, LX-3125)	1000008671
7	X53330020	WASHER		48	XA4534021	STOP PLATE L	
8	048050346	RETAINING RING E5	1000001452	49	XA4532121	REVERSE SEWING LEVER PLATE A	
9	XA0987021	HORIZONTAL FEED PLATE		50	XA4568021	SPRING	
10	XA0988021	FEED STAND SHAFT					
11	XA3960021	FEED STAND					
12	048030346	RETAINING RING E3	1000001452				
13	146200021	RETAINING RING, CS4					
14	XA4430021	FEED DOG					
15	060300416	SCREW BIND M3X4					
16	060400816	SCREW BIND M4X8					
17	XA3474021	DUST PROTECT PLATE					
18	XA4042120	FEED STAND SUPPORT					
19	025040133	WASHER, PLAIN S 4					
20	XA1082021	TAPER POINT STUD R (LS-21**, VX-1435, JS-23, X-5, SL-7, LX-3125)	1000008671				
	XA1082051	TAPER POINT STUD R (OTHER)					
21	XZ0074021	TAPTITE, CUP S M4X16	060158				
22	XA0991021	SPRING					
23	X55472021	TAPER POINT STUD L ASSEMBLY	1000008671				
24	062400416	SCREW, PAN M4X4					
25	XA0649021	TAPTITE, CUP S M4 x 14					
26	X56613021	SPRING					
27	XA4692021	SPRING					
28	XA3480021	VERTICAL FEED ARM					
29	XA3481021	VERTICAL FEED ADJUSTER					
30	XA0995121	VERTICAL FEED SHAFT	050091				
31	048060346	RETAINING RING E6	1000001452				
32	X50559020	ZIGZAG ADJUSTING NUT					
33	062300806	SCREW PAN M3X8					
34	060400516	SCREW BIND M4X5					
35	XA0030021	FEED SQUARE BLOCK					
36	XA0996020	FEED REGULATOR					
37	XA0997020	FEED REGULATOR SHAFT					
38	XA4675021	SPRING	050091				
39	XA9169021	FEED REGULATOR PLATE					
40	XA1002020	REVERSE SEWING REGULATOR SHAFT					
41	0A5300606	SCREW PAN (S/P WASHER) M3X6	1000011101				
42	XC0376021	REVERSE BUTTON HOLDER B ASSY					






#### (4) PATTERN SELECTION, SHUTTLE HOOK AND UPPER TENSION

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
1	XA4693121	CAM DRIVE CONNECTING ROD A		42	XA7986021	BOBBIN WINDER HOLDER SUB ASSY	
2	XA1012221	CAM DRIVE CONNECTING ROD B		43	XA1049021	BOBBIN WINDER SPINDLE ASSEMBLY	
3	XA1014021	CAM DRIVE ROD C SUB ASSY		44	X59939021	BOBBIN WINDER SPRING	
4	XA1017120	RACK		45	XE3453001	UPPER TENSION CONTROL DIAL	1000009051
5	XC7564021	SCREW, PAN (S/P WASHER) M3X6	1000008671	46	XA4426021	TENSION CONTROL HOLDER ASSY	
6	<del>XA3439021</del>	SPRING	DEL	47	XA1058021	UPPER TENSION CONTROL RELEASER	
7	<del>146200051</del>	STOP RING	DEL	48	XC0549020	DIAL HOLD PLATE	
8	048040346	RETAINING RING E4	1000001452	49	XA6907021	SCREW 4X8	1000005128
9	<del>060400816</del>	SCREW	1000005128				
10	<del>XA6909021</del>	TOOTHED WASHER	1000005128				
11	131976020	WASHER, THRUST					
12	XA1019021	RACK PLATE SPRING					
13	XA8290021	TAPTITE, BIND S M4 x 8					
14	X50559020	ZIGZAG ADJUSTING NUT					
15	062301006	SCREW PAN M3X10					
16	X52077121	COLLAR					
17	014400432	SET SCREW SOCKET (CP) M4X4					
18	X53330020	WASHER					
19	XA1317022	SHUTTLE RACE ASSEMBLY					
20	128581022	SHUTTLE HOOK					
21	XA1021021	SHUTTLE DRIVE ASSY					
22	XA1025021	DRIVER SHAFT GEAR					
23	128582023	BOBBIN CASE ASSEMBLY					
24	X52800120	BOBBIN					
25	014400632	SET SCREW SOCKET (CP) M4X6					
26	X57313121	RACK STOPPER					
27	X57908021	TAPTITE, BIND S M4X10					
28	XA5702021	RACK STOPPER A					
29	XA4483121	ZIGZAG CONNECTING ROD ASSY					
30	XA8474021	UPSET 4 x12 DB					
31	XA1529021	SPRING					
32	XC0363021	SELECTING UNIT ASSY					
33	XA1620051	ADJUSTING SCREW					
34	X56851021	LOCK NUT					
35	136681021	TAPTITE, BIND B M3X8	050091				
36	060400416	SCREW, BIND M4X4					
37	XA1255121	THREAD TENSION LABEL					
38	048050346	RETAINING RING E5	1000001452				
39	021400202	NUT 2 M4					
40	X57908021	TAPTITE, BIND S M4X10					
41	XC0369021	SELECTING DIAL (OTHER)					
	XC0369022	SELECTING DIAL (LS-2125: USA, CAN, ARG, CHL, TWN, 2129, 2125i, 2130, 2125b)					













## (5) LAMP AND MOTOR

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
LAMP				19	XC7359021	FOOT CONTROLLER:KD-1902 (USA, CAN)	060049
1	XC6789021	ASSY:SEWING LAMP E12C#025 (USA, CAN, BRA120V, TWN)	060049		XC7456321	FOOT CONTROLLER:KD-2902UK (UK, IRE)	050086
	XA1064021	SEW-LIGHT ASSY (220-240V) (OTHER)			XE0629001	FOOT CONTROLLER:KD-2902AUS (AUS)	
2	X53061020	SEW-LIGHT BULB (100-120V) (USA, CAN, BRA120V, TWN)			XD0112121	FOOT CONTROLLER:KD-2902IRAM (ARG)	1000008422
	205336030	SEW-LIGHT BULB L-4 (220-240V) (OTHER)	1000012695		XE3414001	FOOT CONTROLLER:KD-1902 BRZ (BRA120V)	1000004014
3	X57984021	TAPTITE, BIND S M3 x 20 (100-120V) (USA, CAN, BRA120V, TWN)			XE4302001	FOOT CONTROLLER:KD-2902 BRZ (BRA220V)	
	XA1623021	TAPTITE, BIND S M3 x 10 (220-240V) (OTHER)			XD0105021	FOOT CONTROLLER:KD-2902 CHN (CHN)	
4	X53169020	BAND (220-240V) (OTHER)	050245		XE3447001	FOOT CONTROLLER:KD-1902 TWN (TWN)	1000004114
MOTOR					XD0852021	FOOT CONTROLLER:KD-2902KOREA (KOR)	060085
5	XA1196021	T BELT B163XXL4.8			XC7438321	FOOT CONTROLLER:KD-2902 (OTHER)	
6	XA3004021	BOLT, (S/P WASHER) M5 x 12		20	XE2842001	MOTOR SUPPORTER (USA, CAN, BRA120V, TWN)	1000002813
7	XA8786021	3P SOCKET BODY		21	021400205	NUT 2 M4 (USA, CAN, BRA120V, TWN)	1000002958
8	XA8787021	3P SOCKET COVER		22	028040242	WASHER SPRING 2-4 (USA, CAN, BRA120V, TWN)	
9	052403006	SCREW, PAN (S/P WASHER) M4X30		23	102707023	WASHER (USA, CAN, BRA120V, TWN)	
10	021400205	NUT 2 M4	1000002958	24	XA8474021	UPSET 4X12 DB (USA, CAN, BRA120V, TWN)	1000002958
11	214808020	CONNECTOR : #3					
12	XA1070021	PW SWITCH ASSY (100-120V) (USA, CAN, BRA120V, TWN)					
	XA1073021	PW SWITCH ASSY (220-240V) (OTHER)					
13	XC7354121	MOTOR : HFA-07150 FDM (USA, CAN, BRA120V, TWN)	060085				
	XC7599321	MOTOR : NS-70 FDM220V (ARG, CHL, CHN)	1000012143				
	XD0851121	MOTOR : NS-70 FDM220V/60HZ (KOR, BRA220V)	1000012143				
	XE0730101	MOTOR:NS-70 FDM240V (AUS, MYS)	1000012143				
	XC7436221	MOTOR:NS-70 FDM230V (OTHER)	1000012143				
14	XA1265120	MOTOR T-PULLEY A					
15	XC7355021	MOTOR T-PULLEY B	050090				
16	<del>XA7678051</del>	CORD CLAMP (BRA120V, TWN)	1000009035				
	XA7678021	CORD CLAMP	1000008457				
17	X57908021	TAPTITE, BIND S M4 x 10	1000010046				
18	138598021	SOCKET PIN	040105				













## (6) OTHER PARTS

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
1	X55466021	SCREW DRIVER ASSY	ADD	18	XE4544001	INSTRUCTION BOOK BR (BRA)	1000007560
2	X55467021	SCREW DRIVER	ADD		XE4762001	INSTRUCTION BOOK EEU (LS-2125: EEU)	1000007823
3	X55468021	SCREW DRIVER S	ADD		XE4763001	INSTRUCTION BOOK EEU (LS-2125: EEU)	1000007823
4	XZ5071001	BAG 40X160	ADD		XE2346101	INSTRUCTION BOOK (LS-2130, LX-3125)	1000011170
5	X59370021	ZIPPER FOOT	040115		XE5682001	INSTRUCTION BOOK TUR	1000010619
6	X59369321	BUTTON HOLE FOOT ASSY	040115		XE4953001	MYLAR INSTRUCTION ASSY ENG (LS-2125i: USA)	1000008043
7	XE2137001	BUTTON SEWING FOOT	1000001059		XE4954001	MYLAR INSTRUCTION ASSY SPA (LS-2125i: USA)	1000008043
8	<del>X54243001</del>	SEAM RIPPER	DEL		XC0380021	WARRANTY CARD (USA)	
9	X52800120	BOBBIN			LA1661001	WARRANTY CARD EURO CH (UK, IRE, GER, FRA, HOL, POR, ITA, SWI, DEN, EEU)	1000010793
10	<del>X55465051</del>	OILER	DEL		XC6402021	WARRANTY CARD (UK)	
11	129583021	NEEDLE SET (3PCS) (OTHER)			XE2010001	WARRANTY CARD BROTHER CANADA (CAN)	1000001038
	XE5328001	NEEDLE SET (3PCS) (LX-3125)	1000008671		XE5572001	WARRANTY CARD BROTHER RUS (RUS)	1000010023
12	X57521021	NEEDLE PACKAGE (1PCE) (EXCEPT: USA, CAN, BRA120V, TWN)			XE5652001	WARRANTY CARD BROTHER ARG (ARG)	1000011223
13	<del>X58604001</del>	NEEDLE SET (KOREA)	DEL		XE4548001	WARRANTY CARD BR HSM (BRA)	1000007560
14	130920021	EXTRA SPOOL PIN (EXCEPT: LX-3125)			XA6351221	WARRANTY CARD (LS-2920, SL-7: ITA)	
15	XA3442121	FEED DOG COVER			LW3135001	CEE WARRANTY CARD (EEU)	1000011500
16	XC4487021	ACCESSORY BAG (EXCEPT: LS-2125i, LX-3125)			XD1328021	WARRANTY CARD CHINA (CHN)	050203
17	<del>XA5771051</del>	SCISSORS	DEL	19	XA2112022	DUST COVER ASSY (EXCEPT: USA, CAN) (LS-2720, 2820, 2920, 2020, 2725, 2825)	
	X59371021	NARROW HEMMER FOOT (LS-1520: USA, LS-2125b, LS-2129, LS-2160: IND)	040115		130800021	BAG 230X310H (EXCEPT: LS-2720: KOR)	1000011228
	X59372021	BLIND STITCH FOOT (LS-1520: USA, LS-2125b)	040115		XA7201021	USER'S MANUAL (LS-1520: USA, LS-2125b)	040105
	XA3805021	1/4" QUILTING FOOT (LS-2129, LS-2125b)			XC2067121	USER'S MANUAL (LS-2129, LS-2125b)	060039
18	XE1129001	INSTRUCTION BOOK (LS-1520/2125: UK/SPA/EEU/AUS/SIN/ FIN/MYS, LS-2020/2720: USA/CAN/ IRE/UK/POR/RUS/SIN, LS-2725/2820: SIN, LS-2920: SPA, LS-2160: SIN/IND, VX-1435, X-5: SPA/FIN, JS-23:UK/FIN, SL-7: FIN)	1000009864		XA8545121	QUICK REFERENCE GUIDE (LS-2125: USA/ARG/CHL/TWN, LS-2720: USA/CAN, LS-1520, LS2125b, LS-2125i, VX-1435, LS-2130)	
	XE0529001	INSTRUCTION BOOK (EEU)	060052		XE4594001	QUICK REFERENCE GUIDE (LS-2125i: USA)	1000008043
	XC6790121	INSTRUCTION BOOK (LS-2125: USA/CAN/ARG/CHL, LS-2125b/2129)	050285		XE5240101	QUICK REFERENCE GUIDE (LX-3125: USA)	1000009613
	194404013	INSTRUCTION BOOK (CHN)			XE4764001	QUICK REFERENCE GUIDE (EEU) (Cesko)	
	XC7075021	INSTRUCTION BOOK (DEN)	050197		XE4765001	QUICK REFERENCE GUIDE (EEU) (Hungary)	
	XD1215121	INSTRUCTION BOOK (RUS, X-5: UK) (EXCEPT: LS-2720:	050281		XE4766001	QUICK REFERENCE GUIDE (EEU) (Poland)	
	XE1335001	INSTRUCTION BOOK (FIN)	060131		XE4767001	QUICK REFERENCE GUIDE (EEU) (Romania)	
	194404012	INSTRUCTION BOOK (GER, FRA, HOL, AUS ITA, SWI) (EXCEPT: LS-2125: AUS)			XE4768001	QUICK REFERENCE GUIDE (EEU) (Bulgaria)	
	XE3371201	INSTRUCTION BOOK (TWN)	1000010031		XC6911021	ACCINFO SHEET (USA, CAN) (LS-2125, 2129, 2125i, 2130, 2125b)	1000001713
					XC1885021	MANUAL (LS-1520: USA, LS-2129, LS-2125b, LS-2160: IND)	
					XC2127021	MANUAL (FIN)	
					XC2128021	MANUAL (FIN)	
					XE4988001	INSERTION (CAN) (LS-2125, LS-2129)	1000008451



## (6) OTHER PARTS

No.	CODE	NAME	REMARKS	No.	CODE	NAME	REMARKS
	XD0256121	INSERTION WEEE (EUROPE, AUS) (EXCEPT: RUS, LS-2920: SPA, LS-2125: AUS)		20	XE6111001	COLOR CARTON (VX-1435: USA)	
	<b>XE6308001</b>	<b>INNOV-IS RANGE PROMOTION DVD (EUROPE) (LS-2125, JS-23, X-5, SL-7)</b>	<b>1000013646</b>		XD0834027	COLOR CARTON (JS-23: ITA, SWI)	
	XE4888001	NOT RETURN INSERTION SHEET (LS-2125i: USA)	1000008043		XD0834028	COLOR CARTON (JS-23: UK, FIN, RUS, SPA)	
	XE5844001	INSTRUCTION DVD NTSC ASSY (LX-3125: USA)	1000010882		XE3427001	COLOR CARTON (TWN)	1000004114
	XE6078001	INSTRUCTION DVD PAL ASSY (LS-2125: AUS)	1000012338		X61674043	CARTON (SL-7: ITA, FIN)	
	<b>XE5610101</b>	<b>WARRANTY CARD 2YEARS ITA (ITA)</b>	<b>1000013378</b>		X61674045	CARTON (SL-7: RUS)	1000003775
	<b>XE5609101</b>	<b>WARRANTY CARD 5YEARS ITA (ITA)</b>	<b>1000013378</b>		XE5159001	COLOR CARTON (LS-2160: AUS/SIN/TWN/MYS/TUR/IND)	1000009861
20	X60360037	COLOR CARTON (LS-2720: USA, CAN)		21	X61509120	403SF ASSY (EXCEPT: LS2720:KOR)	1000010299
	X61211046	CARTON (LS-2720: EUROPE)			XE2342001	PS FOAM PAD ASSY 407 (LS-2130, LX-3125)	1000008671
	X61674032	CARTON (LS-2720: SIN)			XE5613001	MOLD PAD TOP (LS2720:KOR)	1000010299
	XE5623001	COLOR CARTON (LS-2720: KOR)	1000010299		XE5614001	MOLD PAD BOTTOM (LS2720:KOR)	1000010299
	X61674039	CARTON (LS-2720: CHN)		22	<b>X60439121</b>	<b>BAG 630X630T</b>	<b>1000013192</b>
	X61674035	CARTON (LS-2725)			X60726020	FOOT CONTROLLER BOX	
	X61674022	CARTON (LS-2820: FRA, AUS)			LA6041001	SECURITY TAG (LS-2125: USA, CAN, LS-2129, LS-2130, LS-2125b, LS-2125i, LX-3125, LS-1520: USA)	1000008671
	X61674029	CARTON (LS-2820: SIN)			X55608177	UPC CODE LABEL (LS-2125: ARG, CHL)	
	X61674037	CARTON (LS-2825)			X57325021	LABEL (LS-2125: ARG, CHL, LS-2020, LS-2720, LS-2820: SIN, SL-7, X-5: UK, RUS)	
	X61674027	CARTON (LS-2920)			X60352020	ACCESSORY TABLE PRESSER D (USA, CAN, EUROPE, CHN, AUS) (LS-1520, 2720, 2920, 2725, 2820, 2825)	
	X60360074	COLOR CARTON (LS-1520: USA)			XE5479001	CONTROLLER RAD D (LX-3125)	1000009581
	X60360039	COLOR CARTON (LS-1520: CAN)			XE5241001	NEEDLE PLATE FIXING METAL	1000008671
	X61674034	CARTON (LS-2020)			XZ5028001	NEEDLE BAR PAD D (EXCEPT: LX3125:USA)	1000011737
	X60360046	COLOR CARTON (LS-2125: USA, CAN)			XE5933001	TOP PAD D (LX-3125: USA)	1000011456
	X61674041	CARTON (LS-2125: ARG, CHL)			XE6077001	NH FOOT STICKER (LS-2160: IND)	
	XD0834023	COLOR CARTON (LS-2125: FRA, ITA, EEU)	050218		XD0242021	DVD STICKER (LS-2125: AUS)	1000012338
	XD0834024	COLOR CARTON (LS-2125: UK, SPA, FIN, RUS, SIN, AUS)	050217				
	XE6110001	COLOR CARTON (LS-2125i: USA)	1000012623				
	XE3903001	COLOR CARTON (LS-2125i: BRA)	1000006416				
	XD0834025	COLOR CARTON (LS-2125b)					
	X60360047	COLOR CARTON (LS-2129)					
	XE2463001	COLOR CARTON (LS-2130)	1000008671				
	XE6112001	COLOR CARTON (LX-3125)	1000012623				
	XE3660001	COLOR CARTON (LS-2150)	1000005185				
	XE3268001	COLOR CARTON (X-5: ITA, FIN)	1000005722				
	X61674046	CARTON (X-5: UK)					
	X61674048	CARTON (X-5: SPA)					
	X61674044	CARTON (X-5: RUS)	1000003775				







LS-2720/2820/2920/2725/2825/1520/2129/2125/2125b/2125i/2130/2150/2160  
SL-7/JS-23/VX-1435/X-5/LX-3125  
HF885405/407

12. 2003.  
04. 2009.