

# LCLS Digital BPM

Converting the BPM Trigger input from NIM to TTL.

1. Remove transformer T2
2. Jumper pin 6 to 1

