

Save/Restore

IOCs

FTOF High Voltage

Save/Restore HV Settings

Sector ON/OFF

S1

S2

S3

S4

S5

S6

ALL ON/OFF

Panel 1A

Panel 2

Sector 1

L

R



Sector 2

L


R



Sector 1

L

R



Sector 2

L

R

