

No.	FM Fault Module LED off	CM Control Module LED	SCRCP Line/Grnd Protection Module LED Off	Remote Fault Line	Diagnosis	Description/Corrective Measure
S T A T U S L E D S		Standby (SBY)		SBY		This LED is "On" before the start is completed, if the regulator temp is not O.K.
		Local/Remote		R/L		One or the other LED is "On" depending on the local or remote mode selected
		Curr Control (CC)		C/V		CC is always "On" because the PS operates only in Curr. Mode
		Normal/ Reverse Polarity (NPOL-RPOL)		FW1 or FW2		One or the other are always "On" indicating the output polarity switch (SW) position. Only during transient are both "OFF"
		Board Interlock (BINT)		BINK 2		"On" if any of the Eurocard modules are not properly placed in the rack