

# **Solid State Logic**

**SL4000/6000 Series**

**ULTIMATION™**

**Service Manual**

82S6D678

# **Solid State Logic**

**Oxford • Paris • Milan • New York • Los Angeles  
Toronto • Tokyo**

Begbroke, Oxford, England OX5 1RU • (0) 865 842300  
1 rue Michael Faraday, 78180 Montigny le Bretonneux, France • (1) 34 60 46 66  
Via Cesare Cantu' 1, 20092 Cinisello Balsamo, Milan • (2) 612 17 20  
320 West 46th Street, New York, NY 10036 • (212) 315-1111  
6255 Sunset Boulevard, Los Angeles, California 90028 • (213) 463-4444  
248 The Esplanade, Toronto, Ontario M5A 4J6 • (416) 363-0101  
3-55-14 Sendagaya, Shibuya-ku, Tokyo 151 • (3) 5474-1144

© 1991 by Solid State Logic Limited  
A Carlton Company

All Rights Reserved under International and Pan-American Copyright Conventions  
SSL and ULTIMATION™ are Registered Tradenames of Solid State Logic Limited

No part of this publication may be reproduced in any form or  
by any means, whether mechanical or electronic, without the  
written permission of Solid State Logic Ltd., Oxford, England.

*As research and development is a continual process, Solid State Logic reserves the right  
to change the features and specifications described herein without notice or obligation.*

# **INDEX**

- 1. Introduction and System Overview**
- 2. Console Service Information**
- 3. Studio Computer Service Information**
- 4. Power Supply Service Information**
- 5. Connector Information**
- 6. Operator's Manual**

## INDEX

1. Introduction and System Overview
2. Console Service Information
3. Studio / Computer Service Information
4. Power Supply Service Information
5. Console Information
6. Appendix: Manual