

Lixie Universal Tuner	Version <b>Final</b>	1 / 3
Project Course 2019-2020	Last saved by J������ Lesauvage / 10 March 2020	LUT_FINAL_UserGuide.docx

# LIXIE UNIVERSAL TUNER

User Guide  
Version Final

**Project Manager:**

J       Lesauvage (jeremy.lesauvage@abo.fi)

**Project Members:**

Thibault Cormery (thibault.cormery@abo.fi)

Andreas Salminen (andreas.salminen@abo.fi)


Marine Poidevin (marine.poidevin@abo.fi)

Oscar Schauman (cschauma@abo.fi)

Benjamin Heinonen (benjamin.heinonen@abo.fi)

GitHub: <https://github.com/JeremyLesauvage/LUT-Lixie-Universal-Tuner>

## 1. Part Description



1: **Power switch**, Turn on and off the device.

2: **Lixie display**, show the accuracy of the played note.

3: **LCD screen** display the note played the frequency, the mode and the reference frequency.

4: **The microphone**.

5: **Toggle switch**, select between UP reference frequency DOWN mode.

6: **Push button**, change the selected value.

## 2. Quick start guide

### 1 Turn on the device

Press the power switch



### 2 Verify the Lixie and the LCD light-up

If not check the state of the battery  
With no sound or noise the Lixie should be white and the frequency should display 0Hz




### 3 Play your instrument

You will notice the tuner react to your playing.



### 4 (optional) change the mode

Put the toggle switch to the DOWN position  
Press the push button to select the desired mode



### 5 (optional) change the reference

Put the toggle switch to the UP position  
Press the push button to select the desired reference



### 6 Turn off the device

Press the power switch

