

oDesktop

AddMessage	ClearMessages	CloseAllWindows
CloseProject	CloseProjectNoForce	DeleteProject
DoesRegistryValueExist	DownloadJobResults	EnableAutoSave
ExportOptionsFiles	GetActiveProject	GetAutoSaveEnabled
GetBuildDateTimeString	GetDefaultUnit	GetDistributedAnalysisMachines
GetDistributedAnalysisMachinesForDesignType	GetExeDir	GetGDIObjectCount
GetLibraryDirectory	GetLocalizationHelper	GetMessages
GetPersonalLibDirectory	GetProcessID	GetProjectDirectory
GetProjectList	GetProjects	GetRegistryInt
GetRegistryString	GetScriptingToolsHelper	GetSysLibDirectory
GetTempDirectory	GetTool	GetUserLibDirectory
GetVersion	LaunchJobMonitor	NewProject
OpenAndConvertProject	OpenMultipleProjects	OpenProject
OpenProjectWithConversion	PageSetup	PauseRecording
PauseScript	Print	QuitApplication
RefreshJobMonitor	ResetLogging	RestoreProjectArchive
RestoreWindow	ResumeRecording	RunACTWizardScript
RunProgram	RunScript	RunScriptWithArguments
SelectScheduler	SetActiveProject	SetActiveProjectByPath
SetLibraryDirectory	SetProjectDirectory	SetRegistryFromFile
SetRegistryInt	SetRegistryString	SetTempDirectory
ShowDockingWindow	Sleep	SubmitJob
TileWindows		

oProject

AddDataset	AddMaterial	AnalyzeAll
ChangeProperty	ClearMessages	CloneMaterial
Close	CopyDesign	CutDesign
DeleteDataset	DeleteDesign	DeleteToolObject
EditDataset	EditMaterial	ExportDataset
ExportMaterial	GetActiveDesign	GetArrayVariables
GetConfigurableData	GetDefinitionManager	GetDependentFiles
GetDesign	GetDesigns	GetEDBHandle
GetLegacyName	GetName	GetPath
GetProperties	GetPropertyValue	GetTopDesignList
GetVariableValue	GetVariables	ImportDataset
InsertDesign	InsertDesignWithWorkflow	InsertToolObject
Paste	PasteDesignBlock	Redo
RemoveAllUnusedDefinitions	RemoveMaterial	RemoveUnusedDefinitions
Rename	Save	SaveAs
SaveAsStandAloneProject	SaveProjectArchive	SetActiveDefinitionEditor
SetActiveDesign	SetPropertyValue	SetVariableValue
SimulateAll	Undo	UpdateDefinitions

oDefinitionManager

AddComponent	AddDataset	AddFootprint
--------------	------------	--------------

AddMaterial
AddSurfaceMaterial
CloneMaterial
DoesMaterialExist
EditDataset
EditPadstack
EditSymbol
ExportFootprint
ExportScript
GetInUseProjectMaterialNames
GetProjectMaterialNames
ImportDataset
RemoveFootprint
RemoveScript
SetPropertyValue

AddPadstack
AddSymbol
CreateComponentData
DoesSurfaceMaterialExist
EditFootprint
EditScript
ExportComponent
ExportMaterial
ExportSurfaceMaterial
GetManager
GetProperties
ModifyLibraries
RemoveMaterial
RemoveSurfaceMaterial
UpdateDefinition

AddScript
ChangeProperty
DeleteDataset
EditComponent
EditMaterial
EditSurfaceMaterial
ExportDataset
ExportPadstack
ExportSymbol
GetMaterialNamesInConfiguredLibraries
GetPropertyValue
RemoveComponent
RemovePadstack
RemoveSymbol
UpdateDefinitionFromLib

oDesign

AddDataset
AnalyzeAllNominal
ClearLinkedData
CreateParametricCircuit
DeleteFullVariation
EditDataset
ExportConvergence
ExportProfile
GetConfigurableData
GetDesignValidationInfo
GetName
GetPostProcessingVariables
GetSolutionType
GetVariationVariableValue
Is2D
Redo
SetConductivityThreshold
SetObjectTemperature
SetVariableValue
StopSimLink
ValidateLink

Analyze
ApplyMeshOps
ConstructVariationString
DeleteDataset
DeleteLinkedDataVariation
EditNotes
ExportDataset
GenerateMesh
GetData
GetManagedFilePath
GetNominalVariation
GetProperties
GetVariableValue
ImportDataset
Is3D
RenameDesignInstance
SetDesignSettings
SetPropertyValue
SimulateLink
Undo

AnalyzeAll
ChangeProperty
Create2DDesign
DeleteFieldVariation
DeleteVariation
EnableHarmonicForceCalculation
ExportMeshStats
GetArrayVariables
GetDesignType
GetModule
GetNoteText
GetPropertyValue
GetVariables
InitializeSystemCoupling
Paste
SetActiveEditor
SetObjectDeformation
SetSolutionType
Solve
ValidateDesign

Editor

AddViewOrientation
AssignSurfaceMaterial
ChangeProperty
Connect
CoverSurfaces
CreateBox
CreateCone
CreateEllipse
CreateEquationSurface
CreateHelix

AlignFaces
BreakUDMConnection
CleanUpModel
Copy
Create3DComponent
CreateCircle
CreateCutplane
CreateEntityList
CreateFaceCS
CreateObjectCS

AssignMaterial
Chamfer
CloseAllWindows
CoverLines
CreateBondwire
CreateComponent
CreateCylinder
CreateEquationCurve
CreateGroup
CreateObjectFromEdges

CreateObjectFromFace	CreateObjectFromFaces	CreatePoint
CreatePolyline	CreateRectangle	CreateRegion
CreateRegularPolygon	CreateRegularPolyhedron	CreateRelativeCS
CreateSphere	CreateSpiral	CreateTorus
CreateUserDefinedModel	CreateUserDefinedPart	CustomGeometryOperation
Defeature	DeletPolylinePoint	Delete
DeleteEmptyGroups	DeleteLastOperation	DeleteOperation
DeletePolylinePoint	DetachEdge	DetachEdges
DetachFace	DetachFaces	DoModalValidationForTest
DoesGeometryMatchForTest	DuplicateAlongLine	DuplicateAroundAxis
DuplicateMirror	Edit3DComponent	Edit3DComponentDefinition
EditEntityList	EditFaceCS	EditNativeComponentDefinition
EditObjectCS	EditPolyline	EditRelativeCS
Export	ExportGDSII	ExportModelImageToFile
Fillet	FitAll	FlattenGroup
GenerateAllUserDefinedModels	GenerateFacetDataForModel	GenerateHistory
GenerateUserDefinedModel	Get3DComponentDefinitionNames	Get3DComponentInstanceNames
Get3DComponentMaterialNames	Get3DComponentMaterialProperties	Get3DComponentParameters
Get3DComponentPartNames	GetActiveCoordinateSystem	GetBodyNamesByPosition
GetCoordinateSystems	GetEdgeByPosition	GetEdgeIDFromNameForFirstOperation
GetEdgeIDsFromFace	GetEdgeIDsFromObject	GetEdgeLength
GetEdgePositionAtNormalizedParameter	GetEntityListIDByName	GetFaceArea
GetFaceByPosition	GetFaceCenter	GetFaceIDFromNameForFirstOperation
GetFaceIDs	GetFaceIDsOfSheet	GetFullGeometry
GetGeometryModelerMode	GetGroupSubmodelNames	GetMatchedObjectName
GetModelBoundingBox	GetModelDrawAttributes	GetModelUnits
GetNumObjects	GetObjectIDByName	GetObjectName
GetObjectNameByEdgeID	GetObjectNameByFaceID	GetObjectNameByID
GetObjectNameByVertexID	GetObjectShapeType	GetObjectsByMaterial
GetObjectsInGroup	GetOperationIndex	GetPartsForUserDefinedModel
GetPoints	GetProperties	GetPropertyValue
GetRelativeCoordinateSystems	GetSelections	GetSubGroupsInGroup
GetUserPosition	GetVertexIDFromNameForFirstOperation	GetVertexIDsFromEdge
GetVertexIDsFromFace	GetVertexIDsFromObject	GetVertexPosition
GetWireBodyNames	HealObject	Import
ImportDXF	ImportFromClipboard	ImportGDSII
Imprint	ImprintProjection	Insert3DComponent
InsertComponent	InsertNativeComponent	InsertPolylineSegment
Intersect	Make3DComponentIndenpendent	Mirror
Move	MoveCSToEnd	MoveEdges
MoveEntityToGroup	MoveFaces	ObjectExists
OffsetFaces	OpenExternalEditor	PageSetup
Paste	PerformExplicitSubtractions	ProjectSheet
ProjectUDPPParametersToValidPlane	ProjectUDPPParametersToValidPlane2	PurgeHistory
RefreshAllUserDefinedModelFrom	RefreshUserDefinedModelFrom	RefreshUserDefinedModelTo
RemoveBadEdges	RemoveBadFaces	RemoveBadVertices
RenamePart	ReplaceWith3DComponent	Rotate
Scale	Section	SendParametersAndGenerateUserDefineModel
SeparateBody	SetModelUnits	SetModelValidationSettings
SetPropertyValue	SetTopDownViewDirectionForActiveView	SetTopDownViewDirectionForAllViews
SetWCS	ShowWindow	Simplify
Split	Stitch	Subtract

SweepAlongPath
SweepFacesAlongNormal
UncoverFaces
UpdateComponentDefinition
Validate3DComponent
WriteHistoryTreeLayoutForTest

SweepAlongVector
SweepFacesAlongNormalWithAttributes
Ungroup
UpdatePriorityList
WrapSheet

SweepAroundAxis
ThickenSheet
Unite
UpgradeVersion
WriteAttributesBlockForTest

oTool-NdExplorer

CheckCausality
ExportNetworkData

ExportFullWaveSpice
ExtractImpulseResponse

ExportNMFData
SetExportTouchstoneOptions

oTool-ImportExport

ImportANF
ImportAutoCAD
ImportGDSII
ImportIDFandMerge
ImportXFL

ImportANFV2
ImportEDB
ImportGerber
ImportIPC

ImportAWRMicrowaveOffice
ImportExtracta
ImportIDF
ImportODB

oModule-BoundarySetup

AddAssignmentToBoundary
AssignCharge
AssignCurrent
AssignCurrentDensityTerminal
AssignCylindricalHField
AssignImpedance
AssignMaster
AssignResistiveSheet
AssignSymmetry
AssignVoltageAPhi
AssignVoltageDropGroup
AssignWindingGroup
DeleteAllBoundaries
EditCharge
EditCurrentDensity
EditExternalCircuit
EditFluxTangential
EditIntegratedZeroTangentialHField
EditRadiation
EditSlave
EditVoltage
EditVolumeChargeDensity
GetAssignment
GetCoreLossEffect
GetEddyEffect
GetNumBoundaries
GetNumExcitationsOfType
RemoveTerminalFromWinding
SetCoreLoss
SetMinimumTimeStep

AddTerminalstoWinding
AssignCoilTerminal
AssignCurrentDensity
AssignCurrentDensityTerminalGroup
AssignFloating
AssignInsulating
AssignPermanentMagnetField
AssignSink
AssignTangentialHField
AssignVoltageAPhiGroup
AssignVoltageGroup
AssignZeroTangentialHField
DeleteAllExcitations
EditCoilTerminal
EditCurrentDensityTerminal
EditExternalSimulinkCircuit
EditImpedance
EditMaster
EditResistiveSheet
EditSymmetry
EditVoltageAPhi
EditWindingGroup
GetBoundaries
GetCoreLossEffectOnField
GetExcitations
GetNumBoundariesOfType
ReassignBoundary
RenameBoundary
SetEddyEffect

AddWindingTerminals
AssignCoilTerminalGroup
AssignCurrentDensityGroup
AssignCurrentGroup
AssignFluxTangential
AssignIntegratedZeroTangentialHField
AssignRadiation
AssignSlave
AssignVoltage
AssignVoltageDrop
AssignVolumeChargeDensity
ComputeOperatingPoints
DeleteBoundaries
EditCurrent
EditCylindricalHField
EditFloating
EditInsulating
EditPermanentMagnetField
EditSink
EditTangentialHField
EditVoltageDrop
EditZeroTangentialHField
GetBoundariesOfType
GetDisplacementCurrent
GetExcitationsOfType
GetNumExcitations
RemoveAssignmentFromBoundary
ReprioritizeBoundaries
SetMagnetizationCompute

oModule-MeshSetup

AssignApplyCurvilinearElementsOp	AssignCloneOp	AssignCurvatureExtractionOp
AssignCylindricalGapOp	AssignDefeatureOp	AssignDensityControlOp
AssignEdgeCutLayerOp	AssignLengthOp	AssignModelResolutionOp
AssignRotationalLayerOp	AssignSkinDepthOp	AssignSurfPriorityForTauOp
AssignTrueSurfOp	DeleteOp	EditApplyCurvilinearElementsOp
EditCloneOp	EditCurvatureExtractionOp	EditCylindricalGapOp
EditDefeatureOp	EditDensityControlOp	EditEdgeCutLayerOp
EditLengthOp	EditModelResolutionOp	EditRotationalLayerOp
EditSkinDepthOp	EditSurfPriorityOp	EditTrueSurfOp
GetOperationNames	InitialMeshSettings	ReassignOp
RenameOp		

oModule-AnalysisSetup

ClearLinkedData	ConfigureFluentConductivityCoupling	CopySetup
DeleteSetups	EditSetup	ExportCircuit
ExportECEData	ExportSolnData	GetSetups
InsertMeshLinkedSetup	InsertSetup	PasteSetup
RenameSetup	ResetAllToTimeZero	ResetSetupToTimeZero
RevertAllToInitial	RevertAllToInitialTemperature	RevertAllToZeroDisplacement
RevertSetupToInitial	RevertSetupToInitialTemperature	RevertSetupToZeroDisplacement

oModule-Optimetrics

CopySetup	DeleteSetups	DistributedAnalyzeSetup
EditSetup	EnableSetup	ExportDOELocalSensitivity
ExportDOELocalSensitivityCurve	ExportDOEResponseCurve	ExportDOEResponseCurveSlices
ExportDOEResponseSurface	ExportDXConfigFile	ExportOptimetricsProfile
ExportOptimetricsResult	ExportParametricResults	ExportRespSurfaceMinMaxTable
ExportRespSurfacePlotToFile	ExportRespSurfaceRefinePoints	ExportRespSurfaceResponsePoints
ExportRespSurfaceVerificationPoints	GenerateVariationData	GetOptimetricResult
GetOptimetricResultRowCount	GetSetupNames	GetSetupNamesByType
ImportSetup	InsertSetup	PasteSetup
RenameSetup	SolveAllSetup	SolveSetup

oModule-Solutions

DeleteSolutionVariation	FFTONReport	GetAvailableVariations
GetValidISolutionList	TDRONReport	

oModule-FieldsReporter

AddMarker	AddMarkerToPlot	AddNamedExpr
AddNamedExpression	CalcOp	CalcRead
CalcStack	CalcWrite	CalculatorRead
CalculatorWrite	ChangeGeomSettings	ClcEval
ClcMaterial	ClcMaterialValue	ClearAllMarkers
ClearAllNamedExpr	CopyNamedExprToStack	CreateFieldPlot

DeleteFieldPlot	DeleteMarker	DeleteNamedExpr
DeleteUneditablePlot	DoesNamedExpressionExists	DumpCalculatorStack
EnterComplex	EnterComplexVector	EnterCoord
EnterEdge	EnterLine	EnterOutputVar
EnterPoint	EnterQty	EnterScalar
EnterScalarFunc	EnterSurf	EnterVector
EnterVectorFunc	EnterVol	ExportFieldPlot
ExportMarkerTable	ExportOnGrid	ExportPlotImageToFile
ExportToFile	GetFieldFolderNames	GetFieldPlotNames
GetMeshPlotNames	GetTopEntryValue	HideAntennaParameterOverlay
HidePolarPlot	HideRadiatedPlotOverlay	LoadNamedExpressions
ModifyFieldPlot	ReassignFieldPlot	RenameFieldPlot
RenamePlotFolder	SaveFieldsPlots	SaveNamedExpressions
SetFieldPlotSettings	SetFieldTypeSettings	SetPlotFolderSettings
SetPlotsSolutionContext	SetPlotsViewSolutionContext	ShowAntennaParameterOverlay
ShowPolarPlot	ShowRadiatedPlotOverlay	Test
UpdateAllFieldsPlots	UpdateQuantityFieldsPlots	XForm

oModule-ReportSetup

AddAllEyeMeasurements	AddCartesianLimitLine	AddCartesianLimitLineFromCurve
AddCartesianLimitLineFromEquation	AddCartesianXMarker	AddCartesianYMarker
AddCartesianYMarkerToStack	AddDeltaMarker	AddMarker
AddNote	AddTraceCharacteristics	AddTraces
ApplyReportTemplate	ChangeProperty	ClearAllMarkers
ClearAllTraceCharacteristics	CloneReportsFromDatasetSolution	CompareReportDataForRegressionTesting
CompareReportDataForRegressionTesting2	CompareTracesForRegressionTesting	CompareTracesForRegressionTesting2
CopyPlotSettings	CopyReportDefinitions	CopyReportsData
CopyTraceDefinitions	CopyTracesData	CreateReport
CreateReportFromFile	CreateReportFromTemplate	CreateReportOfAllQuantities
DeleteAllReports	DeleteReports	DeleteTraceCharacteristics
DeleteTraces	DoesSupportTraceCharacteristics	DumpAllReportsData
DumpReportDataForRegressionTesting	EditCartesianXMarker	EditCartesianYMarker
EditMarker	ExportEyeMaskViolation	ExportImageToFile
ExportReportDataToFile	ExportTableToFile	ExportToFile
ExportUniformPointsToFile	GetAllCategories	GetAllQuantities
GetAllReportNames	GetAvailableDisplayTypes	GetAvailableReportTypes
GetAvailableSolutions	GetDisplayType	GetDynLinkIntrinsicVariables
GetDynLinkQtyData	GetDynLinkQtyValueState	GetDynLinkTraces
GetDynLinkVariableValues	GetPropertyValue	GetQtyExpressionsForSourceTrace
GetReportSummaryForRegressionTesting	GetReportTraceNames	GetSolutionContexts
GetSolutionDataPerVariation	GroupPlotCurvesByGroupingStrategy	ImportIntoReport
ImportReportDataIntoReport	MovePlotCurvesToGroup	MovePlotCurvesToNewGroup
OpenWindowForAllReports	OpenWindowForReports	PastePlotSettings
PasteReports	PasteReportsWithLegacyNames	PasteTraces
PasteTracesWithLegacyNames	RenameReport	RenameTrace
ResetPlotSettings	SavePlotSettingsAsDefault	SetLinkOutputTraces
UngroupPlotCurvesInGroup	UpdateAllReports	UpdateReports
UpdateTraces	UpdateTracesContextAndSweeps	

oModule-OutputVariable

CreateOutputVariable
EditOutputVariable
GetOutputVariables

DeleteOutputVariable
ExportOutputVariables
ImportOutputVariables

DoesOutputVariableExist
GetOutputVariableValue

oModule-UserDefinedSolutionModule

CreateUserDefinedSolution
GetUserDefinedSolutionNames

DeleteUserDefinedSolutions
GetUserDefinedSolutionProperties

EditUserDefinedSolution