

oDesktop

AddMessage	ClearMessages	CloseAllWindows
CloseProject	CloseProjectNoForce	DeleteProject
DoesRegistryValueExist	DownloadJobResults	EnableAutoSave
ExportOptionsFiles	GetActiveProject	GetAutoSaveEnabled
GetBuildDateTimeString	GetDefaultUnit	GetDistributedAnalysisMachines
GetDistributedAnalysisMachinesForDesignType	GetExeDir	GetGDIObjectCount
GetLibraryDirectory	GetLocalizationHelper	GetMessages
GetPersonalLibDirectory	GetProcessID	GetProjectDirectory
GetProjectList	GetProjects	GetRegistryInt
GetRegistryString	GetScriptingToolsHelper	GetSysLibDirectory
GetTempDirectory	GetTool	GetUserLibDirectory
GetVersion	LaunchJobMonitor	NewProject
OpenAndConvertProject	OpenMultipleProjects	OpenProject
OpenProjectWithConversion	PageSetup	PauseRecording
PauseScript	Print	QuitApplication
RefreshJobMonitor	ResetLogging	RestoreProjectArchive
RestoreWindow	ResumeRecording	RunACTWizardScript
RunProgram	RunScript	RunScriptWithArguments
SelectScheduler	SetActiveProject	SetActiveProjectByPath
SetLibraryDirectory	SetProjectDirectory	SetRegistryFromFile
SetRegistryInt	SetRegistryString	SetTempDirectory
ShowDockingWindow	Sleep	SubmitJob
TileWindows		

oProject

AddDataset	AddMaterial	AnalyzeAll
ChangeProperty	ClearMessages	CloneMaterial
Close	CopyDesign	CutDesign
DeleteDataset	DeleteDesign	DeleteToolObject
EditDataset	EditMaterial	ExportDataset
ExportMaterial	GetActiveDesign	GetArrayVariables
GetConfigurableData	GetDefinitionManager	GetDependentFiles
GetDesign	GetDesigns	GetEDBHandle
GetLegacyName	GetName	GetPath
GetProperties	GetPropertyValue	GetTopDesignList
GetVariableValue	GetVariables	ImportDataset
InsertDesign	InsertDesignWithWorkflow	InsertToolObject
Paste	PasteDesignBlock	Redo
RemoveAllUnusedDefinitions	RemoveMaterial	RemoveUnusedDefinitions
Rename	Save	SaveAs
SaveAsStandAloneProject	SaveProjectArchive	SetActiveDefinitionEditor
SetActiveDesign	SetPropertyValue	SetVariableValue
SimulateAll	Undo	UpdateDefinitions

oDefinitionManager

AddComponent	AddDataset	AddFootprint
AddMaterial	AddPadstack	AddScript
AddSurfaceMaterial	AddSymbol	ChangeProperty
CloneMaterial	CreateComponentData	DeleteDataset
DoesMaterialExist	DoesSurfaceMaterialExist	EditComponent
EditDataset	EditFootprint	EditMaterial
EditPadstack	EditScript	EditSurfaceMaterial
EditSymbol	ExportComponent	ExportDataset
ExportFootprint	ExportMaterial	ExportPadstack
ExportScript	ExportSurfaceMaterial	ExportSymbol
GetInUseProjectMaterialNames	GetManager	GetMaterialNamesInConfiguredLibraries
GetProjectMaterialNames	GetProperties	GetPropertyValue
ImportDataset	ModifyLibraries	RemoveComponent
RemoveFootprint	RemoveMaterial	RemovePadstack
RemoveScript	RemoveSurfaceMaterial	RemoveSymbol
SetPropertyValue	UpdateDefinition	UpdateDefinitionFromLib

oDesign

AddCompInstance	AddDataset	AddDesignVariablesForDynamicLink
AddOutputVariable	AddSoDConfig	Analyze
AnalyzeAll	AnalyzeAllNominal	ApplySoDConfig
ChangePortProperty	ChangeProperty	ChangeSourceProperty
CopyEyeItemAsCommand	CopyItemCommand	CreateIOBuffers
CreateReport	DeleteCompInstance	DeleteDataset
DeleteDesignInstance	DeleteOutputVariable	DeletePort
DeleteSoDConfig	DeleteSolutionVariation	DeleteSource
DisplayBiasPointInfo	EditDataset	EditDesignOptions
EditImportData	EditNotes	EditOutputVariable
EditSoDConfig	EnableSolutionSetup	ExportDataset
ExportDesignPoint	ExportForHSpice	ExportForSpice
ExportNMFData	ExportNetlist	ExportNetworkData
ExportNetworkDataWithNoise	ExportReport	GetActiveEditor
GetAllPorts	GetAllReports	GetAllSources
GetConfigurableData	GetData	GetDesignType
GetDiagnostics	GetEditor	GetModule
GetName	GetNoteText	GetOutputVariableValue
GetOutputVariables	GetPropHost	GetProperties
GetPropertyValue	GetResultsDirectory	GetSourceData
GetVariableValue	GetVariables	ImportData
ImportDataFilePath	ImportDataset	InsertDesign
InvalidateAllSolutions	InvalidateSolution	LoadDiffPairsFromFile
PasteDesign	PasteItemCommand	Redo
RemoveAllReports	RemoveImportData	RemoveReport
RenameDesignInstance	RenameImportData	RenamePort
RenameSoDConfig	RenameSource	RunERCBeforeSimulation
RunToolkit	RunWorkflowkit	SaveDiffPairsToFile
SetActiveEditor	SetDiffPairs	SetPropertyValue
SetVariableValue	SimulateLink	StartAnalysis

StopSimLink
UseCircuitSparameterDefinition

Undo
ValidateLink

UpdateSources

Editor

Activate
AddPinIPorts
AddTerminatorsAtPins
BringToFront
Copy
CreateArc
CreateCurve
CreateGround
CreateLine
CreatePagePort
CreateRectangle
CreateWire
DeactivateShort
DisplayIVCurves
FindElements
FlipHorizontal
GetAllElements
GetAllPorts
GetComponentInfo
GetComponentPins
GetNetConnections
GetProperty
GetSelections
GetWireConnections
GridSetup
MovePins
Pan
PasteDesign
RemoveIVSolution
Rotate
SelectPage
SetPropertyValue
UpdateIVCurves
ZoomIn
ZoomToFit

AddAntennasAtPins
AddPinPageconnectors
AlignHorizontal
ChangePinVisibility
CopyData
CreateCircle
CreateEllipse
CreateIPort
CreateNPort
CreatePlot
CreateSelSubSheet
Cut
Delete
ElectricRuleCheck
FitToBorder
FlipVertical
GetAllGraphics
GetCompInstanceFromInstanceName
GetComponentPinInfo
GetEditorName
GetNumPages
GetPropertyAttribute
GetSignalAttributes
GetWireInfo
ModifyIVCurves
NameNets
Paste
PlaceComponent
RenameIVSolution
SelectAll
SendToBack
ShowVariableBlock
Wire
ZoomOut

AddPinGrounds
AddPlaceComponent
AlignVertical
ChangeProperty
CopySubdesign
CreateComponent
CreateGlobalPort
CreateImage
CreatePage
CreatePolygon
CreateText
DeactivateOpen
DeletePage
ExportImage
FlipComponent
GetAllComponents
GetAllNets
GetCompInstanceFromRefDes
GetComponentPinLocation
GetEvaluatedPropertyValue
GetPortInfo
GetPropertyValue
GetSignals
GetWireSegments
Move
PageBorders
PasteData
PushExcitations
RevertToDefaultSymbol
SelectElement
SetPageData
SortComponents
ZoomArea
ZoomPrevious

oTool-NdExplorer

CheckCausality
ExportNetworkData

ExportFullWaveSpice
ExtractImpulseResponse

ExportNMFData
SetExportTouchstoneOptions

oTool-ImportExport

ImportANF

ImportANFV2

ImportAWRMicrowaveOffice

ImportAutoCAD
ImportGDSII
ImportIDFandMerge
ImportXFL

ImportEDB
ImportGerber
ImportIPC

ImportExtracta
ImportIDF
ImportODB

oModule-SimSetup

AddAMIAAnalysis
AddDCAnalysis
AddHBnTone
AddLinearNetworkAnalysis
AddOscillatorNtoneAnalysis
AddSetup
AddTransient
EditAlterBlock
EditEnvelopeSetup
EditHSPICEAnalysisOptions
EditOscResonantFrequencySearch
EditPXFSetup
EditTVNoise
GetAllSolutionSetups
Remove

AddAlterBlock
AddEnvelopeSetup
AddHSPICEAnalysisOptions
AddOscResonantFrequencySearch
AddPXFSetup
AddSystemFDAnalysis
AddVerifEyeAnalysis
EditAnalysisOptions
EditHB1Tone
EditHSPICETransient
EditOscillatorAnalysis
EditQuickEyeAnalysis
EditTransient
GetSetupData
RemoveSimSetup

AddAnalysisOptions
AddHB1Tone
AddHSPICETransient
AddOscillatorAnalysis
AddQuickEyeAnalysis
AddTVNoise
EditAMIAAnalysis
EditDCAnalysis
EditHBnTone
EditLinearNetworkAnalysis
EditOscillatorNtoneAnalysis
EditSystemFDAnalysis
EditVerifEyeAnalysis
ListVariations
Rename

oModule-Optimetrics

CopySetup
EditSetup
ExportDOELocalSensitivityCurve
ExportDOEResponseSurface
ExportOptimetricsResult
ExportRespSurfacePlotToFile
ExportRespSurfaceVerificationPoints
GetOptimetricResultRowCount
ImportSetup
RenameSetup

DeleteSetups
EnableSetup
ExportDOEResponseCurve
ExportDXConfigFile
ExportParametricResults
ExportRespSurfaceRefinePoints
GenerateVariationData
GetSetupNames
InsertSetup
SolveAllSetup

DistributedAnalyzeSetup
ExportDOELocalSensitivity
ExportDOEResponseCurveSlices
ExportOptimetricsProfile
ExportRespSurfaceMinMaxTable
ExportRespSurfaceResponsePoints
GetOptimetricResult
GetSetupNamesByType
PasteSetup
SolveSetup

oModule-ReportSetup

AddAllEyeMeasurements
AddCartesianLimitLineFromEquation
AddCartesianYMarkerToStack
AddNote
ApplyReportTemplate
ClearAllTraceCharacteristics
CompareReportDataForRegressionTesting2
CopyPlotSettings
CopyTraceDefinitions
CreateReportFromFile
DeleteAllReports

AddCartesianLimitLine
AddCartesianXMarker
AddDeltaMarker
AddTraceCharacteristics
ChangeProperty
CloneReportsFromDatasetSolution
CompareTracesForRegressionTesting
CopyReportDefinitions
CopyTracesData
CreateReportFromTemplate
DeleteReports

AddCartesianLimitLineFromCurve
AddCartesianYMarker
AddMarker
AddTraces
ClearAllMarkers
CompareReportDataForRegressionTesting
CompareTracesForRegressionTesting2
CopyReportsData
CreateReport
CreateReportOfAllQuantities
DeleteTraceCharacteristics

DeleteTraces	DoesSupportTraceCharacteristics	DumpAllReportsData
DumpReportDataForRegressionTesting	EditCartesianXMarker	EditCartesianYMarker
EditMarker	ExportEyeMaskViolation	ExportImageToFile
ExportReportDataToFile	ExportTableToFile	ExportToFile
ExportUniformPointsToFile	GetAllCategories	GetAllQuantities
GetAllReportNames	GetAvailableDisplayTypes	GetAvailableReportTypes
GetAvailableSolutions	GetDisplayType	GetDynLinkIntrinsicVariables
GetDynLinkQtyData	GetDynLinkQtyValueState	GetDynLinkTraces
GetDynLinkVariableValues	GetPropertyValue	GetQtyExpressionsForSourceTrace
GetReportSummaryForRegressionTesting	GetReportTraceNames	GetSolutionContexts
GetSolutionDataPerVariation	GroupPlotCurvesByGroupingStrategy	ImportIntoReport
ImportReportDataIntoReport	MovePlotCurvesToGroup	MovePlotCurvesToNewGroup
OpenWindowForAllReports	OpenWindowForReports	PastePlotSettings
PasteReports	PasteReportsWithLegacyNames	PasteTraces
PasteTracesWithLegacyNames	RenameReport	RenameTrace
ResetPlotSettings	SavePlotSettingsAsDefault	SetLinkOutputTraces
UngroupPlotCurvesInGroup	UpdateAllReports	UpdateReports
UpdateTraces	UpdateTracesContextAndSweeps	

oModule-OutputVariable

CreateOutputVariable	DeleteOutputVariable	DoesOutputVariableExist
EditOutputVariable	ExportOutputVariables	GetOutputVariableValue
GetOutputVariables	ImportOutputVariables	

oModule-UserDefinedSolutionModule

CreateUserDefinedSolution	DeleteUserDefinedSolutions	EditUserDefinedSolution
GetUserDefinedSolutionNames	GetUserDefinedSolutionProperties	

oModule-DV

AddRuleSet	AddRun	DeleteRuleSet
DeleteRun	EditRuleSet	EditRun
RenameRuleSet	RenameRun	RunAllDV
RunAllRuleSetDV	RunDV	