

oDesktop

AddMessage	ClearMessages	CloseAllWindows
CloseProject	CloseProjectNoForce	DeleteProject
DoesRegistryValueExist	DownloadJobResults	EnableAutoSave
ExportOptionsFiles	GetActiveProject	GetAutoSaveEnabled
GetBuildDateTimeString	GetDefaultUnit	GetDistributedAnalysisMachines
GetDistributedAnalysisMachinesForDesignType	GetExeDir	GetGDIObjectCount
GetLibraryDirectory	GetLocalizationHelper	GetMessages
GetPersonalLibDirectory	GetProcessID	GetProjectDirectory
GetProjectList	GetProjects	GetRegistryInt
GetRegistryString	GetScriptingToolsHelper	GetSysLibDirectory
GetTempDirectory	GetTool	GetUserLibDirectory
GetVersion	LaunchJobMonitor	NewProject
OpenAndConvertProject	OpenMultipleProjects	OpenProject
OpenProjectWithConversion	PageSetup	PauseRecording
PauseScript	Print	QuitApplication
RefreshJobMonitor	ResetLogging	RestoreProjectArchive
RestoreWindow	ResumeRecording	RunACTWizardScript
RunProgram	RunScript	RunScriptWithArguments
SelectScheduler	SetActiveProject	SetActiveProjectByPath
SetLibraryDirectory	SetProjectDirectory	SetRegistryFromFile
SetRegistryInt	SetRegistryString	SetTempDirectory
ShowDockingWindow	Sleep	SubmitJob
TileWindows		

oProject

AddDataset	AddMaterial	AnalyzeAll
ChangeProperty	ClearMessages	CloneMaterial
Close	CopyDesign	CutDesign
DeleteDataset	DeleteDesign	DeleteToolObject
EditDataset	EditMaterial	ExportDataset
ExportMaterial	GetActiveDesign	GetArrayVariables
GetConfigurableData	GetDefinitionManager	GetDependentFiles
GetDesign	GetDesigns	GetEDBHandle
GetLegacyName	GetName	GetPath
GetProperties	GetPropertyValue	GetTopDesignList
GetVariableValue	GetVariables	ImportDataset
InsertDesign	InsertDesignWithWorkflow	InsertToolObject
Paste	PasteDesignBlock	Redo
RemoveAllUnusedDefinitions	RemoveMaterial	RemoveUnusedDefinitions
Rename	Save	SaveAs
SaveAsStandAloneProject	SaveProjectArchive	SetActiveDefinitionEditor
SetActiveDesign	SetPropertyValue	SetVariableValue
SimulateAll	Undo	UpdateDefinitions

oDefinitionManager

AddComponent	AddDataset	AddFootprint
AddMaterial	AddPadstack	AddScript
AddSurfaceMaterial	AddSymbol	ChangeProperty
CloneMaterial	CreateComponentData	DeleteDataset
DoesMaterialExist	DoesSurfaceMaterialExist	EditComponent
EditDataset	EditFootprint	EditMaterial
EditPadstack	EditScript	EditSurfaceMaterial
EditSymbol	ExportComponent	ExportDataset
ExportFootprint	ExportMaterial	ExportPadstack
ExportScript	ExportSurfaceMaterial	ExportSymbol
GetInUseProjectMaterialNames	GetManager	GetMaterialNamesInConfiguredLibraries
GetProjectMaterialNames	GetProperties	GetPropertyValue
ImportDataset	ModifyLibraries	RemoveComponent
RemoveFootprint	RemoveMaterial	RemovePadstack
RemoveScript	RemoveSurfaceMaterial	RemoveSymbol
SetPropertyValue	UpdateDefinition	UpdateDefinitionFromLib

oDesign

AddCompInstance	AddDataset	AddDesignVariablesForDynamicLink
AddModelingProperties	AddOutputVariable	Analyze
AnalyzeAll	AnalyzeAllNominal	ChangePortProperty
ChangeProperty	CopyItemCommand	CopySimulationResults
CreateReport	DCReportGeneration	DeleteCompInstance
DeleteDataset	DeleteDesignInstance	DeleteFieldVariation
DeleteFullVariation	DeleteOutputVariable	DeletePort
DeleteSolutionVariation	DeleteSource	DesignOptions
EditCoSimulationOptions	EditDataset	EditHfssExtents
EditImportData	EditInfiniteArray	EditNotes
EditOptions	EditOutputVariable	EnableSolutionSetup
ExportConvergence	ExportCurrentsData	ExportDataset
ExportDesignPoint	ExportForHSpice	ExportForSpice
ExportNMFData	ExportNearFieldData	ExportNetworkData
ExportProfile	ExportReport	GetActiveEditor
GetConfigurableData	GetData	GetDesignType
GetDiagnostics	GetEditor	GetMenuChoices
GetModule	GetName	GetNoteText
GetOutputVariableValue	GetOutputVariables	GetPropHost
GetProperties	GetPropertyValue	GetSitempFilePath
GetVariableValue	GetVariables	ImportComponentFile
ImportComponentMappingFile	ImportData	ImportDataFilePath
ImportDataset	InsertDesign	InvalidateAllSolutions
InvalidateSolutions	ModifyMeshAttributes	OverlayCurrents
OverlayFarField	OverlayMesh	OverlayNearField
PasteDesign	PasteItemCommand	PushExcitations
Redo	RemoveAllReports	RemoveCircuitElement
RemoveImportData	RemoveModelingProperties	RemoveReport
RenameCircuitElement	RenameDesignInstance	RenameImportData
RenamePort	RenameSource	ReportTemplates

RunToolkit
SetTemperatureSettings
StartAnalysis
UpdateSources

SetActiveEditor
SetVariableValue
StopSimLink
ValidateCircuit

SetPropertyValue
SimulateLink
Undo
ValidateLink

Editor

Activate
AddObject
AddPortsToNet
AddVoltageRegulators
AssignCircuitRefPort
ChangeLayers
ClearLayerMappings
Connect
ConvertTraceToPlane
Create3DStructure
CreateCircle
CreateComponent
CreateDCTerminalComponent
CreateGroundPortComponent
CreateInterfaceGround
CreateLine
CreateMeasure
CreateObjectFromPolygon
CreatePinGroupPort
CreatePolygonVoid
CreatePortsOnComponentsByNet
CreateText
CreateViaGroups
CutOutSubDesign
DefeatureObjects
Delete
Disconnect
Duplicate
EditComponent
EraseMeasurements
ExportAcis
ExportGerber
ExportNCDrill
ExportToHFSS
FilterObjectList
FindObjectsByPolygon
GenerateFacetDataForModel
GetAllLayerNames
GetCompInstanceFromRefDes
GetComponentPins
GetMaterialList
GetNetConnections

AddCircuitRefPort
AddPinGroupRefPort
AddRefPort
AlignObjects
AssignRefPort
ChangeOptions
ClearRefPort
ConnectPortInstancesToPins
Copy
CreateAutomaticTrace
CreateCircleVoid
CreateCurrentSourcePort
CreateEdgePort
CreateGroupSelected
CreateInterfacePort
CreateLineFromPolygon
CreateNPort
CreatePin
CreatePinGroups
CreatePortInstancePorts
CreateRectangle
CreateTrace
CreateVoltageProbePort
DeactivateOpen
DelExtendedNet
DeleteNets
DissolveComponents
DuplicateAcrossLayers
EditPinGroup
Expand
ExportDXF
ExportImage
ExportStackupXML
ExportToHFSSUDP
FindObjects
FlipHorizontal
GeometryCheckAndAutofix
GetBBox
GetComponentInfo
GetEditorName
GetNetClassNets
GetNets

AddLayer
AddPortsToAllNets
AddStackupLayer
AlignPorts
ChangeLayer
ChangeProperty
ClearRelative
ConvertPlaneToTrace
CopyToPlanarEM
CreateCS
CreateCircuitPort
CreateDCTerminal
CreateExtendedNet
CreateHole
CreateInterfacePortComponent
CreateLineVoid
CreateNetClass
CreatePinGroup
CreatePolygon
CreatePortsOnComponents
CreateRectangleVoid
CreateVia
CreateVoltageSourcePort
DeactivateShort
DelNetClass
DeletePinGroup
DumpPolygon
Edit
EnableComponents
ExpandWithPorts
ExportGDSII
ExportMaterialToHFSSUDP
ExportStride
ExportToQ3D
FindObjectsByPoint
FlipVertical
GetActiveUnits
GetCSObjects
GetComponentPinInfo
GetLayerInfo
GetNetClasses
GetPolygon

GetPolygonDef
GetPortInfo
GetPropertyValue
GetUserGeometryList
HighlightNet
ImportStackupXML
ModifyNetClass
Paste
PlaceDesign
PositionRelative
RemovePort
RemovePortsOnComponents
ReverseLine
Select
SelectFirstViolation
SetActiveUnits
SetHfssPortsVisible
SetMCADModelOrigin
SetPropertyValue
Subtract
Ungroup
UpdateModels

GetPolygonInfo
GetPortInstances
GetSelections
Group
ImportDXF
Intersect
Move
PasteFullDesign
Point
PushExcitations
RemovePortsFromAllNets
RemoveVoltageRegulators
Rotate
SelectAll
SelectNetConnected
SetCS
SetLayerMapping
SetNetColor
Snap3D
ToggleNetHighlight
Unite
UpdateVoltageRegulators

GetPolygonVoids
GetProperties
GetStackupLayerNames
Heal
ImportGDSII
ModifyExtendedNet
PageSetup
PinConnectivity
Polygon
RemoveLayer
RemovePortsFromNet
ResyncGeometry
SanitizeLayout
SelectAllNetViolations
SelectPhysicallyConnected
SetHfssExtentsVisible
SetMCADInstanceAttributes
SetNetVisible
StitchLines
ToggleViaPin
UnselectAll
ZoomToFit

oTool-NdExplorer

CheckCausality
ExportNetworkData

ExportFullWaveSpice
ExtractImpulseResponse

ExportNMFData
SetExportTouchstoneOptions

oTool-ImportExport

ImportANF
ImportAutoCAD
ImportGDSII
ImportIDFandMerge
ImportXFL

ImportANFV2
ImportEDB
ImportGerber
ImportIPC

ImportAWRMicrowaveOffice
ImportExtracta
ImportIDF
ImportODB

oModule-Optimetrics

CopySetup
EditSetup
ExportDOELocalSensitivityCurve
ExportDOEResponseSurface
ExportOptimetricsResult
ExportRespSurfacePlotToFile
ExportRespSurfaceVerificationPoints
GetOptimetricResultRowCount
ImportSetup
RenameSetup

DeleteSetups
EnableSetup
ExportDOEResponseCurve
ExportDXConfigFile
ExportParametricResults
ExportRespSurfaceRefinePoints
GenerateVariationData
GetSetupNames
InsertSetup
SolveAllSetup

DistributedAnalyzeSetup
ExportDOELocalSensitivity
ExportDOEResponseCurveSlices
ExportOptimetricsProfile
ExportRespSurfaceMinMaxTable
ExportRespSurfaceResponsePoints
GetOptimetricResult
GetSetupNamesByType
PasteSetup
SolveSetup

oModule-SolveSetups

Add	AddMeshOperation	AddSweep
Analyze	AnalyzeSweep	Delete
DeleteMeshOperation	DeleteMeshOperations	DeleteSweep
DisplayMesh	DynamicMeshOverlays	Edit
EditMeshOperation	EditSweep	ExportToHfss
ExportToQ3d	GenerateModelMesh	GetAllSolutionNames
GetSetupData	GetSetups	GetSweepInfo
GetSweeps	Layout3DMeshOverlay	LayoutMeshOverlay
ListVariations	RefreshMeshOverlays	Rename
RenameMeshOperation	RenameSweep	RevertToInitialMesh
ShowMeshErrorDialog	Validate	

oModule-FieldsReporter

AddMarker	AddMarkerToPlot	AddNamedExpr
AddNamedExpression	CalcOp	CalcRead
CalcStack	CalcWrite	CalculatorRead
CalculatorWrite	ChangeGeomSettings	ClcEval
ClcMaterial	ClcMaterialValue	ClearAllMarkers
ClearAllNamedExpr	CopyNamedExprToStack	CreateFieldPlot
DeleteFieldPlot	DeleteMarker	DeleteNamedExpr
DeleteUneditablePlot	DoesNamedExpressionExists	DumpCalculatorStack
EnterComplex	EnterComplexVector	EnterCoord
EnterEdge	EnterLine	EnterOutputVar
EnterPoint	EnterQty	EnterScalar
EnterScalarFunc	EnterSurf	EnterVector
EnterVectorFunc	EnterVol	ExportFieldPlot
ExportMarkerTable	ExportOnGrid	ExportPlotImageToFile
ExportToFile	GetFieldFolderNames	GetFieldPlotNames
GetMeshPlotNames	GetTopEntryValue	HideAntennaParameterOverlay
HidePolarPlot	HideRadiatedPlotOverlay	LoadNamedExpressions
ModifyFieldPlot	ReassignFieldPlot	RenameFieldPlot
RenamePlotFolder	SaveFieldsPlots	SaveNamedExpressions
SetFieldPlotSettings	SetFieldTypeSettings	SetPlotFolderSettings
SetPlotsSolutionContext	SetPlotsViewSolutionContext	ShowAntennaParameterOverlay
ShowPolarPlot	ShowRadiatedPlotOverlay	Test
UpdateAllFieldsPlots	UpdateQuantityFieldsPlots	XForm

oModule-ReportSetup

AddAllEyeMeasurements	AddCartesianLimitLine	AddCartesianLimitLineFromCurve
AddCartesianLimitLineFromEquation	AddCartesianXMarker	AddCartesianYMarker
AddCartesianYMarkerToStack	AddDeltaMarker	AddMarker
AddNote	AddTraceCharacteristics	AddTraces
ApplyReportTemplate	ChangeProperty	ClearAllMarkers
ClearAllTraceCharacteristics	CloneReportsFromDatasetSolution	CompareReportDataForRegressionTesting
CompareReportDataForRegressionTesting2	CompareTracesForRegressionTesting	CompareTracesForRegressionTesting2

CopyPlotSettings	CopyReportDefinitions	CopyReportsData
CopyTraceDefinitions	CopyTracesData	CreateReport
CreateReportFromFile	CreateReportFromTemplate	CreateReportOfAllQuantities
DeleteAllReports	DeleteReports	DeleteTraceCharacteristics
DeleteTraces	DoesSupportTraceCharacteristics	DumpAllReportsData
DumpReportDataForRegressionTesting	EditCartesianXMarker	EditCartesianYMarker
EditMarker	ExportEyeMaskViolation	ExportImageToFile
ExportReportDataToFile	ExportTableToFile	ExportToFile
ExportUniformPointsToFile	GetAllCategories	GetAllQuantities
GetAllReportNames	GetAvailableDisplayTypes	GetAvailableReportTypes
GetAvailableSolutions	GetDisplayType	GetDynLinkIntrinsicVariables
GetDynLinkQtyData	GetDynLinkQtyValueState	GetDynLinkTraces
GetDynLinkVariableValues	GetPropertyValue	GetQtyExpressionsForSourceTrace
GetReportSummaryForRegressionTesting	GetReportTraceNames	GetSolutionContexts
GetSolutionDataPerVariation	GroupPlotCurvesByGroupingStrategy	ImportIntoReport
ImportReportDataIntoReport	MovePlotCurvesToGroup	MovePlotCurvesToNewGroup
OpenWindowForAllReports	OpenWindowForReports	PastePlotSettings
PasteReports	PasteReportsWithLegacyNames	PasteTraces
PasteTracesWithLegacyNames	RenameReport	RenameTrace
ResetPlotSettings	SavePlotSettingsAsDefault	SetLinkOutputTraces
UngroupPlotCurvesInGroup	UpdateAllReports	UpdateReports
UpdateTraces	UpdateTracesContextAndSweeps	

oModule-OutputVariable

CreateOutputVariable	DeleteOutputVariable	DoesOutputVariableExist
EditOutputVariable	ExportOutputVariables	GetOutputVariableValue
GetOutputVariables	ImportOutputVariables	

oModule-UserDefinedSolutionModule

CreateUserDefinedSolution	DeleteUserDefinedSolutions	EditUserDefinedSolution
GetUserDefinedSolutionNames	GetUserDefinedSolutionProperties	

oModule-DV

AddRuleSet	AddRun	DeleteRuleSet
DeleteRun	EditRuleSet	EditRun
RenameRuleSet	RenameRun	RunAllDV
RunAllRuleSetDV	RunDV	

oModule-Excitations

Add	AddRefPort	AddRefPortUsingEdges
AlphaNumericCircuitMatrix	AlphaNumericMatrix	ConvertToCoax
CoupleEdgePorts	DecoupleEdgePorts	Delete
DeleteDCIRPort	DeleteExcitation	DeleteProbePortAndVia
DeleteSource	Edit	EditCircuitPort
EditExcitations	GetAllBoundariesList	GetAllCircuitPortsList

GetAllPortsList
RemoveRefPort
ReorderCircuitMatrix
SelectInLayout
SetDiffPairs

LoadDiffPairsFromFile
Rename
ReorderMatrix
SetCircuitDiffPairs
UpdateSources

MultiEdit
RenameSource
SaveDiffPairsToFile
SetCircuitExcitations