



GE Energy

Functional Testing Specification

Parts & Repair Services
Louisville, KY

LOU-GED-DS3800NPMC

Test Procedure for a DS3800NPMC

DOCUMENT REVISION STATUS: Determined by the last entry in the "REV" and "DATE" column

REV.	DESCRIPTION	SIGNATURE	REV. DATE
A	Initial release	Steve Pharris	06/25/2012
B			
C			

© COPYRIGHT GENERAL ELECTRIC COMPANY

Hard copies are uncontrolled and are for reference only.

PROPRIETARY INFORMATION – THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF GENERAL ELECTRIC COMPANY AND MAY NOT BE USED OR DISCLOSED TO OTHERS, EXCEPT WITH THE WRITTEN PERMISSION OF GENERAL ELECTRIC COMPANY.

PREPARED BY Steve Pharris	REVIEWED BY	REVIEWED BY	QUALITY APPROVAL <i>Charlie Wade</i>
DATE 06/25/12	DATE	DATE	DATE 6/25/2012

LOU-GED-DS3800NPMC REV. A	g GE Energy Parts & Repair Services Louisville, KY	Page 2 of 11
------------------------------	--	--------------

1. SCOPE

1.1 This is a functional testing procedure for a DS3800NPMC.

2. STANDARDS OF QUALITY

2.1 Refer to the current revision of the IPC-A-610 standard for workmanship standards.

3. APPLICABLE DOCUMENTS

3.1 The following document(s) shall form part of this specification to the extent specified herein. Unless otherwise indicated, the latest issue shall apply.

3.1.1 Check board's electronic folder for more information

4. ENGINEERING REQUIREMENTS

4.1 Equipment Cleaning

4.1.1 Equipment should be clean and free of debris prior to applying power unless performing an initial check. Refer to site specific SRA's for cleaning guidelines.

4.2 Equipment Inspection

4.2.1 Equipment should be visually inspected for any defects prior to applying power. This inspection should include the following as a minimum:

4.2.1.1 Wires - broken, cracked, or loosely connected

4.2.1.2 Terminal strips / connectors - broken or cracked

4.2.1.3 Components - visually damaged

4.2.1.4 Capacitors - bloated or leaking

4.2.1.5 Solder joints - damaged or cold

4.2.1.6 Circuit board - burned or de-laminated

4.2.1.7 Printed wire runs / Traces - burned or damaged

5. EQUIPMENT REQUIRED

5.1 The following equipment is required to perform the process requirements. Equipment may be substituted provided that all accuracy's and test ratios are equivalent or better.

Qty	Reference #	Description
1		Fluke 87 DMM (or Equivalent)
1		Rainbow Box
1		DS3800 Connector Box
1		DS3800 Power Supply
1		NPMC Resistor Load (by fixtures)

<p>LOU-GED-DS3800NPMC REV. A</p>	<p>g</p> <p>GE Energy Parts & Repair Services Louisville, KY</p>	<p>Page 3 of 11</p>
---	--	----------------------------

6. Testing Process

6.1 Setup

6.1.1 Unless otherwise stated H and L refer to TTL logic states High and Low

6.1.2 Connect DS3800 power supply and DS3800 connector box to rainbow box

6.1.3 Make the following connections

PA60-SW96 and Set H

PA70-L

PA6-SW81 Set L

PA10-SW82 Set L

PA11-SW83 Set L

PA8-SW84 Set L

PA28-SW85 Set L

PA30-SW86 Set L

PA31-SW87 Set L

PA29-SW88 Set L

6.1.4 Connect Load

Blue lead to DMM

Black lead to Com

Red lead to PA2

6.2 Testing Procedure

6.2.1 Apply power

6.2.2 Verify DMM reads 1V (approx.)

6.2.3 Toggle SW81 H-L

6.2.4 Verify DMM reads > 12VDC (approx. 13VDC is typical)

6.2.5 Toggle SW96 L-H

6.2.6 Verify DMM reads 1V (approx.)

6.2.7 Move load from PA2 to PA15

6.2.8 Verify DMM reads 1V (approx.)


6.2.9 Toggle SW82 H-L

6.2.10 Verify DMM reads > 12VDC (approx. 13VDC is typical)


6.2.11 Toggle SW96 L-H

6.2.12 Verify DMM reads 1V (approx.)

6.2.13 Move load from PA15 to PA4

LOU-GED-DS3800NFMC REV. A	 GE Energy <i>Parts & Repair Services</i> <i>Louisville, KY</i>	Page 4 of 11
--------------------------------------	--	---------------------

- 6.2.14** Verify DMM reads 1V (approx.)
- 6.2.15** Toggle SW83 H-L
- 6.2.16** Verify DMM reads > 12VDC (approx. 13VDC is typical)
- 6.2.17** Toggle SW96 L-H
- 6.2.18** Verify DMM reads 1V (approx.)
- 6.2.19** Move load from PA4 to PA14
- 6.2.20** Verify DMM reads 1V (approx.)
- 6.2.21** Toggle SW84 H-L
- 6.2.22** Verify DMM reads > 12VDC (approx. 13VDC is typical)
- 6.2.23** Toggle SW96 L-H
- 6.2.24** Verify DMM reads 1V (approx.)
- 6.2.25** Move load from PA14 to PA26
- 6.2.26** Verify DMM reads 1V (approx.)
- 6.2.27** Toggle SW85 H-L
- 6.2.28** Verify DMM reads > 12VDC (approx. 13VDC is typical)
- 6.2.29** Toggle SW96 L-H
- 6.2.30** Verify DMM reads 1V (approx.)
- 6.2.31** Move load from PA26 to PA35
- 6.2.32** Verify DMM reads 1V (approx.)
- 6.2.33** Toggle SW86 H-L
- 6.2.34** Verify DMM reads > 12VDC (approx. 13VDC is typical)
- 6.2.35** Toggle SW96 L-H
- 6.2.36** Verify DMM reads 1V (approx.)
- 6.2.37** Move load from PA35 to PA27
- 6.2.38** Verify DMM reads 1V (approx.)
- 6.2.39** Toggle SW87 H-L
- 6.2.40** Verify DMM reads > 12VDC (approx. 13VDC is typical)
- 6.2.41** Toggle SW96 L-H
- 6.2.42** Verify DMM reads 1V (approx.)
- 6.2.43** Move load from PA27 to PA34
- 6.2.44** Verify DMM reads 1V (approx.)
- 6.2.45** Toggle SW88 H-L
- 6.2.46** Verify DMM reads > 12VDC (approx. 13VDC is typical)
- 6.2.47** Toggle SW96 L-H

LOU-GED-DS3800NFMC REV. A	 GE Energy <i>Parts & Repair Services</i> <i>Louisville, KY</i>	Page 5 of 11
--------------------------------------	--	---------------------

- 6.2.48** Verify DMM reads 1V (approx.)
- 6.2.49** Move load from PA34 to PA47
- 6.2.50** Verify DMM reads 0VDC
- 6.2.51** Toggle SW81 H-L
- 6.2.52** Verify DMM reads > 12VDC (approx. 13VDC is typical)
- 6.2.53** Toggle SW96 L-H
- 6.2.54** Verify DMM reads 0VDC
- 6.2.55** Toggle SW82 H-L
- 6.2.56** Verify DMM reads > 12VDC (approx. 13VDC is typical)
- 6.2.57** Toggle SW96 L-H
- 6.2.58** Verify DMM reads 0VDC
- 6.2.59** Toggle SW83 H-L
- 6.2.60** Verify DMM reads > 12VDC (approx. 13VDC is typical)
- 6.2.61** Toggle SW96 L-H
- 6.2.62** Verify DMM reads 0VDC
- 6.2.63** Toggle SW84 H-L
- 6.2.64** Verify DMM reads > 12VDC (approx. 13VDC is typical)
- 6.2.65** Toggle SW96 L-H
- 6.2.66** Verify DMM reads 0VDC
- 6.2.67** Toggle SW85 H-L
- 6.2.68** Verify DMM reads > 12VDC (approx. 13VDC is typical)
- 6.2.69** Toggle SW96 L-H
- 6.2.70** Verify DMM reads 0VDC
- 6.2.71** Toggle SW86 H-L
- 6.2.72** Verify DMM reads > 12VDC (approx. 13VDC is typical)
- 6.2.73** Toggle SW96 L-H
- 6.2.74** Verify DMM reads 0VDC
- 6.2.75** Toggle SW87 H-L
- 6.2.76** Verify DMM reads > 12VDC (approx. 13VDC is typical)
- 6.2.77** Toggle SW96 L-H
- 6.2.78** Verify DMM reads 0VDC
- 6.2.79** Toggle SW88 H-L
- 6.2.80** Verify DMM reads > 12VDC (approx. 13VDC is typical)
- 6.2.81** Toggle SW96 L-H

LOU-GED-DS3800NFMC REV. A	<div data-bbox="548 201 581 252" data-label="Image"></div> <div data-bbox="737 258 980 333" data-label="Text"> <p>GE Energy Parts & Repair Services Louisville, KY</p> </div>	Page 6 of 11
--------------------------------------	--	---------------------

- 6.2.82** Verify DMM reads 0VDC
- 6.2.83** Remove PA70
- 6.2.84** Connect PA66-SW89 and set H
- 6.2.85** Move load to PA56
- 6.2.86** Toggle SW81 H-L
- 6.2.87** Verify DMM reads > 12VDC (approx. 13VDC is typical)
- 6.2.88** Verify “DF” LED is illuminated and steady
- 6.2.89** Verify “F1” LED is illuminated and flashing
- 6.2.90** Toggle SW89 L-H
- 6.2.91** Verify DMM reads 1V (approx.)
- 6.2.92** Verify PA47 = 0VDC
- 6.2.93** Verify “DF” LED is now off
- 6.2.94** Verify “F1” is still illuminated and flashing
- 6.2.95** Toggle SW96 L-H
- 6.2.96** Verify all LED’s are now extinguished
- 6.2.97** Connect PA44-SW90 and set H
- 6.2.98** Connect PA42 SW91 and set H
- 6.2.99** Toggle SW81 H-L
- 6.2.100** Verify “DF” LED is illuminated and steady
- 6.2.101** Verify “F1” LED is illuminated and flashing
- 6.2.102** Toggle SW90 L-H
- 6.2.103** Verify “DF” LED is now off
- 6.2.104** Verify “F1” LED is illuminated and steady
- 6.2.105** Toggle SW91 L-H
- 6.2.106** Verify all LED’s are now extinguished
- 6.2.107** Toggle SW82 H-L
- 6.2.108** Verify “DF” LED is illuminated and steady
- 6.2.109** Verify “F2” LED is illuminated and flashing
- 6.2.110** Toggle SW90 L-H
- 6.2.111** Verify “DF” LED is now off
- 6.2.112** Verify “F2” LED is illuminated and steady
- 6.2.113** Toggle SW91 L-H
- 6.2.114** Verify all LED’s are now extinguished
- 6.2.115** Toggle SW83 H-L

<p>LOU-GED-DS3800NFMC REV. A</p>	<p>g</p> <p>GE Energy Parts & Repair Services Louisville, KY</p>	<p>Page 7 of 11</p>
---	--	----------------------------

- 6.2.116 Verify “DF” LED is illuminated and steady
- 6.2.117 Verify “F3” LED is illuminated and flashing
- 6.2.118 Toggle SW90 L-H
- 6.2.119 Verify “DF” LED is now off
- 6.2.120 Verify “F3” LED is illuminated and steady
- 6.2.121 Toggle SW91 L-H
- 6.2.122 Verify all LED’s are now extinguished
- 6.2.123 Toggle SW84 H-L
- 6.2.124 Verify “DF” LED is illuminated and steady
- 6.2.125 Verify “F4” LED is illuminated and flashing
- 6.2.126 Toggle SW90 L-H
- 6.2.127 Verify “DF” LED is now off
- 6.2.128 Verify “F4” LED is illuminated and steady
- 6.2.129 Toggle SW91 L-H
- 6.2.130 Verify all LED’s are now extinguished
- 6.2.131 Toggle SW85 H-L
- 6.2.132 Verify “DF” LED is illuminated and steady
- 6.2.133 Verify “F5” LED is illuminated and flashing
- 6.2.134 Toggle SW90 L-H
- 6.2.135 Verify “DF” LED is now off
- 6.2.136 Verify “F5” LED is illuminated and steady
- 6.2.137 Toggle SW91 L-H
- 6.2.138 Verify all LED’s are now extinguished
- 6.2.139 Toggle SW86 H-L
- 6.2.140 Verify “DF” LED is illuminated and steady
- 6.2.141 Verify “F6” LED is illuminated and flashing
- 6.2.142 Toggle SW90 L-H
- 6.2.143 Verify “DF” LED is now off
- 6.2.144 Verify “F6” LED is illuminated and steady
- 6.2.145 Toggle SW91 L-H
- 6.2.146 Verify all LED’s are now extinguished
- 6.2.147 Toggle SW87 H-L
- 6.2.148 Verify “DF” LED is illuminated and steady
- 6.2.149 Verify “F7” LED is illuminated and flashing

LOU-GED-DS3800NFMC REV. A	<div data-bbox="548 201 581 252" data-label="Image"></div> <div data-bbox="737 258 980 333" data-label="Text"> <p>GE Energy Parts & Repair Services Louisville, KY</p> </div>	Page 8 of 11
--------------------------------------	--	---------------------

- 6.2.150 Toggle SW90 L-H
- 6.2.151 Verify “DF” LED is now off
- 6.2.152 Verify “F7” LED is illuminated and steady
- 6.2.153 Toggle SW91 L-H
- 6.2.154 Verify all LED’s are now extinguished
- 6.2.155 Toggle SW88 H-L
- 6.2.156 Verify “DF” LED is illuminated and steady
- 6.2.157 Verify “F8” LED is illuminated and flashing
- 6.2.158 Toggle SW90 L-H
- 6.2.159 Verify “DF” LED is now off
- 6.2.160 Verify “F8” LED is illuminated and steady
- 6.2.161 Toggle SW91 L-H
- 6.2.162 Verify all LED’s are now extinguished
- 6.2.163 Toggle SW81 H-L
- 6.2.164 Toggle SW82 thru SW88 H-L
- 6.2.165 Verify “F1” LED is illuminated and flashing
- 6.2.166 Verify all other LED’s are illuminated and steady
- 6.2.167 Toggle SW96 L-H
- 6.2.168 Verify all LED’s are now extinguished
- 6.2.169 Toggle SW82 H-L
- 6.2.170 Toggle SW81 thru SW88 H-L
- 6.2.171 Verify “F2” LED is illuminated and flashing
- 6.2.172 Verify all other LED’s are illuminated and steady
- 6.2.173 Toggle SW96 L-H
- 6.2.174 Verify all LED’s are now extinguished
- 6.2.175 Toggle SW83 H-L
- 6.2.176 Toggle SW81 thru SW88 H-L
- 6.2.177 Verify “F3” LED is illuminated and flashing
- 6.2.178 Verify all other LED’s are illuminated and steady
- 6.2.179 Toggle SW96 L-H
- 6.2.180 Verify all LED’s are now extinguished
- 6.2.181 Toggle SW84 H-L
- 6.2.182 Toggle SW81 thru SW88 H-L
- 6.2.183 Verify “F4” LED is illuminated and flashing

LOU-GED-DS3800NPMC REV. A	<div data-bbox="548 201 581 252" data-label="Image"></div> <div data-bbox="737 258 980 333" data-label="Text"> <p>GE Energy Parts & Repair Services Louisville, KY</p> </div>	Page 9 of 11
--------------------------------------	--	---------------------

- 6.2.184** Verify all other LED's are illuminated and steady
- 6.2.185** Toggle SW96 L-H
- 6.2.186** Verify all LED's are now extinguished
- 6.2.187** Toggle SW85 H-L
- 6.2.188** Toggle SW81 thru SW88 H-L
- 6.2.189** Verify "F5" LED is illuminated and flashing
- 6.2.190** Verify all other LED's are illuminated and steady
- 6.2.191** Toggle SW96 L-H
- 6.2.192** Verify all LED's are now extinguished
- 6.2.193** Toggle SW86 H-L
- 6.2.194** Toggle SW81 thru SW88 H-L
- 6.2.195** Verify "F6" LED is illuminated and flashing
- 6.2.196** Verify all other LED's are illuminated and steady
- 6.2.197** Toggle SW96 L-H
- 6.2.198** Verify all LED's are now extinguished
- 6.2.199** Toggle SW87 H-L
- 6.2.200** Toggle SW81 thru SW88 H-L
- 6.2.201** Verify "F7" LED is illuminated and flashing
- 6.2.202** Verify all other LED's are illuminated and steady
- 6.2.203** Toggle SW96 L-H
- 6.2.204** Verify all LED's are now extinguished
- 6.2.205** Toggle SW88 H-L
- 6.2.206** Toggle SW81 thru SW87 H-L
- 6.2.207** Verify "F8" LED is illuminated and flashing
- 6.2.208** Verify all other LED's are illuminated and steady
- 6.2.209** Toggle SW96 L-H
- 6.2.210** Verify all LED's are now extinguished
- 6.2.211** Connect PA50-PA76
- 6.2.212** Set all faults to on by toggling SW81 thru SW88 H-L
- 6.2.213** Verify all LED's are illuminated and steady except the first faulted circuit is flashing
- 6.2.214** Verify the following points are logic Low
 - PA18
 - PA19
 - PA20

LOU-GED-DS3800NFMC REV. A	<div data-bbox="548 205 581 254" data-label="Image"></div> <div data-bbox="737 258 980 333" data-label="Text"> <p>GE Energy Parts & Repair Services Louisville, KY</p> </div>	Page 10 of 11
--------------------------------------	--	----------------------

PA21

PA38

PA39

PA40

PA41

6.2.215 Toggle SW90 L-H

6.2.216 Verify all LED's are now extinguished

6.2.217 Verify the following points are logic High

PA18

PA19

PA20

PA21

PA38

PA39

PA40

PA41

6.2.218 Remove connection from PA76-PA50

6.2.219 Connect PA25-L

6.2.220 Verify all LED's are illuminated

6.2.221 Remove connection at PA25

6.2.222 Connect PA52-L

6.2.223 Set SW96-L

6.2.224 Change the following connections by moving the first location to the second

SW81-PA69

SW82-PA61

SW83-PA64

SW84-PA62

SW85-PA49

SW86-PA71

SW87-PA80

SW88-PA65

6.2.225 Verify all LED's except "DF" are illuminated

6.2.226 Remove PA52

6.2.227 Verify "F1" thru "F8" start scrolling one LED off

<p>LOU-GED-DS3800NFMC REV. A</p>	<p>g</p> <p>GE Energy <i>Parts & Repair Services</i> <i>Louisville, KY</i></p>	<p>Page 11 of 11</p>
---	--	-----------------------------

6.2.228 Set SW96-H

6.2.229 Verify the LED that was extinguished when SW96 went H begins to flash

6.2.230 Verify the “DF” LED illuminates

6.2.231 Set SW96-L

6.2.232 Verify LED scrolling resumes

6.2.233 Remove power from UUT

6.3 *TEST COMPLETE*****

7. Notes

7.1 None at this time.

8. Attachments

8.1 None at this time.