



GE Energy

## Functional Testing Specification

Parts & Repair Services  
Louisville, KY

LOU-GED-IS200WROF

### Test Procedure for an IS200WROF Mark VIe Daughter Card

DOCUMENT REVISION STATUS: Determined by the last entry in the "REV" and "DATE" column

REV.	DESCRIPTION	SIGNATURE	REV. DATE
A	Initial release	J. Francis	02/14/2014
B			
C			

© COPYRIGHT GENERAL ELECTRIC COMPANY

Hard copies are uncontrolled and are for reference only.

PROPRIETARY INFORMATION – THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF GENERAL ELECTRIC COMPANY AND MAY NOT BE USED OR DISCLOSED TO OTHERS, EXCEPT WITH THE WRITTEN PERMISSION OF GENERAL ELECTRIC COMPANY.

PREPARED BY J. Francis	REVIEWED BY	REVIEWED BY	QUALITY APPROVAL <i>Charlie Wade</i>
DATE 02/14/2014	DATE	DATE	DATE 6/10/2014

<p><b>LOU-GED-IS200WROF</b> <b>Rev A</b></p>	<p><b>g</b></p> <p><b>GE Energy</b> <i>Parts &amp; Repair Services</i> <i>Louisville, KY</i></p>	<p><b>Page 2 of 4</b></p>
--	--	---------------------------

## 1. SCOPE

1.1 This is a functional testing procedure for an **IS200WROF** MARK VIe Daughter Card.

## 2. STANDARDS OF QUALITY

2.1 Refer to the current revision of the IPC-A-610 standard for workmanship standards.

## 3. APPLICABLE DOCUMENTS

3.1 The following document(s) shall form part of this specification to the extent specified herein. Unless otherwise indicated, the latest issue shall apply.

3.1.1 Check board's electronic folder for more information.

## 4. ENGINEERING REQUIREMENTS

### 4.1 Equipment Cleaning

4.1.1 Equipment should be clean and free of debris prior to applying power unless performing an initial check. Refer to site specific SRA's for cleaning guidelines.

### 4.2 Equipment Inspection

4.2.1 Equipment should be visually inspected for any defects prior to applying power. This inspection should include the following as a minimum:

4.2.1.1 Wires - broken, cracked, or loosely connected

4.2.1.2 Terminal strips / connectors - broken or cracked

4.2.1.3 Components - visually damaged

4.2.1.4 Capacitors - bloated or leaking

4.2.1.5 Solder joints - damaged or cold

4.2.1.6 Circuit board - burned or de-laminated

4.2.1.7 Printed wire runs / Traces - burned or damaged

## 5. EQUIPMENT REQUIRED

5.1 The following equipment is required to perform the process requirements. Equipment may be substituted provided that all accuracy's and test ratios are equivalent or better.

Qty	Reference #	Description
1	H188922	Mark VIe Simplex Test Rack with computer
1		Fluke 87 Digital Multimeter or equivalent

## 6. TESTING PROCESS

### 6.1 Static Checks

- 6.1.1 Using Fluke 87 Digital Multimeter or equivalent, set for Resistance function, check for, and replace, shorted MOV's and Rectifiers before installing unit into test rack.
- 6.1.2 Remove all Fuses and check for correct value and any defects.

### 6.2 Functional Testing Procedure



**Note:** The following portions of the test assume you are familiar with using ToolboxST. You will need to perform downloads at least twice for UUT to be setup fully. You must also wait for approximately 3 minutes in between downloads for rack and UUT to reboot.

- 6.2.1 Turn off Rack Power switch.
- 6.2.2 Install unit to be tested onto TDBS card.
- 6.2.3 Turn on Rack Power switch. Wait for approximately 3 minutes for rack to boot.
- 6.2.4 Open **ToolboxST** and open "**UCSAH1\_Simplex\_Vle**" by double-clicking on it. Go online with ToolboxST.
- 6.2.5 Once online, select the "**HARDWARE**" tab. Under the "**Distributed I/O**" icon click on the "+" icon to the left of the "**Simplex**" icon. This will list the modules installed.
- 6.2.6 Highlight the "**PDIO**" module. Click on the "**Variables**" tab to the right. This should show a list of values, including Fuse01Fdbk through Fuse12Fdbk at the bottom. Initially, these values should all be "**FALSE**", indicating good Fuse status.
- 6.2.7 One at time, remove the fuse cap for each Fuse, making sure that the corresponding value changes to "**TRUE**", indicating bad Fuse status.
- 6.2.8 Reinstall the fuse cap for each Fuse, making sure the corresponding value changes back to "**FALSE**", indicating good Fuse status.
- 6.2.9 Click on the "**OUTPUTS**" tab next to the "**VARIABLES**" tab. Verify that all of the values listed are "**FALSE**".
- 6.2.10 Click on the "**INPUTS**" tab next to the "**OUTPUTS**" tab. All of the odd numbered "Contact Input" values should be "**TRUE**". All of the even numbered "Contact Input" values should be "**FALSE**". Also, at this time all of the "RelayxxFdbk" values should be "**FALSE**".
- 6.2.11 Click on the "**OUTPUTS**" tab. Double-click on each of the "Live Values" values. This should bring up a dialog box. Click on the "Toggle Value" button, you should be able to

<p><b>LOU-GED-IS200WROF</b> <b>Rev A</b></p>	<p><b>g</b></p> <p><b>GE Energy</b> <i>Parts &amp; Repair Services</i> <i>Louisville, KY</i></p>	<p><b>Page 4 of 4</b></p>
--	--	---------------------------

hear the corresponding Relay engage. Then click on the “Send & Close” button. Dialog box disappears.

**6.2.12** Click on the “**INPUTS**” tab next to the “**OUTPUTS**” tab. All of the odd numbered “Contact Input” values should be “FALSE”. All of the even numbered “Contact Input” values should be “TRUE”. Also, at this time all of the “RelayxxFdbk” values should be “TRUE”.

### **6.3 Burn-In Process**

**6.3.1** After letting unit run in test rack for 48 hours, repeat steps 6.2.1.6 through 6.2.1.12.

### **6.4 \*\*\*TEST COMPLETE\*\*\***

## **7. NOTES**

**7.1** Live View screens will be forthcoming and tests will be amended as needed.

## **8. ATTACHMENTS**

**8.1** None at this time.