



GE Energy

## Functional Testing Specification

Parts & Repair Services  
Louisville, KY

LOU-GED-IS200SSCA

### Test Procedure for IS200SSCA serial communications card

DOCUMENT REVISION STATUS: Determined by the last entry in the "REV" and "DATE" column

REV.	DESCRIPTION	SIGNATURE	REV. DATE
A	Initial release	J.Francis	03/07/2014
B			
C			

© COPYRIGHT GENERAL ELECTRIC COMPANY

Hard copies are uncontrolled and are for reference only.

PROPRIETARY INFORMATION – THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF GENERAL ELECTRIC COMPANY AND MAY NOT BE USED OR DISCLOSED TO OTHERS, EXCEPT WITH THE WRITTEN PERMISSION OF GENERAL ELECTRIC COMPANY.

PREPARED BY J.Francis	REVIEWED BY	REVIEWED BY	QUALITY APPROVAL <i>Charlie Wade</i>
DATE 03/07/2014	DATE	DATE	DATE 3/10/2014

<p><b>LOU-GED-IS200SSCA REV. A</b></p>	<p><b>g</b></p> <p><b>GE Energy</b> Part &amp; Repair Services Louisville, KY</p>	<p><b>Page 2 of 5</b></p>
--	---	---------------------------

## Functional test procedure for IS200SSCA Mark VIe Serial Communications Card.

### 1. SCOPE

1.1 This is a functional testing procedure for the IS200SSCA card.

### 2. STANDARDS OF QUALITY

2.1 Refer to the current revision of the IPC-A-610 standard for workmanship standards.

### 3. APPLICABLE DOCUMENTS

3.1 The following document(s) shall form part of this specification to the extent specified herein. Unless otherwise indicated, the latest issue shall apply.

3.1.1 Check board's electronic folder for more information.

### 4. ENGINEERING REQUIREMENTS

#### 4.1 Equipment Cleaning

4.1.1 Equipment should be clean and free of debris prior to applying power unless performing an initial check. Refer to site specific SRA's for cleaning guidelines.

#### 4.2 Equipment Inspection

4.2.1 Equipment should be visually inspected for any defects prior to applying power. This inspection should include the following as a minimum:

4.2.1.1 Wires broken or cracked

4.2.1.2 Terminal strips / connectors broken or cracked

4.2.1.3 Loose wires

4.2.1.4 Components visually damaged

4.2.1.5 Capacitors leaking

4.2.1.6 Solder joints damaged or cold

4.2.1.7 Circuit board burned or de-laminated

4.2.1.8 Printed wire runs burned or damaged

### 5. EQUIPMENT REQUIRED

5.1 The following equipment is required to perform the process requirements. Equipment may be substituted provided that all accuracy's and test ratios are equivalent or better.

Qty	Reference #	Description
1	H188922	Mark VIe Simplex Test Rack

## 6. TESTING PROCESS

### 6.1 Functional Testing



**Note:** The following tests assume you are familiar with using ToolboxST. You will need to perform downloads at least twice for UUT to be setup fully. You must also wait for approximately 3 minutes in between downloads for rack and UUT to reboot.

- 6.1.1 Turn “OFF” Rack Power Switch on front of test rack.
- 6.1.2 Remove test card (GOLD card) from test rack and install Unit Under Test (UUT) into test rack.
- 6.1.3 Turn “ON” Rack Power Switch on front of test rack. Wait for approximately 5 minutes for rack to fully boot.
- 6.1.4 Open **ToolboxST** and open “**UCSAH1A\_Simplex\_Vle**” by double-clicking on it and click the “ONLINE” button in the toolbar.
- 6.1.5 Click on the “HARDWARE” tab, then click on the “+” sign next to the “Simplex” group under the “Distributed IO” icon. This will show you all of the modules setup in the rack. The PSCA module should have a red circle with an X through it, indicating no communications.
- 6.1.6 Double click on the “X” on the PSCA Module. This will bring up a configuration box to enter the serial number of the UUT and hardware form (with daughter card). Click “OK” button when done.
- 6.1.7 From the menu, Download Controller Setup by going to **Device->Download->Download Wizard**. Follow instructions in dialog boxes that follow.
- 6.1.8 After all downloads completed successfully, bring unit online in ToolboxST and check that the red circle with an X through it is gone and ToolboxST will communicate with PSCA Module.
- 6.1.9 Click on the “+” tab to the left of the PSCA icon. Should display 6 “Port# - ModbusMasterSerial Station 1” that are attached to the PSCA.
- 6.1.10 Click on “Port 1 – ModbusMasterSerial – Station 1”. Then click on the “COIL” tab in the window to the right. Should display 1 through 16 coils attached to the unit. The first column of variables (LIVE VALUES) should all be “FALSE” (GREEN). The second column to the right (I/O LIVE VALUE) should all be “FALSE” (RED).
- 6.1.11 Turn the “PSCA COM PORTS” selector switch to “1”.
- 6.1.12 From the desktop, start the “mod\_RSsim.exe” program by double clicking on the icon.

<p><b>LOU-GED-IS200SSCA REV. A</b></p>	<p><b>g</b></p> <p><b>GE Energy</b> <i>Part &amp; Repair Services Louisville, KY</i></p>	<p><b>Page 4 of 5</b></p>
--	--	---------------------------

- 6.1.13** The program should start flashing and may start communicating. If not, then click the “Toggle Port Open/Close” to stop communications, then click on it again to re-start communications. Both lights in the top center of the program should start blinking after approximately 30 seconds. Also, at bottom left of program a YELLOW box should be around Port 1.
- 6.1.14** In ToolboxST, all of the variables in both the “LIVE VALUES” column and the “I/O LIVE VALUE” column should alternate from “FALSE” to “TRUE”. Let unit run awhile and communicate to verify operations.
- 6.1.15** Turn the “PSCA COM PORTS” selector switch to “2”.
- 6.1.16** The “mod\_RSsim.exe” program should start flashing and may start communicating. If not, then click the “Toggle Port Open/Close” to stop communications, then click on it again to re-start communications. Both lights in the top center of the program should start blinking after approximately 30 seconds. Also, at bottom left of program a YELLOW box should be around Port 1.
- 6.1.17** In ToolboxST, all of the variables in both the “LIVE VALUES” column and the “I/O LIVE VALUE” column should alternate from “FALSE” to “TRUE”. Let unit run awhile and communicate to verify operations.
- 6.1.18** Turn the “PSCA COM PORTS” selector switch to “3”.
- 6.1.19** The “mod\_RSsim.exe” program should start flashing and may start communicating. If not, then click the “Toggle Port Open/Close” to stop communications, then click on it again to re-start communications. Both lights in the top center of the program should start blinking after approximately 30 seconds. Also, at bottom left of program a YELLOW box should be around Port 1.
- 6.1.20** In ToolboxST, all of the variables in both the “LIVE VALUES” column and the “I/O LIVE VALUE” column should alternate from “FALSE” to “TRUE”. Let unit run awhile and communicate to verify operations.
- 6.1.21** Turn the “PSCA COM PORTS” selector switch to “4”.
- 6.1.22** The “mod\_RSsim.exe” program should start flashing and may start communicating. If not, then click the “Toggle Port Open/Close” to stop communications, then click on it again to re-start communications. Both lights in the top center of the program should start blinking after approximately 30 seconds. Also, at bottom left of program a YELLOW box should be around Port 1.

<p><b>LOU-GED-IS200SSCA REV. A</b></p>	<p><b>g</b></p> <p><b>GE Energy</b> Part &amp; Repair Services Louisville, KY</p>	<p><b>Page 5 of 5</b></p>
--	---	---------------------------

- 6.1.23** In ToolboxST, all of the variables in both the “LIVE VALUES” column and the “I/O LIVE VALUE” column should alternate from “FALSE” to “TRUE”. Let unit run awhile and communicate to verify operations.
- 6.1.24** Turn the “PSCA COM PORTS” selector switch to “5”.
- 6.1.25** The “mod\_RSsim.exe” program should start flashing and may start communicating. If not, then click the “Toggle Port Open/Close” to stop communications, then click on it again to re-start communications. Both lights in the top center of the program should start blinking after approximately 30 seconds. Also, at bottom left of program a YELLOW box should be around Port 1.
- 6.1.26** In ToolboxST, all of the variables in both the “LIVE VALUES” column and the “I/O LIVE VALUE” column should alternate from “FALSE” to “TRUE”. Let unit run awhile and communicate to verify operations.
- 6.1.27** Turn the “PSCA COM PORTS” selector switch to “6”.
- 6.1.28** The “mod\_RSsim.exe” program should start flashing and may start communicating. If not, then click the “Toggle Port Open/Close” to stop communications, then click on it again to re-start communications. Both lights in the top center of the program should start blinking after approximately 30 seconds. Also, at bottom left of program a YELLOW box should be around Port 1.
- 6.1.29** In ToolboxST, all of the variables in both the “LIVE VALUES” column and the “I/O LIVE VALUE” column should alternate from “FALSE” to “TRUE”. Let unit run awhile and communicate to verify operations.

## **6.2 Burn-In**

- 6.2.1** Let unit run for at least 48 hours.
- 6.2.2** Cycle power to UUT.
- 6.2.3** Repeat steps through.
- 6.2.4** If successful testing is complete.
- 6.2.5** After testing has been completed successfully, remove UUT, reinstall GOLD card, and verify successfully operation in ToolboxST.

## **6.3 \*\*\*TEST COMPLETE\*\*\***