



GE Energy

Functional Testing Specification

Parts & Repair Services
Louisville, KY

LOU-GED-DS200ACNA

Test Procedure for a ARCNET interface card


DOCUMENT REVISION STATUS: Determined by the last entry in the "REV" and "DATE" column

REV.	DESCRIPTION	SIGNATURE	REV. DATE
A	Initial release	K. Greenwell	07/15/02
B	Clarified test instructions	P. Kelley	09/29/2010
C			

© COPYRIGHT GENERAL ELECTRIC COMPANY

Hard copies are uncontrolled and are for reference only.

PROPRIETARY INFORMATION – THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF GENERAL ELECTRIC COMPANY AND MAY NOT BE USED OR DISCLOSED TO OTHERS, EXCEPT WITH THE WRITTEN PERMISSION OF GENERAL ELECTRIC COMPANY.

PREPARED BY K. Greenwell	REVIEWED BY R. Duvall	REVIEWED BY P. Kelley	QUALITY APPROVAL 
DATE 07/15/02	DATE 07/31/02	DATE 09/29/2010	DATE 07/31/02

<p>LOU-GED-DS200ACNA REV. B</p>	<p>g</p> <p>GE Energy Parts & Repair Services Louisville, KY</p>	<p>Page 2 of 4</p>
--	--	---------------------------

Functional test procedure for an ARCNET interface card

1. SCOPE

1.1 This is a functional testing procedure for an ARCNET interface card.

2. STANDARDS OF QUALITY

2.1 Refer to the current revision of the IPC-A-610 standard for workmanship standards.

3. APPLICABLE DOCUMENTS

3.1 The following document(s) shall form part of this specification to the extent specified herein. Unless otherwise indicated, the latest issue shall apply.

3.1.1 Check board's electronic folder for more information

4. ENGINEERING REQUIREMENTS

4.1 Equipment Cleaning

4.1.1 Equipment should be clean and free of debris prior to applying power unless performing an initial check. Refer to site specific SRA's for cleaning guidelines.

4.2 Equipment Inspection

4.2.1 Equipment should be visually inspected for any defects prior to applying power. This inspection should include the following as a minimum:

4.2.1.1 Wires broken or cracked

4.2.1.2 Terminal strips / connectors broken or cracked

4.2.1.3 Loose wires

4.2.1.4 Components visually damaged

4.2.1.5 Capacitors leaking

4.2.1.6 Solder joints damaged or cold

4.2.1.7 Circuit board burned or de-laminated

4.2.1.8 Printed wire runs burned or damaged

5. EQUIPMENT REQUIRED

5.1 The following equipment is required to perform the process requirements. Equipment may be substituted provided that all accuracy's and test ratios are equivalent or better.

Qty	Reference #	Description
1	H033760	AC2000 Drive
1	H033759	IOS station

<p>LOU-GED-DS200ACNA REV. B</p>	<p>g</p> <p>GE Energy Parts & Repair Services Louisville, KY</p>	<p>Page 3 of 4</p>
--	--	---------------------------

6. Testing Process

6.1 Testing Procedure

- 6.1.1 Power down test drive and remove shop DS200ACNA card.
- 6.1.2 Install card to be tested.
- 6.1.3 Apply power to drive.
- 6.1.4 Verify that IOS station is communicating (RPM on display for drives 1-5).
 - 6.1.4.1 Refer to "IOS Loading Instructions" in DC2000 Test Instructions (Section 7, Loading IOS LAN Test Software) if Test Type display doesn't indicate "acnet".
- 6.1.5 Verify that DRIVE #2 LED on IOS station is blinking.
- 6.1.6 Apply power to test drive # 3 & # 4.
- 6.1.7 Verify that DRIVE #3 & #4 LEDs on IOS station is blinking.
 - 6.1.7.1 This verifies that downstream communication is functioning.
- 6.1.8 Press Drive #2 pushbutton on IOS and verify that Drive # 2 jogs the connected motor.
 - 6.1.8.1 Repeat for Drive # 3 & Drive # 4 with 3 and 4 pushbuttons on the display.
- 6.1.9 Burn in for 1 hour.
- 6.1.10 Repeat jog test 6.2.8.
- 6.1.11 Turn off power and remove board being tested.

6.2 ***TEST COMPLETE ***

7. Loading IOS LAN Test Software

7.1 Setup

- 7.1.1 Change to IOS Cable
- 7.1.2 Plug other end to Drive Under Test

7.2 Test

- 7.2.1 IOS is DOS based and must be booted up from DOS prompt
- 7.2.2 T:\enter& CD\Enter then>
- 7.2.3 IOS enter
- 7.2.4 IOS enter
- 7.2.5 Type **IOS "Enter"**
- 7.2.6 T:\>Type **IOS2 "Enter"**
- 7.2.7 You should now be in the "IOS Configuration Software"
 - 7.2.7.1 Press **Space Bar**

<p>LOU-GED-DS200ACNA REV. B</p>	<p>g</p> <p>GE Energy <i>Parts & Repair Services Louisville, KY</i></p>	<p>Page 4 of 4</p>
--	---	---------------------------

7.2.8 The "Main Menu" will appear on the screen with **(deFine system and/or ios configuration.)** highlighted.

7.2.8.1 You can only make this selection at this point so press **"Enter"**.

7.2.8.2 **"The IOS to be configured is ->di05"** will appear on screen.

7.2.8.3 Press **F10**

7.2.9 The "Main Menu" will again appear on the screen.

7.2.9.1 Arrow down to **"Utilities"**

7.2.9.2 Press **"Enter"**

7.2.10 **"Utility selections"** will appear on screen.

7.2.10.1 Arrow down to **"Download configuration file to operator station"**

7.2.10.2 Press **"Enter"**

7.2.11 **"DS200 Series IOS/IEI Serial Link Utility"** will appear on screen followed by selections>

7.2.11.1 Select **"Local IOS/IEI <-=File"**

7.2.11.2 Press **"Enter"**

7.2.12 **"Download EE File to IOS Local"** will appear under **"DS200 Series IOS/IEI Link Utility"** followed by a selection screen.

7.2.12.1 Arrow down to the specific test you wish to run.

7.2.12.2 Select **"Arcnet.H09"** or **"DLAN.H10"**, then press **"Enter"**

7.2.13 **Arcnet.H09** will test the Arcnet communication between all drives (BNC Connector on Drives)

NOTE: You should see scrolling data on the screen and verify that **Arcnet** appears in the **Test Type** display of the IOS panel at the end of the test sequence.

7.2.14 **DLAN.H10** Will appear DLAN-Communications between all Drives (Terminal Strip)

NOTE: You should see scrolling data on the screen and verify that **DLAN** appears in the **Test Type** display of the IOS panel at the end of the test sequence.

7.2.15 To Exit: Arrow down to **"Exit Program"** and press **"Enter"**

7.2.16 **End**

8. Notes

8.1 None at this time

9. Attachments

9.1 None at this time