



GE Energy

Functional Testing Specification

Parts & Repair Services
Louisville, KY

LOU-GEF-TRAD4

Test Procedure for TRAD4 Printed Circuit Board

DOCUMENT REVISION STATUS: Determined by the last entry in the "REV" and "DATE" column

REV.	DESCRIPTION	SIGNATURE	REV. DATE
A	Initial release	Rick Diercks	04/14/2011
B			
C			

© COPYRIGHT GENERAL ELECTRIC COMPANY

Hard copies are uncontrolled and are for reference only.

PROPRIETARY INFORMATION – THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF GENERAL ELECTRIC COMPANY AND MAY NOT BE USED OR DISCLOSED TO OTHERS, EXCEPT WITH THE WRITTEN PERMISSION OF GENERAL ELECTRIC COMPANY.

PREPARED BY Rick Diercks	REVIEWED BY	REVIEWED BY	QUALITY APPROVAL <i>Charlie Wade</i>
DATE 04/14/2011	DATE	DATE	DATE 4/15/2011

<p>LOU-GEF-TRAD4 REV. A</p>	<p>g</p> <p>GE Energy Parts & Repair Services Louisville, KY</p>	<p>Page 2 of 4</p>
--	--	---------------------------

Functional test procedure for TRAD4 Printed Circuit Board

1. SCOPE

- 1.1 This specification provides the Engineering Requirements for testing the TRAD4 printed circuit board. The process applies TRAD4, TRAD4A, and TRAD4B boards model number 44A294516-G01 and 44A294516-G02.

2. STANDARDS OF QUALITY

- 2.1 Refer to the current revision of the IPC-A-610 standard for workmanship standards.

3. APPLICABLE DOCUMENTS

- 3.1 The following document(s) shall form part of this specification to the extent specified herein. Unless otherwise indicated, the latest issue shall apply.

3.1.1	GEK-25317	Diagnostic Software for 1050MCCM Controls
3.1.2	GEK-45668	Computer Access Panel
3.1.3	44C389941	Schematics

4. ENGINEERING REQUIREMENTS

4.1 Description

- 4.1.1 The TRAD4 board is comprised of two sections. One section is used to amplify the signals, which are produced by the photoelectric cells in tape reader. The other section provides output, which operate the stepping motor of the 150-CPS, sprocket drive, and photoelectric tape reader.

4.2 Equipment Cleaning

- 4.2.1 Equipment should be clean and free of debris prior to applying power unless performing an initial check. Refer to site specific SRA's for cleaning guidelines.

4.3 Equipment Inspection

- 4.3.1 Equipment should be visually inspected for any defects prior to applying power. This inspection should include the following as a minimum:

- 4.3.1.1 Wires broken or cracked
- 4.3.1.2 Terminal strips / connectors broken or cracked
- 4.3.1.3 Loose wires
- 4.3.1.4 Components visually damaged
- 4.3.1.5 Capacitors leaking
- 4.3.1.6 Solder joints damaged or cold
- 4.3.1.7 Circuit board burned or de-laminated
- 4.3.1.8 Printed wire runs burned or damaged

5. EQUIPMENT REQUIRED

- 5.1 The following equipment is required to perform the process requirements. Equipment may be substituted provided that all accuracy's and test ratios are equivalent or better.

Qty	Reference #	Description
1	GE 1050MCCM Control	CPU3 Model
1	GE Computer Access Panel	External Interface
1	Diagnostic Tape Specific to Control	Diagnostic Tape
1	Executive Tape Specific to Control	Executive Tape

6. TESTING PROCESS

6.1 Diagnostic Test

6.1.1 Remove Shop TRAD4 and install TRAD4 to be tested.

6.1.2 Turn on Control.

6.1.3 Load the Diagnostic.

6.1.3.1 Once the tape is fully loaded it will rewind back to the beginning (Before Test No. 1). The Display should show: Depress "Control OFF", then ON, follow this instruction at this time. If the Computer Access Panel is hooked up you will also have to hit the RUN switch to start the control's Diagnostic program.

6.1.4 Setup the control for testing.

6.1.4.1 Depress "**Option Stop**" button (Cycle Start and Option Stop push button will quit flashing).

6.1.4.2 Test All Board Test; depress "**Cycle Start**" to run test. If all pass go on to Mode One Test (Depress "**Next**" than enter 1 from keyboard. Run for 1 to 2 hours.

**** If there is no Errors go on to Functional Test.**

<p>LOU-GEF-TRAD4 REV. A</p>	<p>g</p> <p>GE Energy Parts & Repair Services Louisville, KY</p>	<p>Page 4 of 4</p>
--	--	---------------------------

6.2 Functional Test

6.2.1 Running TRAD4 in operation mole.

6.2.1.1 Load Executive Tape.

6.2.1.2 When Tape is loaded Depress Control **“ON”** to take control out of E-Stop, E-Stop light should go off and LED6 and LED7 on COM4 should come **“ON”**. Depress Emergence Stop LED6 and LED should turn **‘OFF’** then Depress Control **“ON”** to take control out of E-Stop light should go **“OFF”** and LED6 and LED7 should come **“ON”**.

6.2.1.3 Shut down Control and remove TRAD4.

6.3 ***TEST COMPLETE ***

7. REFERENCES

7.1 None at this time.