

## How to Use the GUI

1. Write code in the text-area
2. Click **Compile**
3. Click on input registers' (flagged by **I** in their top left corner) bit values to change inputs (type in hexadecimal strings when prompted)
4. Step through the circuit execution using the **Step** button (this raises and lowers the clock)
5. Rewrite / recompile at will