

SPI Driver Serial EEPROM Demonstration

This demonstration is included in your installation of MPLAB Harmony. MPLAB Harmony is available for download from the Microchip website by visiting: <http://www.microchip.com/mplabharmony>. Once you are on the site, click the **Downloads** tab to access the appropriate download for your operating system.

For additional information on this demonstration, refer to the “Applications Help” section in the MPLAB Harmony Help.

Description

In this demonstration application, the SPI Driver is used to access the external EEPROM in the Explorer 16 Development Board to perform Write and Read operations and indicates the result by LED.

MPLAB Harmony Location

<install-dir>/apps/driver/spi/serial_eeprom

Where <install-dir> refers to the default MPLAB Harmony installation path:

- Windows: C:/microchip/harmony/<version>
- Mac OS/Linux: ~/microchip/harmony/<version>