



INSTRUCTION MANUAL

AL-815T

HORN SPEAKER

WARNING :

- Installation by qualified persons only.
- Speakers must be wired in parallel and connected to the correct line terminals of amplifier.
- Ensure that all speakers have the same polarity with respect to each other.
- Do not select other tapings if the speaker is in use.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.

SPECIFICATIONS

| | | |
|--|--------------|---|
| Model | | AL-815T |
| Rate Power (RMS) | | 15 W |
| Impedance | | 333 Ω , 667 Ω , 1k3 Ω , 2k5 Ω & 5k Ω |
| Power Taps | 100 V | 15 W, 7'5 W, 4 W & 2 W |
| | 70 V | 15 W, 7'5 W, 4 W, 2 W & 1 W |
| Sensitivity SPL (1 W / 1 m) | | 107 dB |
| Sound pressure SPL (15 W / 1 m) | | 119 dB |
| Freq. Range | | 380 Hz ~ 14000 Hz |
| Dispersion (1kHz / 4 kHz) | | 110° / 30° |
| Dimension | | Ø 210 x 235 (height) |
| Protection range | | IP-66 (IEC-529) |
| Weight | | 1,6 kg |
| Finish | | Aluminium, ivory colour |
| Accessory | | Swivel bracket |

FREQUENCY RESPONSE

